# A80 QC MKII

# SERVICE INSTRUCTIONS



Prepared and edited by

STUDER REVOX TECHNICAL DOCUMENTATION Althardstrasse 10 CH-8105 Regensdorf-Zürich Switzerland

We reserve the right to make alterations

Copyright by WILLI STUDER AG Printed in Switzerland

Order No. 10.23.1832 (ED.0788)

2	BEDIENUNG	OPERATING
3	MECHANISCHE EINSTELLUNGEN	MECHANICAL ADJUSTMENTS
	LAUFWERK	TAPE TRANSPORT
4	ELEKTRISCHE EINSTELLUNGEN	ELECTRIC TAPE TRANSPORT
	LAUFWERKSTEUERUNG	ALIGNMENTS
5	AUDIO ELEKTRONIK	AUDIO ELECTRONICS
6	VERDRAHTUNG  LAUFWERK-ELEKTRONIK	WIRING TAPE TRANSPORT ELECTRONICS
	LAUFWERK-ELEKTRONIK  SCHALTBILDER	TAPE TRANSPORT ELECTRONICS  CIRCUIT DIAGRAMS
7	LAUFWERK-ELEKTRONIK  SCHALTBILDER	TAPE TRANSPORT ELECTRONICS  CIRCUIT DIAGRAMS
6 7 8	SCHALTBILDER ALLGEMEINES  SCHALTBILDER LAUFWERK-STEUERUNG  SCHALTBILDER	CIRCUIT DIAGRAMS  CIRCUIT DIAGRAMS  CIRCUIT DIAGRAMS  TAPE TRANSPORT CONTROL  CIRCUIT DIAGRAMS
3	SCHALTBILDER ALLGEMEINES  SCHALTBILDER LAUFWERK-STEUERUNG	CIRCUIT DIAGRAMS GENERAL  CIRCUIT DIAGRAMS TAPE TRANSPORT CONTROL

## WORLDWIDE DISTRIBUTION

Switzerland:

STUDER INTERNATIONAL AG

Althardstrasse 10 CH-8105 Regensdorf Phone: (01) 840 29 60

825 887 sti ch Telex: Telefax: (01) 840 47 37 (G3/2)

**EUROPE** Germany:

STUDER REVOX GmbH

Studiotechnik

Talstrasse 7, D-7827 Löffingen

Phone: 07654/803-0 Telex: 7722118 rvox d Telefax: 76547143 (G3) Cables: studer löffingen

Austria:

STUDER REVOX WIEN Ges.M.B.H.

Ludwiggasse 4 A-1180 Wien

Phone: (0222) 47 33 09 / 47 34 65 Telex: 11/5275 studr a Telefax: 222-47 89 43 (G3)

France:

STUDER FRANCE S.A.R.L.

12 – 14, rue Desnouettes

F-75015 Paris

Phone: 1-45335858 Telex: 204744 studer f Telefax: 1-45334607 (G3)

Italy:

AUDIO INTERNATIONAL SRL

Via Santa Maria, 100

I-20090 San Maurizio al Lambro (MI)

Phone: (02) 25390121 322460 audint i Telefax: (02) 25391008 (G3)

Great Britain:

F.W.O. BAUCH LIMITED

49 Theobald Street

Boreham Wood, Hertfordshire WD6 4RZ

Phone: 01-953 00 91 Telex: 27502 bauch g Telefax: 1-207 59 70 (G3) Cables: bauch borehamwood

**SOUTH AMERICA** 

Brazil:

STERLING DO BRASIL Rua Vitoria 192 – Con. 42 Cep 01210 Sao Paulo – SP

Phone: 55/11/2205612 038/1123979 bris br

Venezuela:

ACUSTILAB

INGENIERIA ELECTROACUSTICA S.R.L.

Aptdo. 65619

Santa Paula - Caracas 1066 A

Phone: 2/9874634 Telex: 28681 cored vc **FAR EAST** 

Hong Kong:

STUDER REVOX (Far East) LTD. 25th Floor Arion Commercial Centre 2-12 Queen's Road West, Hong Kong

Phone: 5-412050 & 5-441310 60185 srfel hx Telefax: 25-8151735 (G3) Cables: studerteam hong kong

Singapore:

STUDER REVOX AUDIO PTE LTD. 173, Goldhill Centre

Singapore 1130 Phone: 2507222/3 50830 sra rs Telex: Telefax: 256 22 18 (G3)

Japan:

STUDER REVOX JAPAN LTD.

1-45-13 Tomigaya Shibuya-Ku Tokyo 151

Phone: (03) 465-2211 Telex: 27618 rfent j Telefax: (03) 465-2214

Australia:

SYNTEC INTERNATIONAL PTY LIMITED

60 Gibbes Street

Chatswood, N.S.W. 2067

Phone: 4064700 & 4064557 & 4064627

70570 syntec aa Telefax: 2-406 6136 (G3)

**NORTH AMERICA** 

Canada:

STUDER REVOX CANADA LIMITED

14 Banigan Drive Toronto, Ontario M4H 1E9

Phone: (416) 423-2831 Telex: 6-23310 studer tor Telefax: 425 69 06 (G3)

USA:

STUDER REVOX AMERICA, INC. 1425 Elm Hill Pike

Nashville, Tennessee 37210

Phone: (615) 254-5651 Telex: 6823006 studer nas Telefax: 2567619 (G3)

## **SICHERHEIT**

Durch Entfernen von Gehäuseteilen, Abschirmungen etc. werden stromführende Teile freigelegt. Aus diesem Grunde müssen die folgenden Sicherheitsvorschriften unbedingt beachtet werden:

# 1. Eingriffe in ein Gerät

dürfen nur von Fachpersonal vorgenommen werden.

# **2. Vor Entfernen von Gehäuseteilen:** Gerät ausschalten und vom Netz trennen.

# 3. Bei geöffnetem Gerät:

- Netzteil- oder Motorkondensatoren mit einem passenden Widerstand entladen.
- Bauteile grosser Leistung, wie Leistungstransistoren und -widerstände sowie Magnetspulen und Wickelmotoren erst nach dem Abkühlen berühren.

# 4. Servicearbeiten bei geöffnetem, unter Spannung stehendem Gerät:

- Keine blanken Schaltungsteile berühren
- Isolierte Werkzeuge verwenden
- Metallene Halbleitergehäuse nicht berühren, da sie hohe Spannungen aufweisen können.

# ERSTE HILFE (bei Stromunfällen)

# Bei einem Stromunfall die betroffene Person raschmöglichst vom Strom trennen:

- Durch Ausschalten des Gerätes
- Ausziehen oder Unterbrechen der Netzzuleitung
- Betroffene Person mit isolierendem Material (Holz, Kunstoff) von der Gefahrenguelle wegstossen
- Nach einem Stromunfall sollte immer ein Arzt aufgesucht werden.

# **ACHTUNG**

EINE UNTER SPANNUNG STEHENDE PER-SON DARF NICHT BERÜHRT WERDEN, SIE KÖNNEN DABEI SELBST ELEKTRI-SIERT WERDEN!

# 2. Bei Bewusstlosigkeit des Verunfallten:

- Puls kontrollieren,
- bei ausgesetzter Atmung künstlich beatmen.
- Seitenlagerung des Verunfallten und Arzt verständigen.

## **SAFETY**

There are no user serviceable components inside the equipment, live parts are laid open when removing protective covers and shieldings. It is essential therefore to ensure that the subsequent safety rules are strictly observed when performing service work or repairs.

# **1. Servicing of electronic equipment** must be performed by qualified personnel only.

# 2. Before removing covers:

Switch off the equipment and unplug the mains cable.

# 3. When the equipment is open:

- Discharge power supply- and motor capacitors through a suitable resistor.
- Components, that carry heavy electrical loads, such as power transistors and resistors as well as solenoid coils and motors should not be touched before a cooling off interval, as a precaution to avoid burns.

# 4. Servicing unprotected and operating equipment:

- Never touch bare wires or circuitry
- Use insulated tools only
- Never touch metal semiconductor cases because they may carry high voltages.

# FIRST AID (in case of electric shock)

# Separate the person as quickly as possible from the electric power source:

- by switching off the equipment,
- unplugging or disconnecting the mains cable,
- pushing the person away from the power source by using dry insulating material (such as wood or plastic).
- After having sustained an electric shock, always consult a doctor.

# **WARNING:**

DO NOT TOUCH THE PERSON OR HIS CLOTHING BEFORE POWER IS TURNED OFF, OTHERWISE YOU STAND THE RISK OF SUSTAINING AN ELECTRIC SHOCK AS WELL!

# 2. If the person is unconscious

- Check the pulse,
- reanimate the person if respiration is poor,
- lay the body down and turn it to one side, call for a doctor immediately.

# SÉCURITÉ

Si les couvercles de protection sont enlevés, les parties de l'appareil qui sont sous tension ne sont plus protégées. Il est donc d'une nécessitée absolue de suivre les instructions suivantes:

# 1. Les intervensions dans les appareils électriques

doivent être faites uniquement que par du personnel qualifié

# 2. Avant d'enlever les couvercles de protection:

Couper l'interrupteur principal et débrancher le câble secteur.

# 3. Après avoir enlevé les couvercles de protection:

- Les condensateurs de l'alimentation et des moteurs doivent être déchargés à l'aide d'une résistance appropriée.
- Il est prudent de laisser refroidir les composants de haute puissance, par ex.: transistors de puissance, résistances de puissances de même que des électroaimants et les moteurs de bobinage.

# S'il faut que l'appareil soit sous tension pendent les réglages internes:

- Ne jamais toucher les circuits non isolés
- Travailler seulement avec des outils isolés

# **PREMIERS SECOURS** (en cas d'électrocution)

# 1. Si la personne est dans l'impossibilité de se libérer:

- Couper l'interrupteur principal
- Couper le courant
- Repousser la personne de l'appareil à l'aide d'un objet en matière non conductrice (matière plastique ou boîs)
- Après une électrocution, consulter un médecin.

# **ATTENTION**

NE JAMAIS TOUCHER UNE PERSONNE QUI EST SOUS TENSION, SOUS PEINE DE SUBIR ÉGALEMENT UNE ÉLECTROCU-TION!

# 2. En cas de perte de connaissance de la personne électrocutée:

- Controller le pouls
- Si nécessaire, pratiquer la respiration artificielle
- Mettre l'accidenté sur le coté latérale et consulter un médecin.

1	ALLGEMEINES		1	GENERAL	
and any time and time time time		Seite	යක යන සහ සහ ස		page
1.1	VARIANTEN DER A80/QC KASSETTENBAND-MASCHINEN	1/ 2	1 • 1	VERSIONS OF THE ABO/QC CASSETTE TAPE RECORDER	1/8
1.1.1 1.1.2 1.1.3	A80/QC-2REPRO A80/QC-2REC/1REPRO A80/QC-1REC/2REPRO	1/2 1/2 1/3	1.1.1 1.1.2 1.1.3	A80/QC-2REPRO A80/QC-2REC/2REPRO A80/QC-1REC/2REPRO	1/8 1/8 1/9
1.2	TECHNISCHE DATEN	1/4	1 • 2	TECHNICAL SPECIFICATIONS	1/10

# 1.1 VARIANTEN DER A80/QC KASSETTENBAND-MASCHINEN

Die A80/QC Kassettenband- Maschine ist in drei Ausfuehrungen erhaeltlich. Als reine Wiedergabe-Maschine, als Zweispur- Aufnahme- und Wiedergabemaschine und als Vollspur- Aufnahmeund Zweispur- Wiedergabemaschine.

#### 1.1.1 A80/QC-2REPRO

Die A80/QC-2REPRO ist ein Stereo- Zweispurgeraet, welches nur die Wiedergabe ermoeglicht. Die PLAY-Richtung ist vor- und rueckwaerts umschaltbar. Das Geraet ist mit zwei Wiedergabekoepfen bestueckt.

Bild Fig $\circ$ 1 $\circ$ 1 zeigt den Kopftraeger von vorne mit den beiden Wiedergabekoepfen $\circ$ 

Der Wiedergabekopf {1>} ist fuer den PLAY- Betrieb VORWAERTS bestimmt. Beim Einschalten der Maschine oder bei Laufrichtungswechsel ist der PLAY-Betrieb erst moeglich, wenn beide Capstan Motoren hochgelaufen sind und die Audio-Stummschaltung abfaellt.

Der Betriebsmodus vor dem Laufrichtungswechsel ist nicht gespeichert, d.h. der gewuenschte Modus muss nach dem Hochlaufen der Capstanmotoren nochmals eingegeben werden.

Beim Einschalten des Geraetes laufen die Capstan-Motoren automatisch vorwaerts (bevorzugte PLAY-Richtung).

Kopftraeger
bestueckt mit:
2 Stereo-Wiedergabekoepfen
mit Vorverstaerker
(im Kpoftraeger eingebaut)

1.020.699.00
-> Fig.1.1
1.116.801.00
1.080.709.00

# Audiokorb

bestueckt mit: -> Fig.1.2 4 Wiedergabe-Verstaerkern {4} 1.081.952.81

#### 1.1.2 A80/QC-2REC/REPRO

Die A80/QC-2REC/REPRO ermoeglicht Aufnahme und Wiedergabe. Sie ist mit je einem Zweispur-Aufnahme- und Wiedergabekopf, sowie zwei Loeschkoepfen ausgeruestet. Auch diese Maschine besitzt zwei Capstanmotoren, ist jedoch nur fuer eine PLAY-Bandlaufrichtung bestimmt.

Kopftraeger bestueckt mit: 1 2-Spur Wiedergabekopf mit Vorverstaerker	{1}	1.020.689.00 -> Fig.1.3 1.116.801.00 1.020.708.00
<pre>(im Kopftraeger eingebaut) 1 2-Spur Aufnahmekopf 2 Loeschkoepfe</pre>		1.116.800.00 1.116.712.01
Audiokorb		
bestueckt mit:		-> Fig.1.4
2 Wiedergabeverstaerkern	141	1.081.952.81
2 Aufnahmeverstaerkern		1.081.964.00
1 Oszillator		1.080.984.00




Fig.1.1




Fig.1.2




Fig.1.3




Fig.1.4

# 1.1.3 A80/QC-1REC/2REPRO

Die A80/QC-1REC/2REPRO ermoeglicht Aufnahme und Wiedergabe. Sie ist mit je einem Zweispur-Wiedergabe-, einem Vollspur-Aufnahme- und zwei Loeschkoepfen bestueckt.

Zwei Capstanmotoren gewaehrleisten den praeziesen Bandtransport fuer die regulaere PLAY-Bandlaufrichtung•

Kopftraeger bestueckt mit:		1.020.697.00 -> Fig.1.5
1 2-Spur Wiedergabekopf mit Vorverstaerker	{1}	1.116.801.00
<pre>(im Kopftraeger eingebaut) 1 Vollspur-Aufnahmekopf 2 Loeschkoepfe</pre>		1.317.110.00 1.116.712.01
Audiokorb		
bestueckt mit:		-> Fig.1.6
2 Wiedergabe-Verstaerkern	{4}	1.081.952.81
1 Aufnahme-Verstaerker	{5}	1.081.964.00
1 Oszillator	<b>{6</b> }	1.080.984.00




Fig.1.5




Fig.1.6

1.2 TECHNISCHE DATEN	
Varianten	
Typ A A80/QC-1REC/2F	REPRO Nr.60.120.11180
Typ B A80/QC-2REC/2F	
Typ C A80/QC-2REPRO	Nr.60.120.11182
Bandgeschwindigkeit	4,76cm/s (1 7/8ips)
Wiedergaberichtung	
Typ A A80/QC-1REC/2F	REPRO unidirektional
Typ B A80/QC-2REC/2F	REPRO unidirektional
Typ C A80/QC-2REPRO	bidirektional
Spulenadapter	
Dreizack Durchmesse	er: 8.0mm (0.31")
NAB Durchmesse	er: 76.2mm (3.0 ")
DIN Durchmesse	
Bandschlupf *1	
·	maximal 0,1%
Bandgeschwindigkeits-Abu (abgleichbar)	eichung +/-0,2%
Bandbreite	3,81mm (0,15")
Tonhoehenschwankungen (Typ C: Vorwaerts-/Ru IEC 386 (DIN 45507), bei 20 Grad C (68 Gra Spitz	
Bandzaehler	
Echtzeitanzeige	Genauigkeit +/-0.2%
Anzeige mathemati	sch oder komplementaer
Bandzuege *1 einstellbar;	0.5C.8N (5080g)
Bandzug-Maximum *1 einstellbar; je nach	Umspulzeit 1.4N (140g)
<b>Umspulzeit *1</b> fuer 1800m (5800ft) M einstellbar;	lagnetband, < 5 Min
E i nga <b>enge</b>	
NF-Anschluesse	entsprechend IEC268-14
symmetrisch, erdfrei,	
•	30Hz • • • 20kH
NF-Anschluesse 13	entsprechend IEC268-144 C-x IEC O4 (XLR-Buchse Impedanz > 5 kOh 30Hz20kH

Bandgeschwindigkeit 4	,76cm/s (1 7/8ips)
Wiedergaberichtung Typ A A80/QC-1REC/2REPR Typ B A80/QC-2REC/2REPR Typ C A80/QC-2REPRO	O unidirektional O unidirektional bidirektional
Spulenadapter Dreizack Durchmesser: NAB Durchmesser: DIN Durchmesser:	8.0mm (0.31") 76.2mm (3.0 ") 150.0mm (5.91")
Bandschlupf *1	maximal 0,1%
Bandgeschwindigkeits-Abweic (abgleichbar)	hung +/-0•2%
Bandbreite	3,81mm (0,15")
Tonhoehenschwankungen (Typ C: Vorwaerts-/Rueck IEC 386 (DIN 45507), bei 20 Grad C (68 Grad F Spitze be	)
Bandzaehler Echtzeitanzeige Ger Anzeige mathematisch	nauigkeit +/-0,2% oder komplementaer
Bandzuege *1 einstellbar; 0.	50.8N (5080g)
Bandzug-Maximum *1 einstellbar; je nach Ums	pulzeit 1.4N (140g)
<pre>Umspulzeit *1   fuer 1800m (5800ft) Magne einstellbar;</pre>	etband, < 5 Min
130-x symmetrisch, erdfrei, Eingangspegel	sprechend IEC268-14B IEC 04 (XLR-Buchse) Impedanz > 5 kOhm 30Hz20kHz max. 22dBm 50nWb/m: min. 0dBm max. 22dBm
	spreched IEC268-14B EC O2 (XLR-Stecker) Impedanz < 30 Ohm 30Hz•••20kHz min• 200 Ohm
Entzerrung *3 schaltbar Fe2 03 Cr 02 /	120/3180 us
Bezugspegel (315 Hz)	250 nWb/m

Spurbreite, Spurlage						
Aufnahmekopf A80/	emaess QC-1RE			(DIN		16) 6mm
Frequenzgang Wiederg	abe *2 Hz1	8 L LI 7			·/-2	d D
40Hz	•••12•	5kHz		4	-/-1	
BASE HI-FI Bezugs DIN 45513, IEC 94					g 19	81)
Frequenzgang Aufnahm						
Fe2 03 und Cr 02	und M				1/-3	dB
63 H	Z	12,5	kHz		+1	dB
16 k	Hzooo	18 kl	1Z	+1 df	3/-5	dB
Stoerspannung						
Effektivwerte nach Bewertungsfi	lter D	IN 45	5405	1967		
bezogen auf 250nW	b/m			2/01		
Maschine in PLAY,	ohne Fe2 0		ewert	· o +	50	dB
	162 0.			ertet		dB
Cr O2 und	Metal		ewert		62	
Shoorenamuna Snihaa	<b>6</b>		IDEME	ertet	20	uв
Stoerspannung Spitze nach CCIR 468-2	Dewei	Let				
bezogen auf 250nW						
Maschine in PLAY,	ohne l	Band	Fe2	ПЗ	50	dВ
	Cr 02	und			53	
Stoerspannung bewert	et					
Effektivwerte, bezogen auf 250nW	b/m					
Aufnahme-Wiederga						
unbewertet	F	e∠ U3 48dE		02 52dB		all dB
bewertet		46dE		52dB		dB
DIN 45405, bewertet	1967	38dE	L.	44dB	42	2dB
CCIR 468-2						
bewertet ASA-A		52dB	3	56dB	54	+dB
<b>43.</b> 64.						
Klirrfaktor bezogen auf 250nWl	b/m <sub>*</sub> 31	L5Hz				
Aufnahme / Wieder						
			2 03 02		a.1.	
			tall		a . 2 .	
Phasenstabilitaet Aufnahme-Wiedergal	be •	·/ <del>-</del> 25	Gra	d bei	10k	κHz
Azimuth-Einstellung						
einstellbar mit Nullpunkt justierl Geometrische Winke	oar		am	Kopft	raeg	ger
Uebersprechen						
Aufnahme / Wieder	gabe			_		
Stereo, I Stereo, I	peilk peil0	HZ kHz		min.		
Wiedergabe, 1kHz			zu C	нз+сн	4	
			tv	pisch	80	dB

Loeschdaempfung bei 1kHz

min. 75 dB

# Loeschfrequenz

150 kHz

Stromversorgung

(waehlbar) 100...120V, 200...240V +/-1-%

50 oder 60 Hz

Leistungs-Aufnahme

max. 320 VA

Umgebungstemperaturbereich

+10...+40 Grad C (50...104 Grad F)

Luftfeuchtigkeit

20...95% (kein Kondenswasser)

Sicherheitsstandard

gemaess IEC-Empfehlung Publikation 65, Schutzklasse 1 Gewicht (Masse)

> 100 kg (2201bs) netto brutto (Luftfracht) 123 kg (2711bs) brutto (Seefracht) 233 kg (5131hs)

Anmerkungen:

Alle Bandmaschinen aus der Typenreihe A80QC sind ab Werk fuer eine Banddicke von 18um eingestellt.


\*1 Die Daten werden nur bei Verwendung von Bandspulen mit Kerndurchmesser von min. 115mm garantiert.

\*2 Toleranz des Bezugsbandes nicht beruecksichtigt.

\*3 Einstellung nur fuer Cr 02 oder Metallband moeglich.

Alle Aenderungen, die dem technischen Fortschritt dienen, bleiben vorbehalten.

## ABMESSUNGEN (mm)



1	GENERAL	
च्या अवस्थ वर्षात्र वर्षात्र वर्षात्र वर्षात्र वर्षात्र वर्षात्र वर्षात्र वर्षात्र		page
1.1	VERSIONS OF THE A80/QC CASSETTE TAPE RECORDER	1/8
1.1.1 1.1.2 1.1.3	A80/QC-2REPRO A80/QC-2REC/2REPRO A80/QC-1REC/2REPRO	1/8 1/8 1/9
1.2	TECHNICAL SPECIFICATIONS	1/10

# 1.1 VERSIONS OF THE A80/QC CASSETTE TAPE RECORDER

The A80/QC cassette tape recorder is available in three versions: for playback only, as two-channel playback and recording, as mono-track recording and dual-track playback equipment.

#### 1.1.1 A80/QC-2REPRO

The A80/QC-2REPRO is a two-channel stereo recorder designed for playback only. The PLAY direction is switch-selectable (forward and reverse). The recorder is equipped with two reproduce heads.

Fig.1.1 shows a front view of the headblock with the two reproduce heads. Reproduce head {1>} is designed for forward PLAY mode. When the machine is switched on, or when the tape direction is reversed, it is only possible to work in PLAY mode after both capstan motors have reached their nominal speed and after the muting function drops out.

The mode in use before tape direction reversal is not retained. Thus the desired mode has to be reselected after the capstan motors have reached the nominal speed.

When the machine is switched on, the capstan motors are running in the forward direction (default PLAY direction).



# Audio basket

complete with: -> Fig.1.2
4 Reproduce amplifiers {4} 1.081.952.81

#### 1.1.2 A80/QC-2REC/REPRO

The A80/QC-2REC/REPRO is designed for RECORD/PLAYBACK operations. It is equipped with separate two-channel playback and record heads, two erase heads and two capstan motors. RECORD/PLAYBACK can only be selected for the normal PLAY direction.

Headblock complete with:	1.020.699.00 -> Fig.1.3
<pre>1 2-track reproduce head including preamplifier</pre>	{1} 1.116.801.00 1.020.708.00
(installed in headblock	ässembly)
1 2-track record head	{2} 1.116.800.00
2 Erase heads	{3} 1.116.712.01

# Audio basket




Fig.1.1




Fig.1.2




Fig.1.3




Fig. 1.4

# 1.1.3 A80/QC-1REC/2REPRO

The A80/QC-1REC/2REPRO is designed for record/ reproduce operation and is equipped with a full-track record head, a two-track reproduce head, and two erase heads. This recorder features two capstan motors.

head, and two erase heads.
This recorder features two capstan motors.
Record/reproduce is only possible in the normal PLAY direction.

<pre>Headblock complete with: 1 Two-track reproduce head including preamplifier</pre>	1.020.687 -> Fig.1.5 {1} 1.116.801.00 1.020.708.00
<pre>(installed in headblock ass 1 Full-track record head 2 Erase heads</pre>	embly {2} 1.317.110.00 {3} 1.116.712.01
Audio basket complete with: 2 Reproduce amplifiers 1 Record amplifier 1 Oscillator	-> Fig.1.6 {4} 1.081.952.81 {5} 1.081.964.00 {6} 1.080.984.00




Fig.1.5




Fig.1.6

150 kHz

# 1.2 TECHNICAL SPECIFICATIONS

Versions	Track width format of August
Type A A80/QC-1REC/2REPRO Nr.60.120.11180	Track width, format of track corresponding to IEC 944 (DIN 45516)
Type B A80/QC-2REC/2REPRO Nr.60.120.11181	record head A80/QC-1REC/2REPRO 6mm
Type C A80/QC-2REPRO Nr.60.120.11182	The state of the s
	Frequency response playback *2
Tape speed	31,5Hz18kHz +/-2 dB
(4,76cm/s) 1 7/8ips	40Hz12.5kHz +/-1 dB
Plan direction	BASF HI-FI test tape Fe2 03/ Cr 02
Play direction Type A A80/QC-1REC/2REPRO unidirectional	DIN 45513, IEC 94 (IEC standard, Prag 1981)
Type B A80/QC-2REC/2REPRO unidirectional	Frequency response recording / playback
Type C A80/QC-2REPRO bidirectional	Fe2 03 and Cr 02 and metal
,,	31.5 Hz 16 kHz +1/-3 dB
Hub adaptors	63 Hz ••• 12•5 kHz +1 dB
RETMA diameter: (8.0mm) 0.31"	16 kHz••• 18 kHz +1dB/-5 dB
NAB diameter: (76.2mm) 3.0 "	
DIN diameter: (150.0mm) 5.91"	Signal to noise ratio
Tape slip *1	RMS value
max. 0,1%	with weighting filter DIN 45405, 1967 reffered to 250 nWb/m
III CA O VI A	recorder in PLAY mode, without tape
Speed deviation	Fe2 03 weighted 59 dB
(adjustable) +/-0,2%	unweighted 53 dB
	Cr O2 and metal weighted 62 dB
Tape width	weighted 56 dB
(3,81mm) 0,15 <sup>m</sup>	
Have and Shockers	Signal to noise ratio, peak weighted
Wow and flutter (Type C: Play direction forward and backw.)	corresponding to CCIR 468-2
IEC 386 (DIN 45507),	reffered to 250 nWb/m recorder in PLAY mode, without tape
at (20 degrees C) 68 degrees F	Fe2 03 50 dB
Peak weighted max. 0,07%	Cr O2 and metal 53 dB
Tape timer	Signal to noise ratio, peak weighted
Real time indication tolerance +/-0.2%	effective value
Mathematical and complementary display sequ.	refer to 250nWb/m
Tape tensions *1	recording and playback
adjustable (5080q) 0.50.8N	Fe2 03 Cr 02 metal
(50000009) 005000000	unweighted 48dB 52dB 50dB weighted 46dB 52dB 50dB
Max. tape tension *1	DIN 45405, 1967
adjustable; dep.on rewind time (140g) 1.4N	weighted 38dB 44dB 42dB
D. J.A.J. da	CCIR 468-2
Rewind time *1 for 5800ft (1800m) tape length	weighted ASA-A 52dB 56dB 54dB
adjustable < 5 Min	
dajasedare ( ) iiii	Distortion
Inputs	reffered to 250nWb/m, 315Hz
AF-connections corresponding to IEC268-14B	record / playback
130-x IEC 04 (XLR-socket)	Fe2 03 approx• 1.5%
balanced, floating   Impedance > 5 kohms	Cr 02 approx. 2.0%
30Hz•••20kHz	metal approx. 2.0%
Input level max. 22dBm	Phase stability
for 250nWb/m: min. OdBm	record - playback +/-25degrees at 10kHz
Outputs max • 22dBm	. Jook a projudent ./ Lodeyrees de lokinz
AF-connections corresponding to IEC268-14B	Azimuth adjustment
130-x IEC 02 (XLR-plug)	adjustable by means of a knob on the head
balanced, floating Impedance < 30 ohms	assembly; zero point adjustable
30Hz•••20kHz	geometrical angle indicatio
terminating impedance min. 200 ohms	Crosstalk
Output level (RL=600 ohms) max• 22 dBm	record / playback
Equalization *3	stereo, at 1 kHz min. 25 dB
switchable Fe2 03 120/3180 us	stereo, at 10 kHz min. 20 dB
Cr O2 / metal 70/3180 us	playback, at 1kHz CH1+CH2 to CH3+CH4
	typical 80 dB
Reference level	Erase efficiency
(315 Hz) 250 nWb/m	at 1kHz min. 75 dB
	Bias frequency
	150 kHz

# Erase frequency

150 kHz

Power supply (selectable) 100...120V, 200...240V +/-1-%

50 or 60 Hz

Power consumption

max. 320 VA

Ambient temperature

(10...+40 degrees C) 50...104 degrees F

Humidity

20 • • • 95% (no condensation)

Security standard

corresponding to IEC recommendations, publication 65, class 1

# Weight

net		(100	kg)	220	1bs
gross	(airfreight)	(123	kg)	271	1bs
gross	(seafreight)	(233	kg)	513	lbs


## Remarks:

All tape recorders of the A80/QC series are factory adjusted for 18 um tape thickness.

- \*1 The specifications are guaranteed only if reels with a hub diameter of min. 115 mm are used.
- \*2 Reference tape errors not considered.
  \*3 Adjustment possible for chromium dioxide or metal tape only.

We reserve the right to make alterations as technical progress may warrant.

## DIMENSIONS {mm}



2	BEDIENUNG		2	OPERATING	
000 day day day day day		Seite	400 400 400 400 400 400 400 400 400 400		page
2 • 1	INBETRIEBNAME	2/2	2.1	FIRST-TIME OPERATION	2/6
2.1.1	Funktionspruefung	2/3	2.1.1	Function check	2/7
2.1.2	Drucktasten-Bedienung	2/3	2.1.2	Push button operation	2/7
2.1.3	EDIT-Funktion	2/3	2.1.3	EDIT function	2/7
2.1.4	Schnell-Start	2/4	2.1.4	Fast tape start	2/8
2.1.5	Elektronischer Bandzaehler	2/4	2.1.5	Electronic tape timer	2/8
2.1.6	Laufwerk-Steuerung	2/4	2.1.6	Remote control for tape transport	,
2.1.7	NF-Anschluesse	2/4	2.1.7	Audio connection	2/8

#### 2.1 INBETRIEBNAHME

# Kontrollen vor der Inbetriebnahme:

- Rueckwand oeffnen und Spannungswaehler kontrollieren. -> Fig.2.1
- Kontrolle von Steckerverbindungen auf festen Sitz (Gewaehrleistung der Kontakte).
- Verdrahtung der Phasenschieber-Kondensatoren -> Fig.2.2




Fig. 2.1

Fig. 2.2

-> Fig. 2.3 Erdung Der Anschluss der Studio-Erde erfolgt an der Bananenbuchse {A}.

- {A} Erd-Anschlüss
- {B} Netz-Sicherung
  {C} Netz-Anschluss




Fig. 2.3

# 2.1.1 Funktionspruefung

-> Fig. 2.4

Mit Netzschalter {12} Geraet einschalten.
Aufleuchten der Taste STOP {7} zeigt die Betriebsbereitschaft des Geraetes an. Gleichzeitig leuchtet der PLAY- Richtungsumschalter {3} PLAY "VORWAERTS" auf.

# 2.1.2 Drucktasten-Bedienung

-> Fig. 2.4

Wiedergabe:

Taste PLAY {1} druecken; die Andruckrollen fahren in PLAY-Position.

Aufnahme: (A80/QC-REC/REPRO) Taste PLAY {1} und REC {2} gleichzeitig druekken; die Andruckrollen fahren in PLAY-Position Maschine geht auf Aufnahme•

PLAY-Bandlaufrichtung (nur A80/QC-REPRO) Gewuenschte 3andlaufrichtung mit Taste {3} oder {4} waehlen und Taste PLAY {1} druecken. Achtung:

Nach dem Einschalten des Geraetes, oder nach dem Umschalten der Bandlaufrichtung ist der PLAY-Betrieb erst moeglich, wenn die Capstan-Motoren ihre Solldrehzahl erreicht haben.

Schnelles Vorspulen:

Taste (5) (FORW) druecken.

Schnelles Rueckspulen: Taste {6} (REW) druecken.

# Hinweis:

Fuer den Uebergang von einer Umspulrichtung in die andere, braucht die Taste STOP nicht gedrueckt zu werden. Die Steuerung speichert den vorgewaehlten Betriebsmodus. Der Uebergang erfolgt automatisch, sobald das Band stillsteht.

Einzig nach PLAY-Bandlaufrichtungswechsel muss mit der Eingabe des gewuenschten Betriebsmodus der Hochlauf der Capstan-Motoren abgewartet werden.

# 2.1.3 EDIT-Funktion

Die EDIT -Funktion wird nur bei stillstehendem ausgefuehrt.

Durch Druecken der Taste EDIT {10} fahren die Andruckrollen in EDIT- Position (Andruckaggregat nicht vollstaendig eingefahren), gleichzeitig werden die Bandzugwaagen blockiert. Das Band liegt auf den Tonkoepfen auf. In dieser Position koennen die Bandwickel von Hand gedreht werden (Suchen einer bestimmten Bandstelle).

Wird die Taste EDIT {10} waehrend dem schnellen Umspulen betaetigt, fahren die Andruckrollen in die EDIT-Position, bis die Taste wieder freigegeben wird (Zwischenhoeren).




Fig. 2.4

# Reglerknoof EDIT { 11 }

fuer variables Umspulen

Das Suchen einer Schnittstelle kann auch motorisch erfolgen (CUTAUT): Bei stehendem Band Taste EDIT {10} druecken und Reglerknopf EDIT {11} in die gewuenschte Laufrichtung (Uhrzeiger- oder Gegenuhrzeigersinn) drehen.

Die Band-Laufgeschwindigkeit ist abhaengig vom Drehwinkel des EDIT-Knopfes.

Sobald der Reglerknopf EDIT {11} gedreht wird, ist die Blockierung der Bandzugwaagen aufgehoben (geregelter Bandzug); bei Bandstillstand blockieren diese wieder (EDIT-Position).

#### 2.1.4 Schnell-Start

Taste EDIT (10) druecken (Voreinstellung), -Taste PLAY {1} druecken.

#### 2.1.5 Elektronischer Bandzaehler

-> Fig.2.4/2.5

Der elektronische Bandzaehler misst die effektive Bandlaufzeit in Stunden, Minuten und Sekunden. Angezeigt wird die Zeit durch das fuenfstellige 7-Segment-Display {8}. Die Wahl der Darstellung erfolgt durch Positionieren des Brueckensteckers {S1}, DECOD•PCB 1•228•811

ematische Darstellung: {S1} = Position A Mathematische Darstellung: Bei negativen Zeiten zeigt die Stunden- Stelle ein Minuszeichen.

Komplementaere Darstellung: {S1} = Position B 0.00.01 < 0.00.00 > 9.59.59Negative Zeiten werden durch das Komplement dargestellt.

Mit der Taste 0 (Null) {9} kann die Zaehler-elektronik zurueckgestellt werden (0.00.00).

# 2.1.6 Laufwerk-Fernsteuerung

Die Fernsteuerung des Laufwerkes erfolgt ueber den Steckanschluss REMOTE MODE CONTROL (Fernsteuerung fuer alle Funktionen, mit Rueckmeldung. Zaehler ferngesteuert, inklusive Nullstellung). Die Fernsteuerung ist identisch mit der internen Steuerung. In normaler Schaltung hat die interne Steuerung Prioritaet vor der Fernbedienung. Am Fernsteuer- Anschluss darf hoechstens eine Fernbedienung mit Rueckmeldelampen angeschlossen werden. Hingegen sind zusaetzlich mehrere Fernbedienungen ohne Rueckmeldelampen zulaessig.

#### 2.1.7 Audio-Anschluesse

-> Fig.2.6

XLR-Buchsen, nach IEC-Empfehlung 268-14

Leitungs - Eingang (INPUT) und - Ausgang (OUTPUT)

Nr.1 = Audio-Masse (Schirm) Nr.2 = A-Leitung (heiss)

 $Nr \cdot 3 = B-Leitung$ (kalt)




Fig. 2.4 {6} {5} {1} {7} {2}{10}{9} {8} {11}{12}




Fig. 2.5




Fig. 2.6

2	OPERATING	
(0x		page
2.1	FIRST-TIME OPERATION	2/ 6
2.1.1	Function check	2/ :
2.1.3	Push button operation EDIT function	2/
2.1.5	Fast tape start Electronic tape timer	2/8
2.1.6	Remote control for tape transport Audio connection	2/8

#### 2.1 FIRST-TIME OPERATION

# Checks before connecting machine to AC power: - Check voltage selector at rear of machine

- - -> Fig.2.1
- Check, that none of the plug connections have become loose during shipment.
- Check wiring of the phase-shift capacitors
  - -> Fig.2.2




Fig. 2.1

Fig. 2.2

Earthing/Grounding -> Fig.2.3 The studio earth is connected to the banana plug {A}.

- {A} Ground terminal
- Power fuse AC inlet {B}
- (c)




Fig. 2.3

#### 2.1.1

#### Function check

-> Fig. 2.4

Switch on machine with mains switch {12} • Machine is operational when STOP button {7} lights up• The PLAY direction indicator {3} points forward•

# 2.1.2 Push button operation

-> Fig.2.4

Playback:

Press PLAY button {1}, pinch rollers move into PLAY position.

Record:

Press PLAY {1} and REC {2} buttons simultaneously. Pinch rollers move in PLAY position.

The machine switches to record mode.

Tape direction in PLAY mode (only A80QC-REPRO) Select tape direction with button {3} or {4} and press PLAY button {1}. Attention:

After the machine has been turned on or after the tape direction has been reversed, PLAY operation can not be activated until the capstan motors have reached their nominal speed.

Fast forward:
Press button {5} (FORW).

Fast rewind:
Press button {6} (REW).

# Note:

when changing from one tape function to another there is no need to press the STOP button {7}. The control system automatically retains the previous setting. Reversal takes place as soon as the tape stops. Only when changing the tape direction on PLAY mode, the required function has to be keyed-in after the capstan motors have reached their nominal value.

### 2.1.3 EDIT function

The EDIT function is operative only when the tape is stopped. By pressing the EDIT button {10} the pinch rollers move into the EDIT position (pinch roller assembly engaged at midpoint) and the tape tension sensors are blokked. The tape is pressed against the heads and the reels can be turned by hand to find the desired edit point.

If the EDIT button {10} is pressed during fast rewind, the pinch rollers move into EDIT position and the fast running tape can be audied until the push button is released.




Fig. 2.4

# EDIT control knob {11}

for variable speed winding

An edit point on the tape can also be found by using the motors (CUTAUT). When the tape is stopped, press the EDIT button {10} and turn the EDIT knob {11} clockwise or counterclockwise in the desired direction. The tape speed depends on the angular setting of the EDIT control knob.

As soon as the EDIT knob {11} is turned, the tape tension sensors are no longer blocked (controlled tape tension). They are blocked again when EDIT knob is returned to its neutral position (EDIT position) and the tape has stopped.

## 2.1.4 Fast tape start

Press EDIT button {10} (preset) - press PLAY button {1}.

#### 2.1.5 Electronic tape timer

-> Fig. 2.4/2.5

The electronic tape timer counts the elapsed running time in hours, minutes and seconds by means of a 7-segment display {8} with five digits. Display mode is selected by positioning the jumper {S1} (DECODER PCB 1.228.811)

Display sequence:  $\{S1\} = Pos."A"$  0.00.01 < 0.00.00 > -.00.01Negative times are signalized by minus sign.

Complementary display sequence  $\{\$1\}$  = Pos."B" 0.00.01 < 0.00.00 > 9.59.59Negative times are signalized by complement.

Timer electronic is reset with the "0" button  $\{9\}_{\bullet}$ 

# 2.1.6 Remote control for tape transport

The remote control for tape transport is connected to the REMOTE MODE CONTROL socket (all functions with feedback signals can be remotely controlled, also the tape timer and its reset). The remote control facillity is identical to the local transport controls. When the remote control is connected to the machine the local control system has priority. No more than one remote control unit with indicator lamps can be connected.

It is possibel, through, to connect several remote controls without lamps.


#### 2.1.7 Audio connections

-> Fig.2.6

XLR-type sockets conforming to the IEC recommendation 268-14.

Line INPUT and OUTPUT:

Nr·1 = Audio ground (screen)
Nr·2 = A-line (hot)
Nr·3 = B-line (cold)






Fig. 2.5





Fig. 2.6

3	MECHANISCHE EINSTELLUNGEN LA	UFWERK	3		
		Seite			page
3.1	AUSBAU DER BAUGRUPPEN	3/4	3.1	REMOVING THE ASSEMBLIES	3/18
3.1.1	Kopftraeger	3/4	3.1.1	Headblock	3/18
3.1.2	Laufwerk-Abdeckbleche	3/4	3.1.2	Tape transport covers	3/18
3.1.3	Andruck-Aggregat	3/4	3.1.3	Pinch roller assembly	3/18
3.1.4	Bandende-Lichtschranke	3/5	3.1.4	Uptical tabe end sensor	3/19
3.1.5	Band-Umlenkrollen	3/5	3.1.5	Guide rollers Spring / Dashpot	3/19
3.1.6	Federelement / Daempfungselement		3.1.6	Spring / Dashpot	3/19
3.1.7	Bandzugwaagen	3/5	3.1.7	Tape tension sensor	3/19
3.1.8	Wickelmotoren	3/6	3.1.8	Spooling motors / Brake assembly	
	Bremsaggregate	3/6	3.1.9	Capstan motors	3/20
3.1.9	Capstan-Motoren	3/6	3.1.10		
3.1.10		3/6		Tape counter assembly	
	Zaehler-Einheit	3/6	3.1.11		3/20
3-1-11	EDIT-Regler	3/6		Power switch	3/20
	Netzschalter	3/6	3.1.13	Power inlet assembly	3/21
3.1.13	Netz-Eingangseinheit	3/7	3.1.14	Power supply unit	3/21
3.1.14		3/ 7			
		٠, .	3.2	ADJUSTMENTS	3/22
3.2	EINSTELLUNGEN	3/8	2 2 1	M	2 . 2 2
			3 • 2 • 1 3 • 2 • 2	Mechanical spooling motor brake	3/22
3.2.1	Mechanische Wickelmotor-Bremsen	3/8	3.2.2		3/23
3.2.2	Andruck-Aggregat 1. Voraussetzungen	3/9		1. Prerequisites	3/23
	<ol> <li>Voraussetzungen</li> </ol>	3/9		2. Pinch roller arm damping	3/23
	2. Andruckarm-Daempfung	3/9		3. Pinch roller contact point	
	3. Andruckrollen-Einsatzpunkt	3/9			3/24
	4. Andruckrollen-Andruckkraft	3/10	2 2 2	5. EDIT solenoid	3/25
	5. EDIT-Magnet	3/11	3.2.3		3/26
3.2.3	5. EDIT-Magnet Bandzugwaagen	3/12		<ol> <li>Spring element</li> <li>Dashpot</li> </ol>	3/26
	1. Federelement	3/12			3/26
	2. Daempfungselement	3/12		<ol> <li>Electromagnetic locking brakes</li> </ol>	3/21
	<ol> <li>Feststellbremse</li> </ol>	3/13			

STUDER A80QC MKII SECTION 3/2



## 3 MECHANISCHE EINSTELLUNGEN

LAUFWERK

W A R N U N G Netzteil und Teile des Laufwerkes fuehren Netzspannung. Um eine Elektrisierungs- Gefahr auszuschliessen, ist vor Ausbauarbeiten der Netz- Stecker zu ziehen.

## Allgemeine Hinweise

- Fuer Service- Arbeiten kann das ganze Laufwerk hochgeschwenkt werden; hierfuer Raendelschraube vorne, unterhalb des Laufwerkes loesen.
- Die Baugruppen sind leicht zugaenglich; alle Aggregate koennen an mehrpoligen Steckverbindungen von der Steuerung getrennt werden.

## Wichtig:

Bevor Steckkarten aus dem Rack gezogen, resp. eingeschoben werden, muss das Geraet mindestens 5 Sekunden ausgeschaltet sein.

# Pflegehinweis:

Aluminiumflaechen sind mit ELOXAL, Spiritus oder Alkohol zu reinigen.

# Benoetigte Werkzeuge und Hilfsmittel

- Innensechskant-Schluesselsatz 1,5...6mm
   Gabelschluessel, Schluesselweiten 7/8/14mm
   Federwaage oder Kontaktor 0...2500g
   Federwaage oder Kontaktor 0...2500g
   1 "Pancake"-Leerspule, Kerndurchmesser 6"
- 1 "Pancake"-Spule, mit Band bestueckt - Bandstueck oder Schnur, mit einer kleinen Schlaufe am Ende: Laenge 2...3m

#### 3.1 AUSBAU DER BAUGRUPPEN

siehe Klappseite, Fig.3

Kopftraeger

V O R S I C H T Um eine Magnetisierungdsgefahr der Tonkoepfe zu vermeiden, ist das Geraet vor dem Entfernen des Kopftraegers auszuschalten.

> Einstellungen an der Spurlage von Ton-, sowie Loeschkoepfen duerfen nur werkseitig ausgefuehrt werden.

- Kopftraeger-Abdeckung entfernen (2 Inbusschrauben).
- 3 Inbusschrauben {3} (3mm), von oben loesen.
- Kopftraeger vorsichtig nach oben ausfahren. ohne die Capstanwelle zu touchieren (Beschaedigungs-Gefahr).

# Laufwerk-Abdeckbleche

{2}/{6}/{7}

# Hinteres Abdeckblech {2}

- Wickelkerne {1} abnehmen.
- 6 Schrauben loesen, Abdeckblech hinten anheben und nach hinten ausfahren.

# Vorderes Abdeckblech {6}

- Abschirmung {5} nach oben abziehen• 4 Schrauben loesen•
- Andruckrollen in PLAY-Position halten; Abdeckblech ueber dem Tastenfeld anheben und nach vorne ausfahren.

# Unteres Abdeckblech {7} (zweiteilig)

Raendelschraube {8} des Klappdeckels, und 4 Schrauben loesen.

## Konsolen-Rueckwand

- 2 Schrauben loesen (unverlierbar).

# 3.1.3

# Andruck-Aggregat

- Kopftraeger {4} nach Abschnitt 3.1.1 ausbau-
- Mehrfach-Steckverbindung abziehen.3 Schrauben (Inbus, 3mm) von oben loesen.
- Andruck-Aggregat vorsichtig nach oben ausfahren.

## Montage-Hinweis

Beachte Kapitel 3.2.2, Abschnitt "Voraussetzungen"

## Wartungs-Hinweis

Ein Austausch der Andruckrollen darf nur paarweise erfolgen. Empfohlene Reinigungsmittel: Spiritus, Wasser, Seifenloesung bis 70%. Nicht zulaessige Reinigungsmittel sind Loesungsmittel jeder Art.

2	- 7	/.

Bandende-Lichtschranke {18

- Mehrfach-Steckverbindung abziehen.

- 4mm-Innensechskantschraube an Chassis-Unterseite loesen und Lichtschranke als Einheit nach oben ausfahren.

#### 3.1.5

Band-Umlenkrollen {16}

Linke Band- Umlenkrolle {16/L}

- Zentrale Inbus-Senkschraube loesen;
   Kupplungsstueck und Umlenkrolle nach oben abheben.
- 3 Inbusschrauben an Lagerflansch loesen und nach oben ausfahren.

# Rechte Band-Umlenkrolle {16/R}

(mit Bandbewegungs-Sensor {22})

- Mehrfach- Steckverbindung zu Bandbewegungssensor abziehen.
- Zentrale Inbus-Senkschraube loesen;
   Kupplungsstueck und Umlenkrolle nach oben abheben.
- 3 Inbusschrauben an Lagerflansch loesen und vorsichtig nach oben ausfahren (Vorsicht auf Bandbewegungssensor).

#### 3.1.6

Feder-Element
Daempfungs-Element

{12} L/R

{14} L/R

A C H T U N G Das Daempfungselement {14} darf nicht zerlegt oder geoeffnet werden: Lufteinschluesse im eingefuellten Daempfungsmedium beeintraechtigen die Funktion•

Ausbau

-> Fig.3/3.1

- Zentrale Inbus-Senkschraube an Bandzugwaageteller loesen und Fuehrungsrollen mit Waageteller abheben.
- Zugstangenbefestigung {15a} auf Ankerplatte loesen (2 Inbusschrauben).
- 3 Inbus-Schrauben zu Daempfer- Grundplatte {14a} loesen•
- Feder-/Daempfungselement nach oben ausfahren
- Federelement {12} von Grundplatte demontieren:
- Zentrale Klemmschraube {14b} an Daempfungselement loesen•
- 2 Inbusschrauben an Grundplatten- Unterseite loesen•

## 3.1.7

Bandzugwaagen {15}

-> Fig.3/3.1

- Zentrale Inbus-Senkschraube an Bandzugwaageteller loesen und Fuehrungsrollen mit Waageteller abheben.
- Zugstangenbefestigung {15a} auf Ankerplatte loesen (2 Inbusschrauben).
- Mehrfach-Steckverbindung (Chassis-Unterseite) abziehen.
- 3 Inbusschrauben {15b} loesen und Bandzugwaage vorsichtig nach oben ausfahren.




Fig.3.1

3.1.8	
Wickelmotoren	
Bremsaggregate	

-> Fig.3/3.1

{13} {11}

- 2 Steckverbindungen abziehen•

- 4 Inbusschrauben {15b} loesen und Wickelmotoren vorsichtig, und ohne zu verkanten, nach oben ausfahren.

# 3.1.9 Capstan-Motoren {24}

Chassis-Unterseite:

- Mehrfach-Steckverbindung abziehen.

 4 Inbusschrauben loesen und Motor vorsichtig nach unten ausfahren (Vorsicht auf Capstan-Welle).

Montage-Hinweis

Beim Wiedereinbau muessen die Capstan-Motoren, soweit es die Toleranz in ihren Befestigungen erlaubt, in hinterster, horizontaler Einbaulage (in Richtung Wickel-Motoren) ausgerichtet sein.

Pflegehinweis

Die Capstan- Welle darf nur mit einem feuchten Lappen gereinigt werden.

Achtung:

Es ist darauf zu achten, dass kein Reinigungsmittel in die Capstan- Achslagerung fliesst. Wartung:

Der Capstan- Motor ist wartungsfrei;

um jedoch dessen Lebensdauer zu erhoehen, ist eine jaehrliche Schmierung des Capstan- Lagers mit einem Tropfen Oel des Typs POP 65\* zu empfehlen. \* Best.-Nr. 20.020.401.04

# 3.1.10 Drucktasten- Einheit {17} Zaehler- Einheit {19}

-> Fig.3/3.2

Drucktasten- Einheit {17}

- Printstecker (links) ausziehen.

 2 Inbusschrauben {17a} loesen und Einheit vorsichtig nach oben ausfahren.

# Zaehler- Einheit {19}

- Printstecker abziehen.

- 2 Inbusschrauben (3mm) von oben loesen: Bei montiertem Andruck- Aggregat {20}, zugaenglich durch zwei, fuer diesen Zweck angebrachten Bohrungen {19a}.
- Zaenler vorsichtig nach vorne ausfahren.

3.1.11			
EDIT- Regler	{ 2	1	}
40° ett 40° ett 40° ett 10° et		-	-

-> Fig.3/3.2

- Mehrfach- Steckverbindung abziehen.
- 2 Inbusschrauben loesen.

-> Fig.3/3.2

- Mehrfach- Steckverbindung abziehen.
- 3 Inbusschrauben loesen.




Fig.3.1




Fig.3.2

3.1.13

Netz- Eingangseinheit {27}

-> Fig.3

#### beinhaltet:

- Netzfilter
- Betriebsstunden- Zaehler
- Capstan- Transformator

#### Ausbau:

- Frontseitig des Gehaeuses 4 Linsenkopf- Inbusschrauben loesen.
- An Gehaeuse- Unterseite 1 Inbusschraube loesen und Kabelhalterung entfernen.

3.1.14

Netzteil {26}

Fig.3/3.2 - Netz- Eingangseinheit {27} ausbauen

(Abschnitt 3.1.13).

- Audio- Kartentraeger {25} demontieren:
   Mittlere zwei, der beidseitig je 4 Inbusschrauben (2.5mm) loesen (siehe Hinweispfeile in Fig. 3).
   Vorsicht: Kartentraeger, waehrend dem Loesen der Schrauben, gegen oben festhalten.
   Kartentraeger nach unten ausfahren: Zugwirkung auf Kabelverbindungen vermeiden.
- Zwischenblech {28} demontieren: Befestigung zum Transformator- Gehaeuse (mit 6-kant-Distanzbolzen), durch Loesen der Linsenkopf- Inbusschraube (2.4mm) aufheben -Zwischenblech {28} entfernen.
- Zwischenblech {28} entfernen.
   4 Inbusschrauben {26a} (6mm) an Chassis-Oberseite loesen.
  Vorsicht: Netzteil, waehrend dem Loesen der
- Befestigungsschrauben, festhalten.
- Netzteil nach unten ausfahren.

# 3.2 EINSTELLUNGEN

3.2.1 Mechanische Wickelmotor-Bremsen

(11)

Die Bremsung der Wickelmotoren erfolgt, bei normalem Betrieb, vornehmlich durch die geregelte Gleichstrom- Bremsung der Wickelmotoren. Beim Ausfall der Netzspannung treten die mechanischen Servo- Bremsen in Aktion. Diese Bremsen wirken auch im Stillstand, bzw. beim Betaetigen der Bandwickel von Hand. Es ist daher wichtig, dass die Bremsen richtig eingestellt sind.

## Einstellung

-> Fig.3.3

1.Das Bremsband {d} muss, bei manuell geloester Bremse, exakt ueber dem Trommel- Bremsbelag positioniert bleiben.
Korrektur durch entdsprechendes Ausrichten
(Verdrehen) des Bremsbandes {d} in seinen
Nietverbindungen {f} zu den Bremshebeln.

Das Spiel {k} zwischen Bremshebel und Hebelbolzen soll in Ruhelage 0,5...lmm betragen. Die Einstellung erfolgt durch paralleles, seitliches Schieben {a} der Traegerplatte, bei geloesten Befestigungsschrauben {e}.

- 2.Der Hub {h} des Abhebebolzens soll ca. 4mm
  betragen. Durch Andruecken des Magnetankers
  von Hand. kann dieser Hub kontrolliert werden. Zur Hub-Einstellung wird der Bremsmagnet {b} verschoben. Bei angehobenem Bremsband muss der Wickelmotor frei, ohne jede
  Bremsung drehen.
- 3.Das richtige Funktionieren der Bremse kann durch kurzes Vor- und Zurueckdrehen des Wikkeladapters {c} kontrolliert werden. Dabei sollen die Bremshebel wechselweise an den Anschlag, resp. den Abhebebolzen schlagen. (schnappendes Geraeusch).
- 4.Bremszug- Einstellung in Aufwickel- Richtung (schwache Bremsung): -> Fig.3.4
  Leerspule mit 2...3m Band oder Schnur in Gegenbetriebslage auf Bandadapter auflegen.
  Federwaage (0...500g) am Bandanfang einhaengen und zur Messung kontinuierlich vorziehen.
  Durch Umhaengen der Feder {g} wird der Bremszug auf 60g eingestellt. (DIN-Spule, Kerndurchmesser 10cm).
- 5.Bremszug- Einstellung in Abwickel- Richtung (starke Bremsung): -> Fig.3.5 Leerspule mit 2...3m Band oder Schnur in Betriebslage auf Bandadapter legen. Federwaage (0...500g) am Bandanfang einhaengen und zur Messung kontinuierlich vorziehen. Mit Schraube {i} wird der Bremszug auf 120g eingestellt. Nach der Justierung des Federzuges soll der Haken am Ende der Feder horizontal stehen.




Fig. 3.3




Fig. 3.4




Fig. 3.5

3.2.2 Andruckaggregat

1201

-> Fig.3/3.6...3.8

Das Andruckaggregat besitzt zwei Elektromagnete, den Andruckmagneten {n} (rechts) und den EDIT-Magneten {c} (links). Das Andruckaggregat arbeitet in zwei Stellungen. In Stellung PLAY sind die Andruckrollen {d} und {m} ganz eingefahren; sie liegen auf den Capstanwellen auf. In Stellung EDIT fahren die Andruckrollen nicht ganz ein, d.h. sie setzen nicht auf die Capstanwellen auf.

~ ~ ~

#### EINSTELLUNG

# 1.Voraussetzungen

- Die Capstan- Motoren muessen, soweit es die Toleranz in ihren Befestigungen erlaubt, in hinterster, horizontaler Einbaulage (in Richtung Wickelmotoren) ausgerichtet sein.
- Das Andruckaggregat muss, soweit es die Toleranz in ihrer Befestigung erlaubt, in vorderster, horizontaler Einbaulage (in Richtung Tastenfeld) ausgerichtet sein.

Vorbereitungen -> Fig.3

- Kopftraeger (4) demontieren (Kap.3.1.1)
- Vorderes {6} und unteres {7} Abdeckblech demontieren (Kap.3.1.2)
- Da die nachfolgenden Einstellungen ohne eingelegtes Band erfolgen, ist die Lichtschranke {18} mit einem lichtundurchlaessigen Klebebandstueck abzudecken.


# 2.Andruckarm-Daempfung

-> Fig.3.6

Durch Drehen des Daempfer- Zylinders {b} kann die Rueckstellgeschwindigkeit der Andruckarme in ihre Ruhestellung beeinflusst werden: Sie ist so zu waehlen, dass die Andruckarme, mit moeglichst geringer Verzoegerung (Daempfung), moeglichst sanft in ihre Ruhestellungen zurueckkehren (Wechselweise PLAY > STOP -Modus waehlen).

# **3.Andruckrollen-Einsaztpunkt** -> Fig.3.7/3.8

Wichtigste Voraussetzung fuer eine exakte Bandfuehrung in der PLAY- Startphase ist das gleichzeitige Auftreffen beider Andruckrollen {d/m} auf ihre Capstan- Wellen {e/l}. Die Einstellung ist in nachfolgender Reihenfolge durchzufuehren:



#### Voreinstellung

Im PLAY-Modus bestimmt der Vorspann der Zugfeder {p} die Andruckkraft der rechten Andruckrolle {m} auf ihre Capstanwelle {l} (Einstellung der Andruckkraft folgt im Abschnitt 4.) Deshalb muss, im PLAY-Modus, der Andruckarm {r} leicht vom Anschlag des Andruck- Hilfsarms {q} abheben:

- Linke Andruckrolle {d} durch Abschrauben der Kappe (Vorsicht, Linksgewinde) demontieren.
- Rechte Andruckrolle {m} von Hand, leicht an die Capstanwelle {l} druecken, und in dieser Position festhalten - bei eingeschalteter Maschine wechselweise PLAY / STOP Tasten betaetigen; beachte Andruckarm {r}: Er muss, beim Wechsel auf PLAY-Modus, 0,3...0,5mm vom Anschlag des Hilfsarms {q} abheben (Spiel {t}).

Eine Justierung erfolgt durch seitliches Verschieben des PLAY- Magneten {n}, nach leichtem Loesen der Befestigungsschrauben (7mm).

- Linke Andruckrolle {d} wieder montieren.

#### Andruckrollen-Einsatzpunkt

#### Kontrolle:

Wechselweise linke und rechte Andruckrolle {d/m} unter langsamer, manueller Betaetigung, gegen die entsprechende Capstanwelle bewegen -

Bei der, jeweils manuell betaetigten Seite, muss die Andruckrolle zuerst zu drehen beginnen.

## Korrektur:

- Kontermutter {g} (8mm) loesen. Als Folge laesst sich die Zugstange {h...k}, durch Drehen, in ihrer Laenge veraendern. Entsprechende Korrektur vornehmen, mit anschliessender Kontrolle bei festgezogener Kontermutter {g} wiederholen.
- Kontermutter {g} angemessen festziehen und mit Sicherungslack fixieren.

Eingangs des Abschnittes erlaeuterte Einstellung des Spiels {t} zwischen rechtem Andruckarm und Andruckhilfsarm nachkontrollieren und bei Bedarf korrigieren.

# **4.Andruckrollen-Andruckkraft** -> Fig.3.7/3.8

# Kontrolle:

- Federwaage (0...2,5kg) an entsprechender Andruckrollen-Achse einhaengen -> Fig.3.8
- Taste PLAY druecken und Andruckkraft messen: Andruckrolle durch Ziehen der Federwaage leicht von der Capstanwelle abheben - Zugkraft auf Federwaage sukzessive vermindern, bis die Andruckrolle auf die Capstanwelle aufsetzt und zu drehen beginnt: In diesem Moment muss die Federwaage eine Zugkraft von 600 +/-50g anzeigen.


## Korrektur:

- Rechte Andruckrolle {m}
  - durch Veraendern des Federvorspannes  $\{p\}$  an Spannmutter  $\{s\}_{\bullet}$
- Linke Andruckrolle {d} durch Vorspannaenderung der gefederten Zugstange:

Kontermutter {i} (14mm) zu Sechskantstueck  $\{k\}$  (14mm) loesen.

Eindrehen der Schraube {h} hat eine Erhoehung der Andruckkraft zur Folge.

Kontermutter {i} festziehen und mit Sicherungslack fixieren.



# 5.EDIT-Magnet {c}

-> Fig.3.6

Er tritt, bei gewaehltem EDIT- Betriebsmodus, anstelle des PLAY- (Andruck-) Magneten in Einsatz und positioniert die Andruckrollen mit einem Abstand von ca. 4mm zu den Capstanwellen Aktiviert wird der EDIT- Magnet ueber den Mikro-Switch {o} (Ruhekontakt).

## Schaltpunkt des Mikro-Switch {o}:

kurz vor Auftreffen der rechten Andruckrolle
{m} auf die Capstanwelle {l}.

#### Kontrolle

PLAY-Taste betaetigen.
 Der EDIT-Magnet darf nicht aktiviert sein.
 (Anker-Zugstange {f} muss frei spielen).

# Spiel Ankerzugstange {f} > Mitnehmerbolzen

Im PLAY- Betriebsmodus darf der EDIT- Magnet ueber seine Ankerzugstange {f} keinen Einfluss auf die Stellung der Andruckrolle nehmen•

#### Kontrolle

- PLAY- Taste druecken.

Der Mitnehmerbolzen muss zum linken Anschlag der Fuehrungsnut in der Ankerzugstange {f} ein Spiel von 0,3...0,5mm halten.

#### Korrektur

durch entsprechendes Schieben des EDIT- Magneten {c}, nach dem Loesen der Befestigungsschrauben.

# Nachkontrolle

- Taste EDIT druecken.
- EDIT-Regler in Mittelstellung positionieren: Der Abstand zwischen Andruckrolle und Capstanwelle soll ca. 3...4mm betragen.

#### 3.2.3 Bandzugwaagen

{15}

-> Fig. 3
Waehrend den verschiedenen Funktionszustaenden
wird der Bandzug durch die Auslenkung der
Bandzugwaagen und die eingestellte Referenzspannung bestimmt. Der Drehwinkel des Waagentellers wird durch ein mechanisch gekuppeltes
Praezisions-Potentiometer {20} in ein analoges
elektrisches Signal umgewandelt. Die erforderliche Rueckstellkraft der Bandzugwaage wird
durch ein Federsystem aufgebracht das - zur
Erziehlung einer annaehernd logarithmischen
Bandzugkurve - zwei Druckfedern verschiedener
Charakteristik enthaelt.

Ein Daempfungselement {14} unterdrueckt mechanische Schwingungen des Bandzugwaagen- Systems

In EDIT-Funktion arretieren elektromagnetische Feststellbremsen die Bandzugwaagen.
Dies verhindert unerwunschte Pendelbewegungen

Dies verhindert unerwuenschte Pendelbewegungen der Bandzugwaagen und ermoeglicht das praeziese Positionieren einer gewuenschten Band-Modulationsstelle.

#### 

Montagehinweis:

 In Ruheposition der Bandzugwaage soll das Federelement und die Federelement- Zugstange in einer Flucht zueinander liegen. Korrektur

bei leicht geloesten Befestigungsschrauben.

## Rueckstellkraft

(Grundeinstellung)

 Stellring {a} ganz an Axialsicherung anstellen. Feststellschraube, um ca. 45 Grad aus der Vertikalen neigend festziehen. (Vermeidung des Streifens an der Laufwerkabdeckung)

# 2.Daempfungs-Element

{14

A C H T U N G Das Daempfungs- Element {14} darf nicht zerlegt oder geoeffnet werden•

Einstellung -> Fig.3.9
Die Hebellaenge "X" vom Daempfungs- ElementDrenpunkt {d} bis zum Federelement- Kniegelenk
{b} bestimmt die Intensitaet der Daempfung.
Die Hebellaenge laesst sich durch Verschieben
des Daempfungs- Elementes bestimmen (Klemmschrauben und Zentralschraube {d} loesen):
Groessere Hebellaenge "X"= geringere Daempfung
Grundeinstellung: "X"= 55...65mm

## Kontrollen:

- Bandzugwaage manuell in Endstellung, mit maximalem Federvorspann bringen und loslassen: Die selbsttaetig zurueckgestellte Bandzugwaage darf, bei moeglichst gering gewaehlter Daempfung, in der Endstellung nicht prellen.
- Unter Reobachtung des Kniegelenk-Bolzens {b} und dessen Spielraums in der Daempferhebel-Fuehrungsnut, Bandzugwaage manuell von einer Endstellung in die andere bewegen:

  Die Achse muss sich im Mittenbereich der Fuehrungsnut bewegen (keinesfalls darf der Daempferhebel mit Querkraft auf das Federgestaenge wirken).




Fig.3.9

# 3. Elektromagnetische Feststellbremse

-> Fig.3.10

- Die Senkschraube {a} loesen und den Waagenteller abheben.Hebelflansch {b} von Hand niederdruecken und
- Hebelflansch {b} von Hand niederdruecken und die drei Stiftschrauben {c} im Uhrzeigersinn vorsichtig drehen, bis die Ankerscheibe {d} gleichmaessig auf der Magnetglocke {e} aufliegt.
- Die drei Stiftschrauben {c} um je 1/4 Drehung im Gegenuhrzeigersinn loesen, damit sich ein Luftspalt von 0,12...0,15mm zwischen Ankerscheibe und Magnetglocke ergibt.
- Geraet einschalten und durch wechselweises Druecken der Tasten STOP und EDIT das korrekte Blockieren und Lueften der Magnete pruefen.
- Waagenteller wieder montieren und die Kontrolle EDIT STOP wiederholen.





Fig.3.10

3	MECHANICAL ADJUSTMENTS: TAPE TRANS	SPORT
		page
3.1	REMOVING THE ASSEMBLIES	3/18
3.1.1	Headblock	3/18
3.1.2	Tape transport covers	3/18
3.1.3	Pinch roller assembly	3/18
3.1.4	Optical tape end sensor	3/19
3.1.5	Guide rollers	3/19
3.1.6	Spring / Dashpot	3/19
3.1.7	Tape tension sensor	3/19
3.1.8	Spooling motors / Brake assembly	3/20
3.1.9	Capstan motors	3/20
3.1.10	Push button unit	,
	Tape counter assembly	3/20
3.1.11		3/20
	Power switch	3/20
	Power inlet assembly	3/21
	Power supply unit	3/21
3.2	ADJUSTMENTS	3/22
3.2.1		3/22
3.2.2	Pinch roller assembly	3/23
	<ol> <li>Prerequisites</li> </ol>	3/23
	<ol><li>Pinch roller arm damping</li></ol>	3/23
	3. Pinch roller contact point	3/23
	4. Pinch roller force	3/24
	5. EDIT solenoid	3/25
3.2.3	Tape tension sensors	3/26
	1. Spring element	3/26
	2. Dashpot	3/26
	3. Electromagnetic locking brakes	3/27

STUDER A80QC MKII SECTION 3/16



#### 3 MECHANICAL ADJUSTMENTS

TAPE TRANSPORT

C A U T I O N The power supply and certain tape transport components are under line voltage.
Disconnect the power plug before removing any parts!

#### General information

- The complete tape transport can be tilted 90 degree by unfastening the knurled thump screws in front of and below the tape transport.
- The assemblies are easily accessible; all modules can be separated through multipin connectors.
- The recorder must have been switched off for at least 5 seconds before any printed circuit boards are removed from or inserted into the rack.

Care instructions Clean aluminium surfaces with aluminite cleaner, ethanol or alcohol.

#### Required tools and instruments

- Set of hexagon-socket-screw keys 1.5...6mm
- Open-end wrench size 7,8,14mm
- Spring dynamometer or contactor 0...500g
  Spring dynamometer or contactor 0...2500g

- 1 Pancake reel, empty, core diameter 6"
   1 Pancake reel, with tape
   Tape section or piece of string with a small Length 2...3m loop on one end.

## 3.1 REMOVING THE ASSEMBLIES

-> Fig.3

3.1.1 Headblock

14

C A U T I O N Switch recorder off before removing the headblock in order to prevent magnetization of the soundheads!

Only the factory is authorized to adjust the track alignment of soundheads and erase heads!

- Remove headblock cover (2 socked-head-screws)
- Unfasten three 2mm socked head-screws {3}
  from the top.
- Carefully lift out the headblock without contracting the capstan shaft.

## 3.1.2 Tape transport covers

{2}/{6}/{7}

Rear cover {2}

- Remove hubs {1}
- Unfasten 6 screws, lift back of cover and slide it out toward the rear.

Front cover {6}

- Pull screen {5} off toward the top.
- Unfasten 4 screws.
- Hold pinch rollers in PLAY position; raise cover past the controls and slide it out toward the front.

Lower cover {7} (two-part)

Release knurled thumb screw {8} of the hinged cover and unfasten 4 screws.

Rear panel of console

- Unfasten 2 screws (captive).

#### 3.1.3

Pinch roller assembly {20}

- Remove headblock {4} according to Section 3.1.1.
- Unplug multipin connector.
- Unfasten 3 screws (hexagon-socket, 3mm) from the top.
- Carefully slide out the pinch roller assembly toward the top.

Reinstallation instructions

Please refer to Section 3.2.2, par. "Prerequisites".

Care instructions

Pinch rollers must always be replaced in pairs.
Cleaning, recommended cleaners:
Ethanol, water, soap solution up to 70%.
Inadmissible cleaning aids:
solvents of any type.

Optical tape end sensor

[18]

- Unplug multipin connector.

 Unfasten 4mm hexagon-socket-head screw on the underside of the chassis and slide out the light barrier as a complete assembly.

3.1.5

Guide rollers

(16)

#### Left-hand guide roller {16L}

- Unfasten hexagon-socket countersunk-head center screw; lift out coupling piece and quide roller.
- Unfasten 3 hexagon-socket-head screws on bearing flange and slide the latter out toward the top.

### Right-hand guide roller {16R}

(with tape move sensor {22})

- Unplug multipin connector to tape move sensor.
- Unfasten hexagon-socket countersunk-head center screw; slide coupling piece and guide roller out toward the top.
- Unfasten 3 hexagon-socket-head screws on bearing flange and slide the latter carefully out toward the top (carful with tape move sensor!).

#### 3.1.6 Spring / Dashpot

{12}/{14} L/R

C A U T I O N The dashpot {14} must not be disassembled or opened because the function of the dashpot is adversely affected, if any air trapped in the damping medium.

#### Removal -> Fig.3.31

- Unfasten hexagon-socket countersunk-head center screw on tape tension sensor plate and lift off guide rollers together with tape tension sensor plate.
- Unfasten pull rod mount {15a} on anchor plate (2 hexagon-socket-head screws).
- Unfasten 3 hexagon-socket-head screws in base plate of dashpot {14a}.
- Slide out spring/dashpot toward the top.
- Unplug spring element {12} from base plate: unfasten central clamping screw {14b} on the dashpot. Unfasten 2 hexagon-socket-head screws on the underside of the base plate.

#### 3.1.7 Tape tension sensor

{15}

-> Fig.3/3.1

- Unfasten hexagon-socket countersunk-head center screw on tape tension sensor plate and lift off guide rollers together with tape tension sensor plate.
- Unfasten pull rod mount {15a} on anchor plate (2 hexagon-socket-head screws).
- Unplug multipin connector (underside of chassis)
- Unfasten 3 hexagon-socket-head screws (15b) and carefully slide tape tension sensor out toward the top.




Fig.3.1

3.1.8	
Spooling motors	[13]
Brake assembly	{11}
· 	
=> Fig 3	2/2 1

- Unplug 3 multipin connectors.

 Unfasten 4 hexagon-socket-head screws {15b} and carefully slide out spooling motor toward the top without twisting it.

# 3.1.9 Capstan motors {24}

-> Fig.3

Underside of chassis:

- Unplug multipin connector

 Unfasten 4 hexagon-socket-head screws and carefully slide out motor toward the bottom (careful with capstan shaft!)

Mounting instruction:

The capstan motors should be aligned in the rear-most horizontal mounting position (against spooling motors) as far as adjustments are possible within their mounts.

#### Care instruction

Clean capstan shaft only with a moist piece of

Note:

Ensure that no cleaner flows into the capstan shaft bearing.

Maintenance:

The capstan motor require no maintenance. In order to extend its life it is recommended to lubricate the capstan bearing annually with one drop of oil (PDP 65; part No.20.020.401.04)

# 3.1.10 Push button unit {17} Tape counter assembly {19}

-> Fig.3/3.2

Push button unit {17}

- Unplug card edge connector (left).

 Unfasten 2 hexagon-socket-head screws {17a} and carefully slide the push button unit out toward the top.

#### Tape counter assembly {19}

- Unplug card edge connector.

- Unfasten 2 hexagon-socket-head screws (3mm): Accessible on the mounted pinch roller assembly {20} through two holes provided for this purpose.
- Carefully slide counter out toward the front.

3.1.11	
EDIT control	{21}
	-> Fig.3/3.2
- Unplug multipin connector.	
- Unfasten 2 hexagon-socket-head	screws.

**3.1.12** Power switch {23}

-> Fig.3/3.2

- Unplug multipin connector.

- Unfasten 3 hexagon-socket-head screws.




Fig.3.1




Fig.3.2

SECTION 3/21

_		-	
7	. 1	7	3

#### Power inlet assembly

{27}

-> Fig.3

Comprises: Line filter Operating hours meter

Capstan transformer

Disassembly:

- Unfasten 4 hexagon-socket oval-head screws on the front of the housing.

- Unfasten 1 hexagon-socket-head screw on the underside of the housing and remove cable retainer.

#### 3.1.14

Power supply unit

{26}

-> Fig.3/3.2

- Remove power inlet assembly {27}. (refer to 3.1.13)

- Remove audio board holder {25}: Unfasten the center 2 of the 4 hexagon-socket-head screws (2.5mm) on each side (see arrows in Fig.3). Careful! While unfastening the screws, lift card holder toward the top. Avoid any tension on cable connections.

- Remove shim {28}: separate the mounting to the transformer housing (with hexagon spacer pin) by unfastening the hexagon-socket oval-head screw (2.5mm) - then remove shim.

- Unfasten 4 hexagon-socket-head screws (6mm) on top of chassis. Caution: Hold power supply unit while unfastening the mounting screws.

- Slide power supply unit out toward the bottom.

#### 3.2 ADJUSTMENTS

3.2.1 Mechanical spooling motor brake [11]

In normal operation, reel rotation is braked mainly by controlled DC braking of the spooling motors. The mechanical servo brakes come into operation in the event of a power failure. These brakes also act when the tape is stationary or the reels are turned by hand. It is therefore essential that the braking forces are correctly adjusted.

#### Brake adjustment

-> Fig.3.3

1.When the brake {d} is released manually, the brake band must stay exactly above the brake lining.

Correction is possible by alligning (twisting) the brake band in its rivet connections to the brake levers.

The play {k} between brake lever and lifting pin should be 0.5...l.0mm in the neutral position. Adjustment is possible through parallel, lateral shifting {a} of the supporting plate {a} of the supporting plate while the mounting screws {e} are loosened.

- 2.The travel {h} of the lift pin should be approximately 4mm. This travel can be checked
  by pressing the solenoid plunger fully home
  by hand. The trvel is adjusted by moving the
  braking solenoid {b}. The spooling motor
  must turn completely freely when the brake
  band is released.
- 3.Correct operation of the brake can be checked
  by turning the reel adapter {c} slightly back
  and forth. The two brake levers should then
  alternately strike the end stop and the lift
  pin (a click sound).
- 4.Braking force adjustment in take-up direction (light braking) -> Fig.3.4 Place empty reel with 2...3m of tape or string on adapter in opposite direction to normal operating position.

  Attach spring dynamometer (0...500g) to tape end and pull steadily in order to measure. The braking force is obtained by repositioning the spring {g} 60g for DIN reels with 10cm core.
- 5.Braking force adjustment in supply direction
  (heavy braking) -> Fig.3.5
  Place empty reel or string on adapter in
  normal operation position.
  Attach spring dynamometer (0...500g) to the
  tape end and pull steadily in order to measure. The breaking force of 120g is set by
  means of screw {i}.
  The hook at end of the spring must be horizontal when the spring tension has been adjusted.




Fig. 3.3




Fig. 3.4




Fig.3.5

#### 3.2.2 Pinch roller assembly

1201

-> Fig.3/3.6...3.8

The pinch roller assembly has two solenoids: the PLAY solenoid {n} on the right and the EDIT solenoid {c} on the left. Thus, there are two operating positions. In PLAY position the rolers {d} and {m} are fully extended and engage the capstan shafts. In EDIT mode the rollers are not fully extended and are not in contact with the capstan shafts.

#### **ADJUSTMENT**

#### 1.Prerequisites

- The capstan motors must be aligned in their rear-most, horizontal mounting position (toward the spooling motors) as far as this possible within their mounting tolerances.
- The pinch rollers must be aligned in its foremost, horizontal mounting position (toward push button unit), as far as this is possible within its mounting tolerance.

#### Preparatory steps

-> Fig.3

- Remove headblock {4}

(Section 3.1.1)

- Remove front {6} and lower {7} panel (Section 3.1.2)

- Since the subsequent adjustments are made without tape present, the light barrier {18} must be covered with a piece of nontransparent adhesive tape.


#### 2.Pinch roller arm damping

-> Fig.3.6

The speed at which the pinch roller arms are restored to their neutral position can be influenced by rotating the dashpot. The restoring speed should be adjusted in such a way that the pinch roller arms return as smoothly as possible and with minimal delay (damping) to their neutral position (alternately select PLAY - STOP mode).

#### 3.Pinch roller contact point -> Fig.3.7/3.8

For accurate tape guidance in the PLAY start phase, both pinch rollers {d/m} must simultaneously contact their capstan shafts {e/l}. Perform the adjust in the following sequence:



#### Preliminary adjustments

In PLAY mode the initial compression of the extension spring {p} determines the pressure of the right-hand pinch roller {m} on its capstan shaft {1} (the pinch force is adjusted in Section 4). In PLAY mode, the pinch roller arm {r} must slightly lift off the tension arm {q}:

- Unfasten left-hand pinch roller {d} by unscrewing the cap (Caution! Left-hand thread).
- Press right-hand pinch roller {m} by hand lightly against the capstan shaft {1} and hold it in this position. Alternately press PLAY STOP with the recorder under power. Observe pinch roller arm {r}: it should lift off the stop of tension arm {q} by 0.3 ... C.5mm when switching to PLAY mode (play {t}). Adjustment is possible by shifting the PLAY solenoid {n} sideways after the mounting screw (7mm) has been loosened somewhat.
- Reinstall left-hand pinch roller {d}.

#### Contact point of pinch rollers

#### Check:

Alternately move the left-hand and right-hand pinch roller {d/m} by means of slow, manual actuation against the corresponding capstan shaft. The pinch roller of the manually actuated side should start to turn first.

#### Correction:

- Loosen lock nut {g} (8mm). The length of the pull rod {h...k} can be now varied by turning the rod. Correct its length as required and repeat check after the locknut {g} has been retightened.
- Tighten lock nut {g} reasonably well and secure it with locking paint.

Recheck the adjustment of the play {t} between the right-hand pinch roller arm and the tension arm, as mentioned in the beginning of this Section, and correct the play if necessary.

#### 4.Pinch roller force

-> Fig.3.7/3.8


#### Check:

- Hook spring dynamometer 0...2.5kg) to corresponding pinch roller shaft. -> Fig.3.8
- Press PLAY key and measure pinch roller force: Lift pinch roller lightly off the capstan shaft by pulling on the spring dynamometer. Gradually reduce the tension on the spring dynamometer until the pinch roller contacts the capstan shaft and starts to rotate: The spring dynamometer should indicate a tension of 600g +/-50g at this point.

#### Correction:

locking paint.

- Right-hand pressure roller {m}
  By varying the spring preload {p} an adjusting nut {s}.
- Left-hand pinch roller {d} By varying the preload of the spring-suspended pull rod: Loosen check nut {i} (14mm) of hexagon piece {k} (14mm). Turning in screw {h} increases the pinch force. Retighten check nut {i} and secure it with



#### 5.EDIT solenoid {c}

-> Fig.3.6

This magnet is activated in EDIT mode in place of the PLAY (pinch roller) solenoid. It positions the pinch rollers with a clearance of approximately 4mm to the capstan shafts. The EDIT solenoid is energized through microswitch {o} (break contact).

Switching point of microswitch {o}:
Shortly before the right-hand pinch roller
{m} contacts the capstan shaft {1}.

#### Check:

 Press PLAY key. The EDIT solenoid should be deenergized (plunger rod {f} should move freely).

Play between plunger rod {f} and driving pin

In PLAY mode the EDIT solenoid should not influence the pinch roller position though its plunger rod  $\{f\}_{\bullet}$ 

#### Check:

- Press PLAY key. The clereance between the driving pin and the left-hand stop of the guide groove in the plunger rod {f} should be 0.3...0.5mm.

#### Correction:

By shifting the EDIT solenoid  $\{c\}$ , after the mounting screw has been loosened.

#### Rechecking:

- Press EDIT key.
- Set edit control to its center position:
   The clereance between the pinch roller and the capstan shaft should be approximately
   3...4mm.

#### 3.2.3 Tape tension sensors

-> Fig. 3 The tape tension during the various operating modes is determined by the deflection of the tape tension sensors and the reference voltage. The angle of rotation of the roller plate is converted into an electrical analog signal by a mechanically coupled precision potentiometer {22}. The force needed to return the tape tension sensor is provided by a spring system comprising two compression springs of different rates to give an approximately logarithmic curve of tape tension.

A dashpot {14} prevents mechanical oscillation of the tension sensor system.

In EDIT mode the electromagnetic locking brakes block the tape tension sensors. This prevents unwanted oscillation of the tape tension sensors and permits accurate positioning at the desired tape modulation address.

#### 1.Spring element {12} spring restoring force -> Fig.3.9

Installation instructions:

- When the tape tension sensor is in neutral position, the spring element and the latter's pull rod should be in a straight line. Correction is possible by slightly loosening the mount-

ing screws.

#### Restoring force (basic setting)

- Set adjusting ring {a} fully against the axial retainer. Turn locking screw by approximately 45 degree from the vertical (in order to prevent if from contacting the tape transport cover) and tighten screw.

#### 2.Dashpot (14)

 ${\tt C}$  A  ${\tt U}$   ${\tt T}$   ${\tt I}$   ${\tt O}$   ${\tt N}$   ${\tt Do}$  not disassemble or open the dashpot! The function of the dashpot is adversely affected if air is trapped in the damping medium.

-> Fig.3.9 The lever length "X", measured from the dashpot fulcrum {d} to the toggle joint {b} of the spring element determines the damping intensity. The lever length can be adjusted by shifting the dashpot (unfasten clamping screws and center screw {d}): Larger lever length "X" = weaker damping "X" = 55...65mm.

#### Checks:

Basic setting:

- Deflect tape tension sensor manually to the limit position with maximum spring preload, then release tape tension sensor: the automatically restored tape tension sensor should not bounce against the stop when minimal damping is selected.
- Observe toggle joint pin {b} and its play in the dashpot lever guide groove. Manually shift tape tension sensor from one limit position to the other: The shaft should move in the center region of the guide groove (under no circumstance should the dashpot lever apply transverse force to the spring-suspended linkage).




Fig.3.9

#### 3. Electromagnetic locking brakes

-> Fig.3.10

- Loosen countersunk screw {a} and lift off roller plate.
- Press down armature flange {b} and carefully tirn the three anchor screws {c} clockwise until the armeture disc {d} rests evenly on the solenoid housing e}.
- Then loosen all three anchor screws {c} by 1/4 of a turn so that there is a gap of 0.12...0.15mm between armature disc and solenoid.
- Switch on the machine and alternately press the STOP and EDIT buttons to check that the solenoids lock release correctly. Refit roller plate and repeat EDIT STOP
- check.




Fig. 3.10

4	ELEKTRISCHE EINSTELLUNGEN LAUFWERKSTEU	JERUNG	4	ELECTRIC TAPE TRANSPORT ALIGNMENT	S
		Seite	40 an 40 an an an an		page
4.1	FUNKTIONSBESCHREIBUNG DER		4.1	OPERATING	
	LAUFWERK-STEUERUNG	4/2		OF TAPE TRANSPORT CONTROL	4/24
4.1.1	Anordnung der Steuer-Elektronik	4/2	4.1.1	Arrangement	
4.1.2	Drucktasten	4/3		of control electronics	4/24
4.1.3	Eingangs-Abschwaecher	4/4	4.1.2	Push buttons	4/25
4.1.4	IC Memory and Counter	4/5	4.1.3	Attenuator and Preamplifier	4/26
4.1.5	IC Decoder and Driver	4/7	4.1.4	IC MEMORY AND COUNTER	4/27
4.1.6	Logische Ausgangs-Signale	4/9	4.1.5	IC DECODER AND DRIVER	4/29
			4.1.6	Logical output signals	4/31
4.2	ELEKTRISCHE EINSTELLUNGEN	4/13			
			4.2	ELECTRIC	
4.2.1	Allgemeines	4/13		TAPE TRANSPORT ALIGNMENTS	4/35
4.2.2	Stabilisator	4/13			
4.2.3	Bandzug-Einstellungen	4/14	4.2.1	General	4/35
	l. Bandzug im PLAY∽Modus	4/15	4.2.2	Stabilizer (Voltage regulator)	4/35
	2. Bandzug-Begrenzung FORW/REW	4/16	4.2.3	Tape tension adjustments	4/36
	3. Bandzug-Begrenzung EDIT	4/17		<ol> <li>Tape tension in PLAY mode</li> </ol>	4/37
4.2.4	Brems-Regelung	4/18		<ol><li>Limiting the tape tension in</li></ol>	
4.2.5	Abgleich der Capstan-Steuerung	4/19		spooling mode	4/38
	<pre>l. Voreinstellung</pre>	4/20		<ol><li>Limiting the tape tension in</li></ol>	
	2. Capstan-Hochlaufkontrolle	4/20		EDIT mode	4/39
	3. Tachoabgleich MASTER-Capstan	4/21	4.2.4	Brake control	4/40
	4. Tachoabgleich SLAVE -Capstan	4/21	4.2.5	Capstan motor control alignment	4/41
	5. Bandzug zwischen den Capstans	4/21		<ol> <li>Preliminary adjustments</li> </ol>	4/42
	6. Schlusskontrolle	4/22		<ol><li>Capstan acceleration control</li></ol>	4/42
				3. MASTER capstan tacho alignment	4/43
				4. SLAVE capstan alignment	4/43
				5. Tape tension between capstans	4/43
				6. Final inspections	4/44

#### 4.1 FUNKTIONSBESCHREIBUNG DER LAUFWERK- STEUERUNG

#### 4.1.1 Anordnung der Steuer- Elektronik

Die gesamte Laufwerksteuerung ist, im Interesse einer optimalen Service- Zugaenglichkeit, auf Steckkarten einheitlicher Groesse in einer Steuer- Einheit (Rack- Aufbau) konzentriert. Das Rack enthaelt folgende Steckkarten:

Bezeichnung	Schema-Nr•	ΕL
CAPSTAN SERVO / MASTER Capstanmotor-Steuerung	1.080.371	12
ATTENUATOR	1.080.396	10
Eingangsabschwaecher IC MEMORY AND COUNTER Speicher-Einheit	1.080.393	9
IC DECODER AND DRIVER	1.080.391	8
IC Decoder und Treiber DUAL CAPSTAN DIRECTION BOARD Laufrichtungssteuerung	1.080.369	7
CAPSTAN SERVO / SLAVE	1.080.371	6
Capstanmotor-Steuerung SPOOLING MOTOR CONTROL Wickelmotor-Steuerung	1.080.387	5
CONTACTOR	1.080.381	4
Wickelmotor-Schuetzen STABILIZER Spannungs-Stabilisator	1.080.370	2

Eine Reihe von Sensor- Elementen ueberwachen kontinuierlich folgende Zustaende:

Sensor/ Funktion	(Signal/Name)
TAPE END SENSOR	YBI-END
Band-Praesenz/-Ende	
TAPE MOVE SENSOR	YBI-MOVE
Bandbewegung	
TAPE DIRECTION SENSOR	YBI-DIR
Bandlauf-Richtung	
TAPE TENSION SENSORS	R-TT1 / R-TT2
B <b>andzug</b>	
TACHO HEADS	YAC-M3/YAC-M6
Capstan-Drehzahl	

Diese Sensoren liefern der Steuerlogik der Wickelmotor- Steuerung und der Capstanmotor-Steuerung die, fuer Regelvorgaenge noetigen Daten. Damit wird ein optimaler Funktionsablauf und eine konstante Praezision im Bandtransport gewaehrleistet.

#### 4.1.2 Drucktasten

Die Laufwerk- Ansteuerung erfolgt ueber grossflaechige, beleuchtete Impuls-Drucktasten (LO-CAL CONTROL SWITCHES) oder ueber einen identischen Fernsteuersatz (REMOTE CONTROL SWITCHES) Die Tastenbeleuchtung des lokalen Tastensatzes wie auch des Fernsteuersatzes, signalisiert die Rueckmeldung des durchgeschalteten Steuerbefehls.

In gleicher Weise steht auch ein Rueckmeldesignal (FADER INDICATOR) fuer den Reglerstart zur Verfuegung•

#### Verriegelung

Die Tastensteuerung ist gegen Fehlbedienung verriegelt; eingetastete Befehle werden elektronisch gespeichert. Deshalb kann von der schnellen Umspulfunktion direkt die Wiedergabetaste PLAY gedruckt werden. Waehrend dem Stop-Vorgang leuchten die Tasten STOP und PLAY; bei Band- Stillstand erlischt die Taste STOP und die Steuerlogik schaltet automatisch auf Wiedergabe PLAY.

#### EDIT-Taste

Die EDIT- Taste ist nur bei stillstehendem Band oder waehrend dem schnellen Umspulen wirksam. In letzterem Fall ist die Funktion jedoch nur bei gedrueckter Taste aktiv. Nach Betaetigung der EDIT- Taste wird die EDIT

Nach Betaetigung der EDIT- Taste wird die EDIT Regelfunktion freigegeben. Bei eingerasteter Mittelstellung des EDIT- Reglers werden die Bandzugwaagen blockiert.

Die Andruckrollen bleiben jedoch in ihrer Ausgangsposition. Zur Heranfuehrung des Bandes an den Wiedergakopf ist zwischen der Andruckrolle und der rechten Umlenkrolle ein Schieber angebracht.

#### Zwischenhoeren

Wird die EDIT- Taste waehrend dem schnellen Umspulen betaetigt, fahren die Andruckrollen in EDIT- Position, wodurch die Bandaufzeichnung hoerbar wird. Die Bandzugwaagen werden dabei nicht blockiert.

#### Automatischer EDIT-Betrieb (CUTAUT)

In EDIT-Position koennen die Wickelmotoren mit dem EDIT-Regler stufenlos in beide Richtungen gesteuert werden•

Die Deblockierung der Bandzugwaagen erfolgt durch das Drehen des Reglers aus seiner Rast. Die Bandgeschwindigkeit wird durch den gewaehlten Drehwinkel des Reglers bestimmt.

# 4-1-3 Eingangs-Abschwaecher ATTENUATOR AND PREAMPLIFIER

1.080.396

Steuersignale, die vom Drucktastensatz, vom Fernsteuer- Tastensatz, vom Reglerstart- Relais und vom Geschwindigkeitsschalter eintrefen, werden im Eingangs- Abschwaecher abgeschwaecht. Die Befehlsgabe erfolgt dadurch, dass der entsprechende Eingang von den Tastenkontakten auf Potential Null gelegt wird. Am Ausgang des Abschwaechers entsteht, bei betaetigter Drucktaste, "Logisch Null". Die entsprechenden Signalspannungen betragen fuer:

"L" (0) = max. +0,4V "H" (1) = min. +2,4V

Die Prioritaet der Tastenfunktion ist durch die Reihenfolge der Tastenkontakte gegeben. Hoechste Prioritaet besitzt der Relaiskontakt Reglerstart- Relais, darauf folgt der Kontakt STOP, usw. Die Ansteuerung des Reglerstarr-Relais erfolgt ueber eine Graetz- Brueckenschaltung mittels interner Speisung (24V/FAD1/FAD2) oder externer Speisung, wobei die Polaritaet der Steuerspannung nicht beruecksichtigt werden muss. Die Reglerstart-Funktion kann auch zum "Aussteigen" aller Kanaele aus dem Aufnahme- in den Wiedergabemodus verwendet werden.

Die Steckkarte ATTENUATOR AND PREAMP" enthaelt auch die Vorverstaerker fuer den Bandendschalter und den Bandbewegungs-Sensor, sowie einen Sicherheitskreis, der die Logik auf STOP-Funktion schaltet, solange die Speisespannung ihren Sollwert nicht erreicht.

#### Band-Endschalter

Bei eingelegtem Band ist der Fotowiderstand RP-END dunkel, das resultierende Signal YBI-END ist "H".

Die Speisespannung fuer den Fotowiderstand (+16V) wird ueber den Laengstransistor (Q1)von der +24V Speisespannung geliefert.

#### Sicherheitskreis SAFETY CIRCUIT

Die Funktion des Fotoelement- Verstaerkers Q3, Q2, wird vom Schaltzustand von Q4 beeinflusst. Im Sicherheitskreis werden die Speisespannungen +24V und +5,8V ueberwacht. Solange nicht beide Spannungen ihren Sollwert erreicht haben ist einer der Transistoren Q6 oder Q7 gesperrt und Transistor Q4 wird leitend. Das Bandend-Schalter-Signal YBI-END wird "L", was die STOP-Funktion bewirkt. Gleichzeitig wird der Transistor Q8 gesperrt, ein allfaelliges Aufnahmesignal (YBI-REC ="H") wird blockiert und die Aufnahme- Relais in den Verstaerkerkanaelen fallen ab, bzw. koennen nicht anziehen.

#### Bandbewegungs-Sensor-Verstaerker

Da die Logik bei Lauffunktions- Uebergaengen selbsttaetig die gespeicherten Befehle weitergibt, muss sie ueber den Bandbewegungs-Zustand informiert sein. Zu diesem Zweck sind an der rechten Band- Umlenkrolle Sensoren angebracht, welche die benoetigten Signale erzeugen. Nach entsprechender Umwandlung geben diese Signale Auskunft ueber die Bandbewegung, Bandbewegungsrichtung und die durchlaufende Zeit (Bandzaehler).

Die Impulse, die vom Foto- Transistor QP-MOVE (QP2, TAPE MOVE SENSOR 1.080.185/186) bei laufendem Band geliefert werden, werden gleichgerichtet, integriert und verstaerkt und ergeben fuer das Signal Q-MOVE ein logisch "H".

Auf der Steckkarte 1.080.396-13 befindet sich eine Stufe (Q9), welche das Signal YPS-MOVE ueber den Fernsteuerstecker (GR22) fuer die A80-Vorwahleinheit liefert (fuer Geschwindigkeits-Auswertung).

#### 4.1.4 IC-MEMORY AND COUNTER

1.080.393

Die integrierten Schaltungen sind numeriert, ebenso sind in den Schaltbildern die Anschluesse angegeben. Ein bestimmtes "Gate" wird in den folgenden Erklaerungen durch die IC-Nummer und den Anschluss des Ausganges bezeichnet, z.B. Gate 12-8.

Die Steckkarte "IC-MEMORY" enthaelt den integrierten Speicherbaustein, den Bandrichtungs-Sensor und die Elektronik fuer den Bandzaehler mit Takterzeugung, Zaehlrichtungs- Umschalter und Zaehlersignal-Regeneration.

#### IC-MEMORY

Der IC-Speicher hat die Aufgabe, die logischen Steuersignale vom Eingangs- Abschwaecher zu speichern und im Funktionsablauf gleichzeitig das Endschaltersignal YBI-END und das Bewegungssignal YBI-MOVE zu beruecksichtigen. Die Eingangssignale sind im Ruhezustand mit eingelegtem Band alle "H", mit Ausnahme des Einganges YBI-FAD dessen Ruhe- Signal = "L" ist.

Fuer die Steuersignal-Speicherung sind 4 Flip-Flops FF1...FF4 vorgesehen. Ein weiteres Flip-Flop (FF0) ist mit Gate 12-8 als Speicher-Element geschaltet und beruecksichtigt, neben dem Bandbewegungssignal, auch den Zustand, der vor dem Uebergang einer Funktion herrschte.

#### Bandrichtungs-Detektor

Beim Bremsvorgang werden die Wickelmotoren mit Gleichstrom gebremst. Damit auch der zulaessige Bandzug nicht ueberschritten wird, wird der Bremsstrom fuer den jeweils aufwickelnden Motor geregelt. Die Steuer-Elektronik muss daher informiert werden, in welcher Richtung sich das Band bewegt (Vor- oder Rueckspulen, angesteuert durch die Bedienungstasten oder den EDIT- Regler).

Diese Richtungsinformation wird zusaetzlich auch fuer den Bandzaehler benoetigt und deshalb direkt vom Band, ueber die rechte Bandumlenkrolle bezogen. Der Bandrichtungs- Sensor liefert zwei um 90 Grad phasenverschobene Rechtecksignale (QP-DIR1 und QP-DIR2). An den Gates 8-8 und 6-6 werden zwei, um 180 Grad phasenverschobene Rechteck- Spannungen abgezweigt, die fuer die Erzeugung des Takt-Impulses zur Zaehlersteuerung verwendet werden. Eine Detektor-Schaltung erzeugt das Richtungssignal YBI-DIR, das einerseits fuer die Steuerung der Bremsstrom-Verteilung benoetigt wird und andererseits den Zaehlrichtungs-Umschalter fuer den Bandzaehler ansteuert.

#### Takt-Erzeugung fuer den Bandzaehler

Die abgezweigten, um 180 Grad phasenverschobenen Rechteckspannungen P2 und P3 werden durch die Kapazitaeten C16 und C21 differenziert.

Die positiven Flanken ergeben schmale Impulse, die bei der tiefen Bandgeschwindigkeit im Gate 2-6 zusammengesetzt werden. Bei der hohen Bandgeschwindigkeit ist einer der Ausgaenge von Gate 4-8 oder 4-11 (abhaengig von der Band-bewegungs-Richtung) dauernd "L", sodass die entsprechenden Impulse nicht wirksam werden.

Damit ist die Frequenzteilung entsprechend der Bandgeschwindigkeit gegeben, der Zaehler zeigt immer Echtzeit an. Diese Impulse werden in C18 nochmals differenziert, wobei die hintere, positive Flanke den Taktimpuls erzeugt. Im Gate 4-1 wird der Taktimpuls gesperrt, sobald YBI -END "L" wird, d.h. wenn das Bandende den Fotoendschalter passiert. Der Taktimpuls steuert die Zaehler-Signal-Rege-

neration der D-Flip-Flops FF7.

#### Zaehlrichtungs-Umschalter

Das Richtungs-Signal YBI-DIR bestimmt zusammen mit den Rueckkoppelungssignalen der Zaehler-Signal-Regeneration, die Ausgangs-Signale der NOR-Gates 5-8 und 5-6, welche auf die Set-Eingaenge der D-Flip-Flops wirken. Die Taktimpul-se (CLOCK) schalten diese Signal- Zustaende durch und bestimmen damit den Schritt-Rhythmus des Bandzaehlers.

#### 4.1.5 IC-DECODER AND DRIVER

1.080.391

Die Steckkarte IC-DECODER AND DRIVER enthaelt die Kontrollstufen fuer die Funktion der Sensor-Leuchtdioden, den Bewegungs-Simulator und den IC-Decoder mit vorgeschalteter Freigabestufe (ENABLE GATES), der die codierten Funktions-Signale entschluesselt und die Treiberstufen ansteuert.

Die Treiber-Ausgaenge mit den Signalen K-CUT und K-TT sind durch eine Diode verbunden.

Im EDIT-Betrieb. bleiben die Andruckrollen in Ausgangsstellung.

#### Kontrollstufen fuer Sensor-Leuchtdioden

Die Sensor-Leuchtdioden werden ueber die Serie Widerstaende R1 und R2 (Bandrichtungs-Sensor), bzw. R9 und R10 (Bandbewegungs-Sensor) gespiesen. Die Verstaerkerstufen (Q1, Q2, bzw. Q3) liefern die, dem Funktionszustand entsprechenden digitalen Signale an die Logik. Bei defekten Leuchtdioden sind diese fuer Ausgang Q2 = "L", bzw. fuer Q3 = "H".

Beide Signale bewirken, dass TEST-B ="L" wird, was weiter zur Folge hat, dass ueber die Blinkautomatik (Steckkarte CONTACTORS 1.080.381) die betaetigten Drucktasten blinken.

Gleichzeitig wird das Signal K-BRAKE blockiert (bleibt ="H"), d.h. der Brems-Schuetz schaltet nicht mehr auf elektronisch gesteuerte Bremsung, wenn wegen fehlender Richtungs- Information die elektronische Bremsstrom- Verteilung nicht mehr arbeitet, oder das Bewegungssignal nicht mehr ueber den Status "Bandstillstand" informiert wird.

Die Bremsung erfolgt nur noch mechanisch. Mit dieser Einschraenkung ist der Betrieb aber weiterhin in saemtlichen Funktionen moeglich, wenn Leuchtdioden des Richtungssensors (K-DI-RECTION) defekt sind. Dasselbe gilt jedoch nicht, wenn die Leuchtdiode des Bewegungs-Sensors ausfaellt. Daher ist fuer diesen Fall eine spezielle Simulation vorgesehen.

#### Bandbewegungs-Simulation

Weil bei defekten Leuchtdioden des Bandbewegungs-Sensors die Logik nicht mehr erkennen kann, wann das Band stillsteht, wird ein dauerndes Bewegungssignal simuliert (Gate-Eingang 9-1 ist "L", Ausgang 9-3 wird "H"). Somit ist YBI-MOVE konstant "H", was zur Folge hat, dass YBI-FFO fuer die Steuerbefehle "Wiedergabe" und "Aufnahme" nicht mehr "H" werden kann (FF2 und FF3 = "H") und somit die Durchschaltung dieser Befehle blockiert ist.

Damit sind die Funktionen, die ueber STOP ablaufen, blockiert. Tritt der Ausfall einer Leuchtdiode waehrend einer bestehenden Funktion ein, bewirkt das simulierte Bewegungssignal, dass diese Funktion aufrecht erhalten bleibt, bis die Taste STOP gedrueckt wird oder das Bandende erreicht ist.

Die Funktionen fuer schnelles Umspulen koennen weiterhin aktiviert werden•

#### IC-DECODER AND DRIVER

Der IC-Decoder entschluesselt die Funktions-Signale FF1...FF4 und stellt die logischen Verknuepfungen fuer das Zusammenwirken der elektromechanischen Elemente wie Wickelmotoren, Elektromagnete, Schuetze und der Anzeigelaempchen her.

Der eigentlichen Decodierung ist eine Freigabestufe vorgelagert, welche die Aufgabe hat, bei YaI-FFO = "L" (Funktions-Uebergaenge die Bandstillstand erfordern) die Weiterschaltung der gespeicherten Befehle zu blockieren, bis YBI-MOVE ="L" wird.

#### 4.1.6 Logische Ausgangssignale

Jede Kombination von Steuerbefehlen und Sensor-Signalen hat, zusammen mit dem vorausgegangenen Zustand eine bestimmte Signal- Kombination an den Ausgaengen des IC-Decoders zur Folge.

Die Kombination der Ausgangssignale loest die entsprechenden Arbeitsfunktionen der elektromechanischen Elemente aus.

Eingangs- und Ausgangssignale sind demzufolge logisch verknuepft. Diese Tatsache erleichtert die Pruefung und Fehlersuche betraechtlich, denn es ist nicht erforderlich die logischen Schaltungen zu verstehen. Es genuegt zu wissen, dass ein bestimmter Befehl eine bestimmte Reaktion in Form eines Ablaufs logischer Signale

Dieser Zusammenhang laesst sich in Tabellenform festhalten. Eine solche Tabelle enthaelt die Ausgangssignale der Steckkarten:

- ATTENUATOR 1.080.396
- IC-MEMORY AND COUNTER 1.080.393
- IC-DECODER AND DRIVERS 1.080.391

mit den entsprechenden Bezeichnungen der Anschlusspunkte (TP) sowie der Signal- Namen (linke Spalte). Weiter sind auch die Signal-Namen der Sensoren aufgefuehrt, deren Zuordnung alle drei Steckkarten betrifft.

In den senkrechten Kolonnen sind die logischen Zustaende der Signale aufgefuehrt; zur leich-teren Unterscheidung sind die aktivierten Laempchen und Magnete mit "\*" bezeichnet. Logische Zustaende sind nur aufgefuehrt, wenn sie fuer die entsprechende Funktion von Bedeutung sind.

Die Logik- Ansteuerung erfolgt normalerweise mit logisch "L" (Ausnahme Reglerstart, YBI-FAD logisch "H"). Fuer Bandbewegung vorwaerts ist das entsprechende Signal YBI-DIR = "H". Fuer bewegtes Band ist das entsprechende Sig-nal Q-MOVE oder YBI-MOVE = "H". Logisch "L" am Ausgang der Treiberstufen des IC-DECODERs bedeutet Aktivierung des angeschlossenen Elementes.

Die Testpunkte TP3, TP6 und TP11 liegen di-rekt an den Basen der Treiberstufen, sodass sie ein inverses Signal gegenueber dem entsprechen-den Ausgang anzeigen. Diese TP- Nummern sind deshalb in der Tabelle mit dem Negationszeichen (Querbalken ueber der Ziffer) gekenntzeichnet.

(Beispiel: ist K-CUT am Anschluss 8B des IC-DECODERs = "L", ist der entsprechende TP ="H")

Die waagrechten Zeilen enthalten die notwendigen logischen Zustaende einer Funktion. Diese stellen von Zeile zu Zeile einen Funktionsablauf dar.

#### LOGICAL OUTPUT SIGNALS



Diese Tabelle enthaelt einen gewoehnlichen Funktionsablauf, der mit dem Einschalten beginnt (Zeile 1) und mit dem Auflegen des Bandes fortsetzt (Zeile 2).

Die Zeile 3 zeigt den Zustand der Signale im Moment, bevor die Taste FORWARD (schnelles Vorspulen) gedrueckt wird.

Die naechste Zeile (PRESS FORWARD, Zeitzustand 1) zeigt die Signale bei gedrueckter Taste. Diese Taste bleibt nun gedrueckt (bis RELEASE FORWARD).

Die naechste Zeile zeigt die Signal- Zustaende sobald sich das Band bewegt (MOVE SENSOR "ON" YBI-MOVE = "H").

Die Zeile RELEASE FORWARD (Taste loslassen) zeigt, dass der Zustand der Signale nicht aendert, ausser Aktivierungssignal YPS-FORW, da der Steuerbefehl gespeichert ist und sich das Band in Bewegung befindet.

In diese feinen Schritte aufgeloest, gibt die Tabelle weitgehenden Aufschluss ueber die Ablaeufe beim Betaetigen einer Taste, beim Start (MOVE SENSOR "ON"), beim Anhalten des Bandes (MOVE SENSOR "OFF") oder beim Richtungswechsel des Bandes.

			A	ГТ	ΞNI	JA	то	R	***********				OR AL			M	EM	OR	Y						IC-	DE	EC	ODE	ΞR					-
	ТР		Τ		Ī	Γ	T	Τ							7	2	6	5	4		4	5	10	3	14	Q	6	7	11	13		12	8	
	РТ	A 17	B 16	B 14	B 12	B 8	B 19		B 20						B 7	A 5	B 8	B 9	B 10	A 21	B 12	B 13	A	A 8	B 22	A	В	A	B 20	B 18	A 20	A 22	B 14	B 3
SIG	NAL.	Υ	Υ	Y	Y	Υ	Υ	s	Υ	Υ	Υ	Q	В	В	Υ	Υ	Υ	Υ	Υ	В	В	В	В	В	Υ	В	K	$^{+-}$	К	K	К	ĸ	Υ	Υ
NAM		P S	P S	P S	P S	S	P S	c	B	B	B	М.	M	D	B	B	B	B	B	- R	- s	F	- R	R	B	c	c	- P	ī	B	- D	Ť	c	B
		S	R	F	R	R	C	TA	F	E	D	0 V E	0 V E	R	F	F	F	F	F	C	T 0 P	O R W	W	E P R	R	T	T	R E S	F	R A K	R	T	U T A	- М О
ODEDATION		O P	W	R	PR	č	Ť	Ü	Ď	D	R	-	-		Ö	1	2	3	14		ľ			"	c			s	ľ	Ē			Û	V E
OPERATION															<del> </del> -																			
SYMB.F.SIGNAL O		0		0	0	0	0	0	L_	0	0 L	L	*	*	0 L	0 L	0 L	0 L	0 L	*	*	*	*	*	L	*	*	*	*	*	*	*	0	L
INITIALISATION	0 1									0	L		*	*	L	0	0	0	0		ŧ													
LOAD TAPE	0										L		*	n	L	0	0	0	0		ŵ													
PRESS FORWARD	0 1			0							L		*	*	L	0 L	0 L	0	0		*	*							*					
MOVE SENSOR ON	0 1			0							L	L	* *	ú n	L	L	L	0	0			*							*					L
RELEASE FORWARD	0										L	L	*	Ŕ	L	L	L	0	0			*							*					L
PRESS REWIND	0		0								L	L	*	#	L	L	L 0	0 0	0			*	*						*					L
RELEASE REWIND	0										L	L	*	*	L	L	0	0	0				*						*					L
CHANGE DIRECTIO	N 0										0	L	*	*	L	L	0	0	0				*						*		*			L L
PRESS PLAY	0				0						0	L	*	*	L 0	L	0	0	0		*		*	*					*	*	rk rk			L
PRESS RECORD	0				0	0					0		*	*	0	L	L		0	*	*			*						*	*			L
RELEASE PLAY	0					0					0	L	*	*	0	L	L	L	L	*	*			*						*	ŵ			L
RELEASE RECORD	0										0	L	*	n	0	L	L	L	L	*	*			*						ŵ	*			L
MOVE SENSOR OFF	0										0		*	tr tr	0 L	L	L	L	L L	*	*			*	L		#	ŵ	*	*	*			L
MOVE SENSOR ON	0 1										0	L	*	n n	L	L	L	L	L	*				*	L		*	*	*		*			L
CHANGE DIRECTIO	N 0										L	L	*	*	L L	L	L	L L	L L	*				*	L		*	*	*		*			L
PRESS STOP	0	0									L	L	*	rk rk	L	L 0	L 0	L 0	L 0	*	*			*	L		*	*	*	*				L
RELEASE STOP	0										L	L	*	*	L	0	0	0	0		ŵ									*				L
MOVE SENSOR OFF	0										L		*	*	L	0	0	0	0		*									*				L
PRESS EDIT	0 1						0				L		*	*	L	0	0	0 L	0		ŵ					*	*					ŵ		
RELEASE EDIT	0										L		*	*	L	0	0	L	0							*	*					*		
PRESS CUTAUT	0 6							0			L		*	*	L	0	0	L L	0							*	*					*	0	
MOVE SENSOR ON	0 1							0			L L	L	*	*	L	0	0	L	0							*	*					*	0	L
RELEASE CUTAUT	0										L	L	*	*	L	0	0	L	0							*	*					*	0	L
MOVE SENSOR OFF	0										L		*	*	L	0	0	L	0							*	*					#		L
PRESS REWIND	0 1		0								L L		*	* *	L	0 L	0	L 0	0				*			*	*		*			*		
RELEASE REWIND	0										L		*	ŧ	L	L	0	0	0				*						*					
MOVE SENSOR ON	0 1										L L	L	*	n n	L	L	0	0	0				rk rk						*					
CHANGE DIRECTIO											0	L	*	*	L	L	0	0	0				*						*					L

END OF TAPE

MOVE SENSOR OFF

0 1

#### LOGICAL OUTPUT SIGNALS

2

Diese Tabelle zeigt, dass bei Regler-Start (Fader-Start) die anderen Funktionen gesperrt sind (z.B. REWIND).

### LOGICAL OUTPUT SIGNALS (FADER OPERATION)

		ATTENUATOR SENSOR SIGNALS									M	EM	OF	RY IC-DECODER																				
2	TP														7	2	6	5	4		4	5	10	3	14	9	6	7	11	13		12	8	
	PT	A 17	B 16	B 14	B 12	B 8	B 19		B 20						B 7	A 5	B 8	B 9	B 10	A 21	B 12	B 13	A 12	A 8	B 22	A 18			B 20	B 18	A 20	A 22	B 44	B 3
SIGN NAM OPERATION	1ES	Y P S T O P	Y P S R E W	Y P S F O R W	Y P S R E P R	Y P S R E C	Y P S C U	S - C U T A U T	Y B I F A D	Y B I E N D	Y B I D I R	Q - MOVE	B M O V E	B D I R	Y B I - F O	Y B I F F 1	Y B I - F F 2	Y B I F F 3	Y 8 ! - F 4	B R E C	B S T O P	B F O R W	B R R E W	B R E P R	Y B I R E C	B C U T	C	R E S S	K L I F T	K - B R A K E	K D I R	K T T	Y - C U T A U T	Y B - M O V E
SYMB.F.SIGNAL 0 SYMB.F.SIGNAL 1		0	0	0	0	0	0	0	 L	0	0 L	L	*	*	0 L	0 L	0 L	0 L	0 L	*	*	*	*	*	 L		*	*	*	*	*	ŵ	0	
INITIALISATION	0 1									0	L		*	*		0	0	0	0		*						1							
LOAD TAPE	0										L				L	0	0	0	0		*				-	t	T	t			-			$\dashv$
PRESS FORWARD	0			0							L		*	*	L	0 L	0	0	0		*	*							*					1
RELEASE FORWARD	0										L		*	*	L	L	L	0	0															Distribution
MOVE SENSOR ON	0 1										L	L	*	*	L	L L	L	0	0			*							*					
PRESS STOP	0 1	0									L	L L	*	*	L L	L 0	L 0	0	0		*	*							*				1	L
RELEASE STOP	0										L	L	ŵ	ŵ	L	0	0	0	0		*									ŵ				L
MOVE SENSOR OFF	0 1										L		*	*	L L	0	0	0	0		*									*				L
SWITCH FADER ON	0								LL		L		*	*	L	0	0 L	0	0		*			*				*	*				1	٦
MOVE SENSOR ON	0 1								L L		L	L	*	*		L	LL	L	0					*			*	*	*					L
PRESS REWIND	0		0						L		L	L	*	n	٦	L	L	L	0					*			ŵ	ŵ	ŵ					L
RELEASE REWIND	0								L		L	L	*	*	L	L	L	L	0					*			*	*	*					L
SWITCH FADER OF	F 0										L L	L L	*	*	L L	L O	L O	L O	0					*			*	*	ŵ	*			- 1	L
MOVE SENSOR OFF	0										L		*	*	L	0	0	0	0		*									#				L
PRESS FORWARD	0 1			0							L		*	*	L L	0 L	0 L	0	0	$\exists$	*	*							*				1	1
RELEASE FORWARD	0										L		*	ŵ	L	L	L	0	0			*							*					1
MOVE SENSOR ON	0										L	L	*	*	L	L	L	0	0			*							*					
END OF TAPE	0									0	L	L	rh rh	ŵ ŵ	L	L 0	L 0	0	0			*							*				$\dashv$	L
MOVE SENSOR OFF	0									0	L		*	*	L	0	0	0	0		*									*				L
PRESS PLAY	0				0					0	L		*	*	L	0 L	0 L	0 L	0		*							*					1	1
RELEASE PLAY 0										0	L L		*	*	L	L 0	L 0	L 0	0		*			*			*	*	*					

## ELEKTRISCHE EINSTELLUNGEN

LAUFWERK

#### 4.2.1 Allgemeines

#### Benoetigte Messgeraete und Hilfsmittel

- Universal- Messinstrument
- Tentelometer 10.300.001.01 (Bandzug-Messgeraet) mit Spezialhalterung QC 1.080.431.00 - Oszilloskop (mit Vorteil 2-Kanal)
- Quarz-Oszillator, 400 Hz
- oder Frequenzzaehler (quarzstabilisiert) - Verlaengerungsprint 21.080.941.00

#### Hinweise

- Ausgangslage elektrischer Einstellungen an der Laufwerksteuerung ist die korrekte Einstellung der mechanischen Funktionselemente. -> Kap.2.2
- Bevor Steckkarten aus dem Rack gezogen, resp. in das Rack eingeschoben werden, muss das Geraet mindestens 5 Sekunden ausgeschaltet sein.
- Vor elektrischen Einstellungen an der Laufwerksteuerung sind die Speisespannungen, wie nachfolgend beschrieben, zu kontrollieren. -> Kap.4.2.2

#### 4.2.2 Stabilisator (Voltage Regulator)

-> Fig.4.1 Die Speisespannungen werden an den Testpunkten TP1...TP5 der Stabilisator-Steckkarte gemessen und an den Trimmpotentiometern R1 (+20,0V) und R29 (+/-5,8V) eingestellt.

Am Potentiometer R2 wird die Strom- Begrenzung der +20V/+24V Speisung eingestellt.

-> Fig.4.2 Zur Messung ist ein Ampere-Meter (Bereich >4A) in Reihe mit einem Widerstand von 4...5 Ohm (50...75 Watt) an die Sammelschiene +0.0V und +24,0V, auf der Rueckseite des Steckkarten-Chassis anzuschliessen.

- Maschine einschalten, Laufwerkstatus STOP.
- Potentiometer R2 (I-MAX) so einstellen, dass das Amperemeter folgenden Wert anzeigt: mit Logik-Karten 3,5A ohne Logik-Karten 4A

#### WICHTIG Diese Messung darf nicht an den Steckkarten- Testpunkten vorgenommen werden.

Hinweis: Die Stabilisierung der +20V und +24V Speisespannungen enthaelt Automatikkreise fuer die begrenzung und die Abschaltung bei Kurzschluss. Bei Kurzschluss schaltet die Stabilisierung die Speisespannung +20V/+24V vollstaendig ab• Sie bleiben auch dann abgeschaltet, nachdem der Kurzschluss aufgehoben wurde. Die Stabilisierung arbeitet erst wieder normal

wenn das Geraet waehrend mindestens 15 Sekunden ausgeschaltet wurde.
Die Charakteristik dieser Schutzschaltung erlaubt es nicht, das Geraet ueber einen Netz-Regeltransformator langsam von 0 V unter Spannung zu setzen (Die Einschaltspannung muss mindestens die halbe Netzspannung betragen).




Fig. 4.1




Fig. 4.2

#### 4.2.3 Bandzug-Einstellungen

-> Fig.4.3

Die Bandzuege der Wickelmotoren werden mit den Einstellreglern R70...R75 auf der Steckkarte SPOOLING MOTOR CONTROL 1.080.387 abgeglichen.

Die oberen drei Trimmpotentiometer beeinflussen den linken Wickelmotor (SUPPLY MOTOR), die unteren drei Trimmpotentiometer den rechten Wickelmotor (TAKE-UP MOTOR).

#### Vorbereitungen

- Kopftraeger demontieren -> Kap.3.1.1 - Vorderes Abdeckblech entfernen -> Kap.3.1.3 - Bändende-Sensor demontieren -> Kap.3.1.4 (behindert Band- Fuehrung bei demontiertem Kopftraeger).
- Tentelometer montieren -> Fig.4.4 Spezialhalterung anstelle des Kopftraegers einsetzen.
- Wichtig: Halterung genau in Bandlaufrichtung ausrichten•
  - Tentelometer mit seinen Abtastrollen genau senkrecht ausrichten.
- Band auflegen
  - Wichtig: Beide Wickelteller muessen mit Spulen gleichen Typs bestueckt sein (Abmessungen, Material) Kerndurchmesser: 150mm
- Band ordnungsgemaess ueber Bandzugwaagen und Umlenkrollen einfuehren•

Wichtig: Alle Bandzugdaten beziehen sich auf das "Pancake"-Format.




Fig. 4.3



Fig. 4.4

#### 1.Bandzug im PLAY-Modus

Vorbereitung Gilt nur fuer Maschinen mit Aufnahme-Betriebsmodus (A80/QC-REC) und unterdruecktem RUECKWAERTS-PLAY-Modus.

Fuer die nachfolgende Einstellung muss, voruebergehend, der umschaltbare Betriebs- Modus mit waehlbarer PLAY- Bandlaufrichtung (PLAY >, PLAY <) erstellt werden.

-> Fig.4.5

Dies erfolgt durch Setzen des Brueckensteckers JS2 auf der Steckkarte DUAL CAPSTAN DIRECTION BOARD 1.080.369

DUAL CAPSTAN DIRECTION BOARD 1.080.369 in Position "B".

Nach Beendigung der Einstellung ist der Bruekkenstecker wieder in seine Ausgangsposition "A" zurueckzusetzen.

# Einstellung im PLAY-Modus "VORWAERTS" PLAY-> Fig.4.3

Voraussetzung:

Beide Bandspulen muessen gleiche Wickeldurchmesser aufweisen.

- Linke Andruckrolle durch Abschrauben der Kappe (Achtung: Linksgewinde) demontieren.
   Maschine im PLAY-Modus "PLAY->" starten.
- Maschine im PLAY-Modus "PLAY->" starten. (Rechte Bandlaufrichtungs-Vorwahltaste leuchtet).

Beachte horizontale Bandfuehrung ueber die Andruckrollen:

Das Band muss genau zentriert ueber die definierte Laufflaeche am Andruckrollen- Umfang gefuehrt werden•

Eine Korrektur erfolgt durch entsprechendes, seitliches Neigen des Tentelometers in seiner senkrechten Befestigungslage.

- Trimmpotentiometer R70 (PLAY/SUPPLY MOTOR): Bandzug auf eine Anzeige am Tentelometer von 30g einstellen.
- linke Andruckrolle wieder montieren.

# Einstellung im PLAY-Modus "RUECKWAERTS" PLAY<--> Fig.4.3

Voraussetzung:

Beide Bandspulen muessen gleiche Wickeldurchmesser aufweisen.

- Rechte Andruckrolle demontieren.
- Maschine im PLAY-Modus "PLAY<-" starten. (Linke Bandlaufrichtungs-Vorwahltaste leuchtet).

Beachte exakte, horizontale Bandfuehrung ueber
 die Andruckrollen (siehe oben).
- Trimmpotentiometer R75 (PLAY/TAKE-UP MOTOR):

- Trimmpotentiometer R75 (PLAY/TAKE-UP MOTOR): Bandzug auf eine Anzeige am Tentelometer von 30g einstellen.
- Rechte Andruckrolle wieder montieren.

#### Kontrolle:

- Bandvorrat auf beide Spulen gleichmaessig verteilen.
- Kontrolle im PLAY> und PLAY<:
   <p>Das Band darf, waehrend die Andruckrollen manuell von den Capstan- Wellen abgehoben werden, keine Bewegung aufzeigen.

Bei Maschinen mit Aufnahme-Betriebsmodus:
Brueckenstecker JS2 auf Position "A" zuruecksetzen (Betriebs- Modus PLAY< unterdrueckt). -> Fig.4.5




Fig.4.5

(FORW) 2.Bandzug-Begrenzung beim Vorspulen und Rueckspulen (REW)

-> Fig.4.3

An den Einstellreglern R71 und R74 ist die maximal zulaessige Belastung des Bandes beim Schnellen Umspulen einstellbar; diese ergibt sich beim Start zum Schnellen Umspulen (waehrend der Beschleunigungsphase) oder bei Richtungsaenderung waehrend des schnellen Umspulens.

Bei der Bestimmung des maximalen Bandzuges ist zu beachten: Eine starke Beschleunigung erfordert einen hohen Spitzen-Bandzugwert.

Aus niedrig gewaehlter Beschleunigung tiert zwar eine laengere Reaktionszeit wach-rend der Umspulfunktion, gewaehrleistet aber maximale Schonung des Tontraegers, was insbesondere bei der Verarbeitung von Master- Baendern von groesserer Wichtigkeit ist.

#### Vorbereitung:

Linke Bandzugwaage

-> Fig. 4.6

im Uhrzeigersinn auf Anschlag drehen (Richtung maximaler Federvorspann).

- Diese Position, durch Setzen einer Markierung (mit weichem Bleistift) an der Peripherie des drehbaren Bandzug- Waagetellers {A} zum fixen Bandzugwaagen- Rand {B} zeichnen•

- Mit einer Distanz von 18mm, von der fixen Marke {B} in Gegenuhrzeigersinn (geringerer Federvorspann) neue Marke {B'} setzen.

Rechte Bandzugwaage -> Fig.4.7

im Gegenuhrzeigersinn auf Anschlag drehen

Markierung {A}-{B} setzen (siehe oben).Mit einer Distanz von 18mm, von der fixen Marke {B} in Uhrzeigersinn, neue Marke {B\*} setzen.

#### Einstellung:

-> Fig.4.3/4.6/4.7

Bedingung: Korrekte Einstellung der PLAY-Bandzuege, nach Abschnitt 1.

Bandvorrat auf beide Spulen gleichmaessig verteilen (gleiche Wickeldurchmesser).

Rechte Bandzugwaage in Position {B'} vor Endanschlag) festhalten oder mit Klebeband fixieren.

- Betriebsart FORW waehlen und Einstellung an Potentiometer R74 ermitteln, bei der Band stillsteht.

Bandzugwaage in Ruhestellung freigeben (Fixierung entfernen).

Bandvorrat auf beide Spulen gleichmaessig verteilen.

Linke Bandzugwaage in Position {B'} (18mm mit Klebevor Endanschlag) festhalten oder band fixieren.

waehlen und Einstellung an Betriebsart REW R71 ermitteln, bei der das Potentiometer Band stillsteht. Bandzugwaage in Ruhestellung freigeben (Fixierung entfernen).

#### Kontrolle mit Tentelometer:

- In der Beschleunigungsphase der Wickelmotoren darf der maximale Bandzug 120g nicht ueberschreiten.

Korrektur durch entsprechendes, proportionales Reduzieren des Bandzuges an R71 und R74 (entspricht einer Vergroesserung der Markendistanz {B}-{B\*}).




Fig. 4.3




Fig. 4.6




Fig. 4.7

#### 3.Bandzug-Begrenzung im Betriebsmodus EDIT

-> Fig.4.3/4.8

Voraussetzung: Korrekte Einstellung der Bandzuege fuer die Betriebsmodis PLAY/FORW/REW.

- Bandvorrat auf beide Spulen gleichmaessig
- verteilen (gleiche Wickeldurchmesser).
   R72 (CUT) fuer EDIT-"Rueckwaerts": Auf 1/5...1/4 des Einstellbereiches aufdrehen (Uhrzeigersinn CW). -> Fig.4.8
- EDIT-Taste druecken.
- Mikro-Switch zu EDIT- Drehknopf kurzschliessen (Anschluss mit schwarzer Litze mit unbelegtem Anschluss verbinden) - EDIT- Magnet faellt ab.
- EDIT- Drehknopf in Mittelstellung positionieren.
- R73 (CUT) fuer EDIT-"Vorwaerts": Einstellung ermitteln, in der das Band (bei gleichen Wickeldurchmessern) stillsteht.
- Kurzschluss an Mikro-Switch aufheben.

#### Kontrolle mit Tentelometer:

- Beim wechselseitigen Umspulen im EDIT-Modus, darf der Bandzug weder waehrend der Beschleunigungsphase, noch bei maximaler Umspulgeschwindigkeit, 120g uebersteigen.

Korrektur durch Reduktion des Bandzuges an R72 (Drehen in Gegenuhrzeigersinn CCW), mit anschliessendem Abgleich von R73, wie oben beschrieben.

Kontrolle mit Tentelometer wiederholen.

#### 4.PLAY-Bandzug zwischen den Capstans

siehe Kapitel 4.2.5

Abgleich der Capstan-Motoren




Fig.4.8

#### 4.2.4 Brems-Regelung

Die folgende Einstellung der Bremsregelung basiert auf dem Bandzug fuer Wiedergabe (PLAY).

Es ist daher wichtig, dass vor der Einstellung der Bremselektronik die Bandzuege fuer Wiedergabe (Kapitel 4.2.3) richtig eingestellt sind.

Die Bremsregelung tritt in Aktion, wenn aus Betriebsmodus REW, FORW oder PLAY die Taste STOP betaetigt wird (K-BRAKE). Dabei wird die rechte Bandzugwaage (T-TT2) als Regelglied (Sensor) verwendet.

In Abhaengigkeit der Bandbewegungs- Richtung wird der Wickelmotor der jeweiligen Aufwickelseite in den Stromkreis der Brems- Elektronik geschaltet•

-> Fig. 4.9

Der bei der Bremsung auftretende Bandzug laesst sich an R9 begrenzen (Der Begrenzungspunkt ist abhaengig vom Drehwinkel der rechten Bandzugwaage und der, an R9 eingestellten Referenzspannung).

Mit Hilfe eines Universalinstrumentes laesst sich die Bremsspannung nach Fig•4•10 einstellen•

#### Einstellung

Volle Bandspule auflegen und ca. 10...20m Band vorspulen. Taste PLAY druecken und die sich dabei ergebende Stellung der rechten Bandzugwaage markieren. Band abnehmen. Messinstrument an den Testpunkten TP2 (yel) und TP3 (+,wht) anschliessen (Messbereich >20V).

Zur Simulierung des Bandlaufes ist der Bandbewegungssensor mit einem Gummiband, welches ueber die Capstan-Welle und die rechte Umlenkrolle gespannt wird, anzutreiben.

Kurzzeitig Taste REW oder FORW druecken, STOP- Taste betaetigen.

#### Achtung:

Geraet nicht laenger als 2 Minuten in Bremsstellung halten. Zum Aufheben der Bremsstellung, rechte Umlenkrolle (Bandbewegungssensor) stoppen.

Rechte Bandzugwaage in die zuvor markierte Stellung drehen und fixieren. Einstellregler R9 auf eine Anzeige am Messinstrument von 4V einstellen.

Durch Bewegen der rechten Bandzugwaage kontrollieren, ob das Regelsignal der in Fig. 4.10 dargestellten Kurve entspricht.

Bei ansprechendem Foto- Endschalter (Lichtschranke nicht abgedeckt) und Ruhestellung der Bandzugwaage tritt volle Bremsung fuer beide Motoren ein, bis die rechte Bandumlenkrolle stillsteht (YBI-MOVE = "L").




Fig. 4.9




Fig.4.10

#### 4.2.5 Abgleich der Capstan-Motorsteuerung

-> Fig.4.11 Capstan- Tachoabqleich und Bandzug zwischen den Capstan- Wellen, stehen in unmittelbarem Zusammenhang:

Die Drenzahlregelung der beiden Capstan- Motoren erfolgt ueber je eine separate Servo-Elektronik (Steckkarten CAPSTAN SERVO 1.080.371)

Die als MASPER definierte Steuereinheit regelt den, ihr zugeordneten Capstan-Motor exakt entsprechend der Band-Nenngeschwindigkeit.

Die als SLAVE definierte Steuereinheit regelt ihren zugeordneten Capstan-Motor auf eine Drehzahl, entsprechend einer leicht ueberhoehten Band-Nenngeschwindigkeit.

Diese einstellbare Drehzahl- Differenz bewirkt einen minimalen, kontrollierten Bandschlupf am SLAVE-gesteuerten Capstan und ermoeglicht die praeziese Bestimmung des Bandzuges zwischen den Capstan-Wellen.

Die Capstanmotor-Zuordnung der Steuereinheiten MASTER und SLAVE ist von der Vorwahl der PLAY-Bandlaufrichtung abhaengig (PLAY> / PLAY<)•

#### Wichtige Hinweise

Grundlegende Voraussetzung fuer den wirkungsvollen Abgleich der Capstan- Motorsteuerung sind:

- die gewissenhaft durchgefuehrten mechanischen Einstellungen des Laufwerkes nach Kap. 3.2.
- die korrekte Einstellung der vorgaengig beschriebenen Bandzuege und Bandzugbegrenzung der Wickelmotoren (Kapitel 4.2.3)
- Alle Abgleich-Vorgaenge muessen in betriebswarmem Zustand der Bandmaschine erfolgen.
- Waehrend Einstellarbeiten muss das Laufwerk in horizontaler Betriebslage positioniert sein.
- Bandlaufflaechen an Capstan- Wellen und Andruckrollen muessen sauber und fettfrei sein.

#### Benoetigte Messgeraete und Hilfsmittel

-> Fig.4.12

- Verlaengerungsprint

21.080.941.00

Messaufbau {A}

- Oszilloskóp (mit Vorteil 2-Kanal)
- Quarz-Oszillator 400Hz

Messaufbau {B}

- Steht kein 400Hz- Oszillator zur Verfuegung, kann die Einstellung des Capstan- Abgleichs, in eingeschraenktem Masse, mit einem
- Frequenzzaehler (ev. quarzstabilisiert) durchgefuehrt werden.

Fuer Wobbelmessungen wird ein Oszilloskop benoetigt.

Ein Hoehenschwankungs- Messgeraet stellt nur fuer Aufnahme- Maschinen eine Alternative.




Fig.4.11




Fig.4.12

#### Einstellorgane

-> Fig.4.12 - Steckkarte CAPSTAN SERVO "MASTER" 1.080.371: CAPSTAN SERVO "SLAVE" 1.080.371: Ll Diskriminatorspule (Tachoabgleich grob) R46 Trimmpotentiometer (Tachoabgleich fein) TP1 Testpunkt Masse (+0.)V)
Messaufbau A: TP2 Testpunkt Signal (Y-TAC)
Messaufbau B: R42 Signal (Kollektor von Q4) -> Fig.4.13

Steckkarte DUAL CAPSTAN DIR. BOARD 1.080.369 Regler fuer Wobbel- Abgleich:

R1 SLAVE- Capstan R2 MASTER-Capstan

Regler fuer Capstan- Hochlaufkontrolle:

R7 SLAVE- Capstan, Signalisation durch DL1 R8 MASTER-Capstan, Signalisation durch DL2

#### 1. Voreinstellungen

Folgende Einstellungen bezwecken die Schaffung einer Ausgangslage, welche einen sukzessiven Einstellablauf erlauben (z.B. nach dem Ersetzen einer Steuerkarte).

Feinabgleiche, welche bei regulaeren Wartungszyklen vorgenommen werden, koennen direkt am entsprechenden Einstellorgan erfolgen.

-> Fig.4.12 Steckkarte CAPSTAN SERVO (MASTER und SLAVE):

- R46 auf Mitte Einstellbereich stellen.

- L1 Spulenkern ca.lmm tief in den Spulenkoerper eindrehen (entspricht einer Tachofrequenz von ca.400Hz).

Steckkarte DUAL CAPSTAN DIRECTION BOARD:

- Rl, R2, R7 und R8 auf Mitte Einstellbereich stellen.

Nur bei Aufnahme-Maschinen (A80/QC-REC):

-> siehe Kapitel 4.2.3, Fig.4.5 - Brueckenstecker {JS2} auf Position {B} setzen (= bidirectionaler PLAY-Bandlauf).

#### 2.Capstan-Hochlaufkontrolle

-> Fig.4.13

Waehrend der Hochlaufphase der Capstan-Motoren beim Einschalten der Maschine oder beim Bandlauf- Richtungswechsel• wird der Betriebsmodus PLAY (und (REC) verriegelt, bis die Capstanmotoren ihre Soll- Drehzahl erreicht haben. Die Leuchtdioden DL1 und DL2 signalisieren, durch Aufleuchten, die Hochlaufphase. Sobald ein Capstanmotor seine Tachofrequenz von 400Hz innerhalb einer bestimmten Toleranz erreicht. erlischt die zugeordnete Leuchtdiode DL1/DL2. Diese Zuordnung ist von der vorgewaehlten PLAY-3andlaufrichtung abhaengig:

PLAY > DL1 fuer rechten Capstan (Slave)
DL2 fuer linken Capstan (Master)

DL1 fuer rechten Capstan (Slave) DL2 fuer linken Capstan (Master) PLAY <

Voreinstellung (DUAL CAPSTAN DIRECTION BOARD) -> Fig.4.13/4.14

## Betriebszustand STOP.

Trimmpotentiometer R7 und R8 auf den linken Anschlag CCW drehen - DL1 und DL2 leuchten.

- Unter langsamem Aufdrehen von R7 und R8, Positionen ermitteln und markieren, in denen die zugeordnete Leuchtdiode erlischt {A} und beim Weiterdrehen wieder aufleuchtet {C}• - Potentiometer auf Mitte der beiden Markie-

rungen stellen {B}.




Fig.4.12




Fig. 4.13 Fig. 4.14

#### 3.Tachoabgleich MASTER- Capstan

-> Fig.4.12

- Steckkarte MASTER CAPSTAN SERVO mit Verlaengerungsprint versehen in Rack einschieben.
- Messaufbau (A) oder (B) erstellen.
- Maschine einschalten (PLAY>).

### Abgleich der MASTER-Tachofrequenz

Ğrobabgleich an Spulenkern L1 Feinabgleich an Potentiometer R46

#### - Messaufbau {A}:

Sinuskurve auf Bildschirm (Tacho Signal) mit Quarzfrequenz (400Hz, extern getriggert) synchronisieren: L1 so einstellen, dass die Sinusdarstellung auf dem Bildschirm stillsteht (kein horizontales Abwandern). Feinabgleich an R46.

#### - Messaufbau {B}:

Abgleich von L1 (Grobeinstellung) und R46 (Feineinstellung) auf eine Anzeige am Frequenzzaehler von 400Hz, +/-0,1Hz.

#### Korrektur von Gleichlauf-Schwankungen

-> Fig.4.13

Steckkarte DUAL CAPSTAN DIRECTION BOARD:

- Oszilloskop an TP1 (OV) und TP2 des MASTER CAPSTAN PCB anschliessen.
- RI (auf DUAL CAPSTAN DIRECTION BOARD): Abgleichen, bis die horizontale Zitterbewegung (Jitter) auf ein Minimum beschraenkt ist.

#### 4. Tachoabgleich SLAVE-Capstan

Sinngemaess gleiche Einstellung wie beim MAS-TER-Capstan, beim SLAVE CAPSTAN SERVO-Einschub durchfuehren.

Die Korrektur von Gleichlaufschwankungen erfolgt an R2 der Steckkarte DUAL CAPSTAN DIREC-TION BOARD.

Messaufbau fuer die nachfolgende Einstellung belassen.

#### 5.Bandzug zwischen den Capstans

-> Fig.4.12

- Band einlegen und durch Vorspulen auf beide Spulen gleichmaessig verteilen (gleiche Wikkeldurchmesser).
- Band ueber Tentelometer fuehren

-> Kap. 4.2.3, Abschnitt "Vorbereitungen" Maschine starten "PLAY>": - Steckkarte CAPSTAN SERVO "SLAVE":

Einstellung des Bandzuges an R46, je nach verwendeter Bandsorte (18 $\mu$ \*): Fe 80g +/-5g Cr 60g +/-5g

\* (fuer duennere Baender entspr. reduzieren)

Nur bei Maschinentyp ohne Aufnahmemodus:

- Maschine starten "PLAY<".

- Bandzug messen•

Korrektur

...durch geziehlte Veraenderung der mechanischen Andruckkraft der Andruckrollen, im Be--> Kap.3.2.2 reich von 600g +/-50g Andruck linke Andruckrolle erhoehen = hoeherer Bandzug.

- Betriebsmodus "PLAY>":

Andruck der rechten Andruckrolle vermindern = kleinerer Bandzug.

#### 6.Schlusskontrolle

Nach einer Betriebdauer von 1 Stunde im PLAY-Betriebsmodus: Einstellungen, Kapitel 4-2-5, Punkte 2---5

Einstellungen, Kapitel 4-2-5, Punkte 2---5 nochmals ueberpruefen und bei Bedarf korrigie-ren.

Nur bei Aufnahme-Maschinen A80/QC-REC: Brueckenstecker JS2 (DUAL CAPSTAN DIRECTION BOARD 1.080.369) auf Position {A} zuruecksetzen ("PLAY<" = unterdrueckt). -> Fig.4.5

4/44

#### ELECTRIC TAPE TRANSPORT ALIGNMENTS page OPERATING 4.1 OF TAPE TRANSPORT CONTROL 4/24 4.1.1 Arrangement of control electronics 4/24 4.1.2 Push buttons 4/25 4.1.3 Attenuator and Preamplifier 4/26 IC MEMORY AND COUNTER 4/27 4.1.4 4.1.5 IC DECODER AND DRIVER 4/29 Logical output signals 4.1.6 4/31 4.2 ELECTRIC TAPE TRANSPORT ALIGNMENTS 4/35 4.2.1 General 4/35 4.2.2 Stabilizer (Voltage regulator) 4/35 Tape tension adjustments 1. Tape tension in PLAY mode 2. Limiting the tape tension in spooling mode 3. Limiting the tape tension in 4.2.3 4/35 4/37 4/38 4/39 EDIT mode 4.2.4 Brake control 4/40 4.2.5 Capstan motor control alignment 4/41 Preliminary adjustments 4/42 2. Capstan acceleration control 4/42 3. MASTER capstan tacho alignment 4/43 4. SLAVE capstan alignment 4/43 4/43 5. Tape tension between capstans6. Final inspections

## 4.1 OPERATING OF TAPE TRANSPORT CONTROL

## 4.1.1 Arrangement of control electronics

For convenience and ease of servicing, all tape transport controls are mounted on PC boards of identical size in the control unit (rack construction).

The rack contains following PC boards:

Description	Diagram	ΕL
		-
CAPSTAN SERVO / MASTER	1.080.371	12
Capstanmotor-Steuerung		
ATTENUATOR	1.080.396	10
Eingangsabschwaecher		
IC MEMORY AND COUNTER	1.080.393	9
Speicher-Einheit		
IC DECODER AND DRIVER	1.080.391	8
IC Decoder und Treiber		
DUAL CAPSTAN DIRECTION BOARD	1.080.369	7
Laufrichtungssteuerung		
CAPSTAN SERVO / SLAVE	1.080.371	6
Capstanmotor-Steuerung		
SPOOLING MOTOR CONTROL	1.080.387	5
Wickelmotor-Steuerung		
CONTACTOR	1.080.381	4
Wickelmotor-Schuetzen		
STABILIZER	1.080.370	2
Spannungs-Stabilisator		

A series of sensor elements continuously monitors the following features:

Sensor/ Function	(Signal/Name)
TAPE END SENSOR	YBI-END
Photoelectric end-switch TAPE MOVE SENSOR	YBI-MOVE
Tape motion	ADI-MOAE
TAPE DIRECTION SENSOR	YBI-DIR
Direction of tape motion	
TAPE TENSION SENSORS Tape tension	R-TT1 / R-TT2
TACHO HEADS	YAC-M3/YAC-M6
Capstan motor speed	1.10 1.57 1.40 110

These sensors fully automatically supply the required control data to the control logic of the spooling motors and capstan motor controls. Thus, an optimum operation and accurate tape motion is ensured.

#### 4.1.2 Push buttons

The tape transport is controlled by large-size

illuminated push button (LOCAL CONTROL SWIT-CHES) or an identical remote control unit (REMOTE CONTROL SWITCHES). The local push buttons as well as those of the remote control unit are lighted by means of feedback logic.

Similary, a feedback signal is availlable (FA-DER INDICATOR) or fader start.

#### Interlocking

Push button control is interlocked against incorrect operation. Control commands are electrically stored. Therefore it is possible to switch from the fast wind mode directly to PLAY. During the STOP function the PLAY and STOP buttons are lit. As soon as the tape stops the STOP lamp is turned off and the PLAY function is released to the transport control from the memory.

### EDIT button

The EDIT button is operative only when the tape is stopped or during fast wind. in the latter case, in funktion is onlt active when the button is depressed. After depressing the EDIT button, the tape tension sensors are locked and the EDIT control function is actuated.

The pinch roller however, remain in their initial position. To raise the tape against the playback head, a tape defeater is installed between the pinch roller and the right-hand guide roller.

### Fast wind monitoring

If the EDIT button is pressed during fast wind, the pinch roller moves to the EDIT position and the recording on the tape becomes audible. The tape tension sensors are not locked during this operation.

### Automatic EDIT operation

In the EDIT mode, the spooling motors can be continuously controlled in both directions by the EDIT control knob. The tape tension sensors are unlocked by turning the EDIT control knob out of its neutral position.

The tape speed is proportional to the angular displacement of the EDIT control knob.

#### 4.1.3 Attenuator and Preamplifier

1.080.396

The input attenuator attenuates control signals coming from either the push buttons board, the remote control unit, the fader start relay or the speed switch. Control is realized adjusting the respective input of the button contacts to potential zero. A logical level zero appears at the attenuator output by depressing a push button.

The corresponding signal voltages are:

Logic "L" (0) = max. +4.0V Logic "H" (1) = min. +2.5V

The order of priority of the push buttons functions depends on the sequence of their contacts. First priority is given to the fader start relay, then to the push button contact of STOP, etc. The control of the fader start relay is realized by a Graetz full-wave bridge rectifier using an internal power supply (24V, FAD1, FAD2) or an external supply. The control voltage polarity is immaterial in this case. The fader start function can also be used for dropping out of record mode on all channels, hence continuing in PLAY mode.

The ATTENUATOR AND PREAMP. PC board also comprises the preamplifiers of the tape end switch and the tape motion sensor as well as a logic cicuit switching the logic to STOP as long as the nominal supply voltage is not reached.

### Tape end switch

When the tape is threaded, the RP-END photoresistor is dark and the resulting YBI-END signal is "H".

The supply voltage for the photo-resistor (+16V) is provided from the +24V supply voltage via the series transistor (Q1).

### Safety circuit

The function of the Q3, Q2 photocell amplifier depends on the switching of Q4. The supply voltages of +24V and +5.8V are controlled in the safety circuit. As long as both voltages have not reached their nominal value, either the Q6 or Q7 transistor is locked and transistor Q4 is conducting. The tape end switch signal turns to "L" which is equivalent to the STOP mode.

AT THE SAME TIME THE Q8 TRANSISTOR IS LOCKED, any possible recording signal (YBI-REC = "H") is blocked and the recording relays in the amplifier channels are de-energised or cannot close.

### Tape motion sensor amplifier

As the logic automatically transmits the memorized commands when transport functions are changing, the logic has to be informed of the curent tape motion. For this purpose, sensors producing the required signals are installed on the right-hand tape guide roller. After being converted, these signals indicate tape motion, direction of motion and running time (tape timer).

The impulses produced by the photo-transistor QP-MOVE (QP2, TAPE MOVE SENSOR 1.080.185/186) when the tape is running are rectified, integrated and amplified to produce a logic "H" for the Q-MOVE signal.

An additional stage (Q9) is mounted on the PC board 1.080.396-13 which supplies the YPS-MOVE signal via the remote control connector (GR22) for the A80 preselection unit (for speed evaluation).

## 4.1.4 IC MEMORY AND COUNTER

1.080.393

The integrated circuits are numbered and their connections given in the circuit diagrams. In the following, a particular gate is identified by its IC number and the connection on its output, e.g. Gate 12-8.

The "IC MEMORY" PC board comprises the IC memory, the tape direction detector and the tape timer electronics which include the pulse generator, the counting direction as well as the counter signal regeneration.

#### IC MEMORY

The IC MEMORY has the function of storing and comparing the logic signals from the input attenuator and to process the YBI-END end switch signal and the YBI-MOVE motion signal. When the tape is threaded and the transport stopped all quiescent input signals are at "H" exept for the YBI-FAD input whose quiescent signal is "L".

4 Flip-flops, FFl...FF4, store the control signals. A further Flip-flop (FFO) is connected to gate 12-8 as a history element and monitors in addition to the tape motion signal, also

the situation existing before a function change.

### Tape direction detector

During the braking process, the spooling motors are braked with d.c. current. The braking current for the take-up motor is controlled in order to keep tape tension at the permissible value. The control electronics must, therefore, be informed of the direction in which the tape is moving (fast forward or rewind) as selected by the push buttons or EDIT control knob.

This information about the tape direction is also necessary for the tape timer and is therefore directly taken from the tape by means of the right-hand tape guide roller. The tape direction sensor produces two square-wave signals (QP-DIR1 and QP-DIR2) with a phase shift of 90 degree. Two square-wave signals with a phase shift of 108 degree are derived from the gates 8-8 and 6-6 to generate the timing pulses for the timer control.

The YBI-DIR signal, produced by the detector circuit is required for controlling braking current distribution and for driving the counting direction change-over logic of the tape timer.

### Pulse generation for the tape timer

The derived square-wave voltage P2 and P3 with a phase shift of 108 degree are differentiated by the capacitances C16 and C21. The positive slopes produce narrow pulses which, at low tape speed, are assembled in gate 2-6. At high tape speed, one of the outputs of gate 4-8 or 4-11 (dependent upon the tape direction) is allways being "L" so that the respective pulses have no effect. Thus, the frequency division corresponding to the tape speed is given and the timer always shows real time. These pulses are differentiated once again in C18 and here the rear positive slope produces the time pulse. In gate 4-1 the time pulse is blocked as soon as YBI-END has become "L", i.e. when the tape end has passed over the photo-electric cell. The time pulse controls the counter signal regeneration of the D-flip-flops 7.

### Counting direction change-over logic

The YBI-DIR direction signal together with the feedback signals of the counter signal regeneration determine the output signals of the NOR-gates 5-8 and 5-6 which act on the setting of the D-flip-flops 7. The time (CLOCK) pulses transmit these signals and, thus, determine the frequency of the tape timer logic.

## 4.1.5 IC DECODER AND DRIVERS

1.080.391

The "IC DECODER AND DRIVERS" PC board comprises the control stages for the sensor LED's operation, the motion simulator and the IC decoder including the ENABLE GATES connected in series which decodes the operating signals and controls the driver stages.

The driver outputs are connected to the K-CUT and K-TT signals by means of a diode  $\bullet$ 

In the EDIT mode the pinch rollers stay in start position.

### Control stages for LEDs or lamps

The LEDs are powered by means of the series-resistors R1 and R2 (tape direction sensor), or R9 and R10 (tape motion sensor). The amplifier stages (Q1, Q2, resp. Q3) supply the digital signals corresponding with the operational mode to the logic. When diodes are faulty, these are "L" for output Q2 and "H" for output Q3.

Due to both signals, TEST-B is changed into "L" with the effect that, via the automatic blink circuit (PC board 1.080.381 - spooling motor contactors) the pressed button blink.

At the same time, the K-BRAKE signal is blocked (remains "H"), i.e. the braking contactor no longer switches to electronically controlled braking, if due to lack of direction information, the electronic current distribution is not working, or if the movement signal no longer informs of the "tape stop" situation.

Braking can be done mechanically. When the LEDs of the direction sensor (K-DIRECTION) are faultry, it still is possible to continue operation in all modes with the above restriction. The same is not true, however, if the motion sensor light diode fails. A special simulation is provided for this event.

### Tape motion simulation

Since, due to a faulty tape motion sensor light diode, the logic can no longer recognize when tape is stopped a permanent motion signal is simulated (Gate input 9-1 is "L", output 9-3 chanches to "H"). Thus, YBI-MOVE constantly stays "H", which causes that YBI-FFO can no longer be changed into "H" for the control commands "PLAY" and "REC" (FF2 and FF3 = "H") and the transmission of these commands is blocked.

Thus, all functions operating by way of STOP are blocked. If the motion sensor light diode fails during the running of a function, the simulated motion signal maintains this function unaltered until the STOP button is pressed or the end of tape is reached.

The fast winding functions can still be activated, though.

### IC DECODER AND DRIVERS

The IC decoder decodes the function signals FF1...FF4 for logical sequencing of the operation of electromechanical components such as the spooling motors, solenoids, contactors and indicator lamps.

An enable gate is inserted in front of the actual decoding and has the function of blocking the onward transmission of the stored commands until YBI-MOVE becomes "L" when YBI-FFO= "L" (transport mode changes which requires a tape stop).

### 4.1.6 Logical output signals

Each combination of control signals and sensor signals, together with the status, results in a certain signal combination at the output of the IC decoder.

This combination of output signals causes a corresponding action by the electromechanical elements.

Therefore, input and output signals are logically linked. This fact facilitates tracing of errors since it is not necessary to comprehend the layout of the logic circuits. It suffices to know that a given command will generate, specific reactions in form of a sequence of logical signals.

The interrelationship can be presented in tabular form. Such a table contains the output signals of the PCBs:

- ATTENUATOR 1.080.396 - MEMORY 1.080.393 - IC DECODER 1.080.391

with the corresponding labels of the transfer points (PT) and the signal names (listet vertically). In addition, the signal names of the sensors, whose functions are spread across all 3 PCBs are also included.

The vertical columns shows the logical signal states. The activated indicator lights and magnets are identified with "\*". Only the logical states relevant to the corresponding function are indicated. It should be remembered that the logic is generally accessed with a logical "L" (exept fader start, YBI-FAD = logical "H"). The signal for forward tape motion is YBI-DIR = "H".

For moved tape the corresponding signal for Q-MOVE or YBI-MOVE = "H". A logical "L" at the output of the driver stage to the IC decoder calls for activation of the element connected.

Testpoints (TP) 3, 6 and 11 are located directly at the base of the driver stages. For this reason, their signal is inverse to the one of the corresponding output. These TP numbers, therefore, are identified with the negation sign (crossbar above digit). (Example: if K-CUT at connection point 8B of the IC decoder is = "L", the corresponding TP = "H").

The horizontal rows contains the necessary logical states of a function. From row to row we optain a complete sequence of operations.

### LOGICAL OUTPUT SIGNALS



The Table LOGICAL OUTPUTS NO.1 represents a normal sequence of operation starting with power ON (row 1) and continuing with the treading of tape (row 2).

Row 3 shows the status of the signals immediately before the FAST FORWARD key is depressed.

The next row (DEPRESS FORWARD, time status 1) shows the signals with depressed key. The key remains depressed until RELEASE FORWARD occurs.

The next row shows the signal states occurring when the tape begins to move (MOVE SENSOR"ON") and YBI-MOVE changes to "H".

The row RELEASE FORWARD (key released) shows that no change in signal occours (except for activation signals YBS-FORW), because command is stored and the tape is still in motion.

When breaking down an operation into such individual steps, the table provides far-reaching information on the processes to be performed when a key is depressed, when starting the tape (MOVE SENSOR "ON"), when stopping the tape (MOVE SENSOR "OFF") or when changing the running direction.

LOGICAL	OUTPUT	SIGNALS
---------	--------	---------

### (NORMAL OPERATION)

			A٦	ГТЕ	ENU	JA	то	R	•	1			OR ALS			M	ΞM	OR	Υ						IC-	DE	CC	DE	R					
	TP														7	2	6	5	4		4	5	10	3	14	9	6	7	11	13		12	8	
	PT	A 17	B 16	B 14	B 12	B 8	B 19		B 20						B 7	A 5	B 8	B 9	B 10	A 21	B 12	B 13	A 12	A 8	B 22	A 18	B 8	A 15	B 20	B 18	A 20	A 22	B 14	B 3
SIGN		Y P	Y	Y	Y	Y	Y	s	Υ B	Y B	Y B	Q	В	В	Y B	Y B	Y	Y B	Y B	В	В	В	В	В	Y B	В	К	K	K	K	K	K	Υ	Y B
NAM	IES	S -	S -	S -	S -	s	S	C	<u> </u>	1 -	-	M 0	M 0	D	-	-	Ī	-	1	R E	S T	F 0	R E	R E	-	C	C	P R	L	BR	D	T	C	-
		S	R	F 0	R	R	C	T A	F	E N	D	E	V E	R	F	F	F	F	F	С	O P	R W	W	P R	R	Т	Т	S	F	A K	R		T A	M 0
OPERATION		0 P	W	R	PR	С	T	T	D	D	R				0	1	2	3	4						С			S		Ε			U	E
SYMB.F.SIGNAL 0 SYMB.F.SIGNAL 1	)	0	0	0	0	0	0	0	L	0	0 L	L	*	*	0 L	0 L	0 L	0 L	0 L	*	*	*	*	*		*	*	*	*	*	*	*	0	 L
INITIALISATION	0 1									0	L		ŵ	*	L	0	0	0	0		*													
LOAD TAPE	0										L		ŵ	*	L	0	0	0	0		*													
PRESS FORWARD	0 1			0							L		*	*	L	0 L	0 L	0	0		*	*							*					
MOVE SENSOR ON	0			0							L	L	*	rk rk	LL	L	L	0	0			*							*					L
RELEASE FORWARD	0										L	L	*	*	L	L	L	0	0			*							*					L
PRESS REWIND	0 1		0								L	L	*	*	L	L	L 0	0	0			*	n						*					L
RELEASE REWIND	0										L	L	*	*	L	L	0	0	0				*						*					L
CHANGE DIRECTIO	N 0										0	L	*	*	L	LL	0	0	0				*						*		*			L
PRESS PLAY	0				0						0	L	# #	*	L L	L	0 L	0 L	0		*		*	*					ŵ	*	n n			L
PRESS RECORD	0 1				0	0					0	L	*	*	0	L	L	L L	0 L	*	*			*						*	*			L
RELEASE PLAY	0					0					0	L	*	*	0	L	L	L	L	*	*			*						ŵ	ŵ			L
RELEASE RECORD	0										0	L	*	*	0	L	L	L	L	*	*			ŵ						*	*			L
MOVE SENSOR OFF	0 1										0		*	*	0 L	L	L	L	L	rk rk	*			*	L		*	*	*	*	*			L
MOVE SENSOR ON	0						-				0	L	*	*	L	L	L	L	L	*				*	L		食食	*	*		÷			L
CHANGE DIRECTIO	N 0										L L	L	*	*	L	L	L	L	L	*				*	L		*	th th	*		ŵ			L
PRESS STOP	0	0									L	L	*	rk rk	L	L 0	L 0	L 0	L 0	ŵ				÷	L		*	*	ŵ	÷				L
RELEASE STOP	0	ľ									L L	L	*	*	L	0	0	0	0											*				
MOVE SENSOR OFF	0										L		*		L	0	0	0	0											tr				L
PRESS EDIT	1 0 1						0				L		*	*		0	0	0 0 L	0		*					*						*		
RELEASE EDIT	0						ľ				L		*	*	L	0	0	_ L	0							*	*					*		
PRESS CUTAUT	0							0			L		ŵ	*	L	0	0	L	0							*	*					*		$\exists$
MOVE SENSOR ON	6 0 1							0			L	L	*	*	L	0	0	L	0							* *	*					* *	0	L
RELEASE CUTAUT	0										L	L	*	*	L L	0	0	L	0							* *	*					rit de	0	L
MOVE SENSOR OFF											L	-	*	*		0	0	L	0							*	*					*		L
PRESS REWIND	0		0								L		*	*	L	0 L	0	L	0				ŧ			*	*		*			*		$\neg$
RELEASE REWIND	0										L				L	L	0	0	0				*						*					
MOVE SENSOR ON	0										L	L	*	*	L	L	0	0	0				*						*					L
CHANGE DIRECTIO	1 N 0 1										0 0	L	*	*	L	L	0	0	0				*						*		*			L
END OF TAPE	0									0	0	L	*	*	L	L 0	0	0	0		*		*						÷	*	*			L
MOVE SENSOR OFF										0	0	L	*	*	L	0	0	0	0		*									*	*			L

### LOGICAL OUTPUT SIGNALS

(2)

This table shows that other functions (such as REWIND) are inhibited when activating fader start.

### LOGICAL OUTPUT SIGNALS

### (FADER OPERATION)

			A	ТТ	ΕN	UA	то	R			SEI					M	EM	OF	Ϋ́						IC-	DE	CC	DDI	ΞR					
2	TP														7	2	6	5	4		4	5	10	3	14	9	6	7	11	13		12	8	
	PT	A 17	B 16	B 14	B 12	B 8	B 19		B 20						B 7	A 5	B 8	B 9	B 10	A 21	B 12	B 13	A 12	A 8	B 22	A 18	B 8	A 15	B 20	B 18	A 20	A 22	B 44	B 3
SIGN NAM OPERATION	1ES	Y P S T O P	Y P S - R E W	Y P S F O R W	Y P S R E P R	Y P S R E C	Y P S C U T	S C U T A U T	Y B I F A D	Y B I E N D	Y 8 1 - D 1 R	Q - M O V E	B M O V E	B D I R	Y B I F F O	Y B I F F	Y B I F F 2	Y B I F F 3	Y B I F F	B REC	B - S T O P	BFORW	B R E W	B R E P R	Y B I R E C	B C U T	K - C U T	R R E S	L L F T	K B R A K E	K D I R	K T T	Y C U T A U T	Y B M O V E
SYMB.F.SIGNAL 0 SYMB.F.SIGNAL 1		0	0	0	0	0	0	0	L	0	0 L	L	*	*	0 L	0 L	0 L	0 L	0 L	*	*	*	*	*	L	*	*	*	*	*	*	*	0	L
INITIALISATION	0									0	L		*	*	L	0	0	0	0		ŵ													
LOAD TAPE	0				,						L		*	*	L	0	0	0	0		ŵ													٦
PRESS FORWARD	0			0							L		*	*	L	0 L	0 L	0	0		*	ŵ							*				1	
RELEASE FORWARD	0										L			*	L	L	L	0	0										*					
MOVE SENSOR ON	0 1										L	L	*	*	L	L	L	0	0			*							n n					L
PRESS STOP	0 1	0									LL	L	*	*	L	L 0	L 0	0	0		ń	*							ń					L
RELEASE STOP	0										L	L	*	*	L	0	0	0	0		ŵ									*				L
MOVE SENSOR OFF	0 1										L L		*	n n	L	0	0	0	0		*									ŵ				L
SWITCH FADER ON	0 1								L L		L		*	*	L	0 L	0 L	0 L	0		ŵ			n			*	ŵ	*					
MOVE SENSOR ON	0 1								L L		L	L	sh sh	*	L	L	L	L	0					*			tr tr	th th	*					L
PRESS REWIND	0		0						L		L	L	ŵ	*	L	L	L	L	0					÷			ŵ	ŵ	*					L
RELEASE REWIND	0								L		L	L	*	*	L	L	L	L	0					*			*	ŵ	*				_	L
SWITCH FADER OF	F 0										L L	L L	*	*	L	L 0	L O	L 0	0					*			*	ŵ	*					L
MOVE SENSOR OFF	0 1										L	-	*	*	L L	0	0	0	0		*									*				L
PRESS FORWARD	0			0							L		*	*	L L	0 L	0 L	0	0		*	*							*					1
RELEASE FORWARD	0										L		*		L	L	L	0	0			*							*					
MOVE SENSOR ON	0										L	L	*	*	L	L	L	0	0			*							*					L
END OF TAPE	0									0	L	L	*	*	L	L 0	L 0	0	0		*	*							*			1		L
MOVE SENSOR OFF	0 1									0	L		*	*	L	0	0	0	0		*									*				L
PRESS PLAY	0 1				0					0	L		*	*	L	0 L	0 L	0 L	0		*			ŵ			*	*	*					
RELEASE PLAY	0 1									0	L L		*	*	L L	L 0	L 0	L 0	0		ŵ			*			*	*	*					

## 4.2 ELECTRIC TAPE TRANSPORT ALIGNMENTS

### 4.2.1 General

#### Required instruments and aids

- Multimeter
- Tentelometer 10.300.001.01 (tape tension meter) with special holder QC 1.080.431.00
- Oscilloscope (preferably 2-channel)
- Quartz oscillator 400Hz or
- Frequency counter (preferably quartz-stab.)
- Extender board 21.080.941.00

#### Note

- Ensure that all mechanical elements function correctly before making any electrical adjustements to the tape transport control (see Section 2.2).
- The recorder must have been powered off for at least five seconds before any circuit boards are removed from or installed in the rack.
- Check the supply voltages as follows before making any electrical adjustments to the tape transport control (see Section 4.2.2)

### 4.2.2 Stabilizer (Voltage regulator)

-> Fig.4.1

The supply voltages are measured at the test points 1...5 of the stabilizer PCB, and adjusted with trimmers R1 for +20.0V and R29 for +5.8V / -5.8V.

The current limit for the +20V / +24V supply is set on potentiometer R2.

For measuring purposes, connect an ammeter (range > 4A) in series with the 4...5 ohm resitor (50...75W) across the +0.0V and +24.0V busbars at the rear of the PCB chassis.

- Switch on machine, STOP mode.
- Adjust the potentiometer R2 (I-MAX) so that the ammeter shows the following values: with logic PCBs 3.5A without logic PCBs 4.0A

CAUTION This measurement must be carried out on the test points of the PB boards.

### Note:

The stabilizer system for the +20.0V and +24.0V supply includes circuits for current limiting and disconnection in the event of a short circuit.

If a short circuit occurs, the stabilizing system cuts off the +20.0V and +24.0V supplies completely. The voltages remain disconnected after the short circuit has been cleared. The stabilizing system does not resume normal operation until the machine has been switched off for at least 15 seconds. Also, the nature of this protection circuit does not allow the use of a variable power transformer to raise the voltage slowly from OV (The voltage must be at least half the specified supply voltage when switching on the machine.




Fig.4.1




Fig.4.2

### 4.2.3 Tape tension adjustments

-> Fig.4.3

The tape tension of the spooling motors are aligned with the trimmer potentiometers R70...R75 on the

SPOOLING MOTOR CONTROL PCB 1.080.386: The upper three potentiometers influence the left-hand spooling motor (SUPPLY MOTOR), the lower three trimmer potentiometers influence the right hand spooling motor (TAKE-UP MOTOR).

### Preparatory steps

- Remove head block -> Section 3.1.1
- Remove front cover -> Section 3.1.3
- Remove tape end sensor -> Section 3.1.4 (obstructs tape guidance when the headblock is removed)
- - lers exactly perpendicular.

    Important Reels of the same type (size, material) with a core diameter of 150mm must be mounted on both spindles.
- Thread tape normally across tape tension sensor and guide roller.

Important: All tape tension data refer to the pancake format




Fig. 4.3



Fig. 4.4

### 1. Tape tension in PLAY mode

Note: Applies only to recorders equipped for recording disabled PLAY REVERSE mode.

The switch-selectable PLAY direction (forward/reverse) has to be established for the following adjustments by setting the jumper JS2 on the circuit board

DUAL CAPSTAN DIRECTION BOARD 1.080.369 in position "B".

Restore the jumper to the previous setting "A" after the adjustments have been made.

### Adjustment in PLAY FORWARD mode

PLAY>

#### Prerequisites

Both reels should contain the same amount of  $\mathsf{tape}_{\bullet}$ 

- Remove left-hand pinch roller by unscrewing the cap (Caution! Left-hand thread).
- Start recorder in PLAY FORWARD mode (the right-hand direction preselection button is illuminated).

**Observe** horizontal tape guidance across pinch rollers:

The tape should be guided accurately centered across the defined running surface of the pinch roller perimeter.

Correction is possible by lateral inclination from the perpendicular mounting position.

- Adjust trimmer potentiometer R70 (PLAY/SUP-PLY MOTOR) in such a way that a reading of 30q is obtained on the tentelometer.
- Reinstall left-hand pinch roller.

### Adjustment in PLAY REVERSE mode

PLAY<br/>-> Fig.4.3

### Prerequisites

Both reels should contain the same amount of tape.

- Remove right-hand pinch roller.
- Start recorder in PLAY REVERSE mode (lefthand direction preselector button is illuminated).

Observe horizontal tape guidance across pinch rollers (see above).

- Adjust trimmer potentiometer R75 (PLAY/TAKE-UP MOTOR) in such a way that a reading of 30g is obtained on the tentelometer.
- Reinstall right-hand pinch roller.

### Checks:

- Distribute tape supply evenly to both reels.
- Check in PLAY FORWARD and PLAY REVERSE mode: The tape should not move when the pinch rollers are lifted manually off the capstan shaft.

On machines equipped for RECORD mode:
Reset jumper JS2 to position "A": (disables reverse PLY mode). -> Fig. 4.5




Fig. 4.5

2.Limiting the tape tension in spooling mode FORW (fast forward) REW (fast rewind)

-> Fig.4.3

The maximum tension applied to the tape in spooling mode can be adjusted with the trimmer-potentiometer R71 and R74. This peak tension occurs during the acceleration phase and when reversing the tape direction during fast winding.

Note that a high peak tape tension is required for rapid acceleration.

Although lower peak tape tension result in longer response time during spooling functions the tape will be threated more gently, a fact that is very important when processing master tapes.

### Preparatoty steps

Left-hand tape tension sensor -> Fig. 4.6

- Turn clockwise to the stop (direction of maximum spring preload)
- Identify this position by setting a mark (with a soft pencil) on the circumference of the rotatable tape tension sensor plate {A} relative to the stationary tape tension edge {B}.
- Set a new mark {B\*} at a distance of 18mm in the CCW direction of the fixed marking {B} (lower spring preload).

Right-hand tape tension sensor -> Fig.4.7

- Turn counterclockwise to the stop (direction of maximum spring preload).
- Set mark, as described above.
- Set a new mark {B\*} at a distance of 18mm in the CW direction from the fixed mark {B} (lower spring preload).

### Adjustments

-> Fig.4.3/4.6/4.7

Prerequisite: correct PLAY tape tension according to Section 1.

- Evenly distribute tape supply to both reels (same pancake diameter)
- Hold right-hand tape tension sensor in position {B\*} (18mm before stop) or secure it there with ashesive tape.
- Select fast forward mode (FORW) and determine setting of potentiometer R74 at which the tape stands still.
  - Restore tape tension sensor to its neutral position (remove adhesive tape).
- Evenly distribute tape supply to both reels.
- Retain left-hand tape tension sensor in position (B\*) (18mm before stop) or secure it there with adhesive tape.
- Select fast rewind (REW) and determine the setting of potentiometer R71 in which the tape stands still.
   Restore tape tension sensor to its neutral position (remove adhesive tape).

### Check with tentelometer:

- The maximum admissible tension of 120g should not be exceeded during the acceleration phase of the spooling motors.
- Correction is possible by proportional reduction of tape tension on R71/R74 (corresponds
  to an increase of the distance between the
  marks {B} and {B'})




Fig. 4.3




Fig.4.6




Fig.4.7

### 3.Limiting the tape tension in EDIT mode

-> Fig. 4.3/4.8

Prerequisites: The tape tension for PLAY and spooling mode (FORW/REW) should be correct.

- Evenly distribute tape supply to both reels (same pancake diameter).
- Open (turn clockwise) R72 (CUT) for EDIT RE-VERSE to 1/5...max.l/4 of the setting range. -> Fig.4.8
- Press EDIT button.
- Short-circuit EDIT knob microswitch (interconnect terminal to which black wire is soldered and vacant terminal) - EDIT solenoid becomes deenergized.
- Turn EDIT knob to its center position.
- Determine setting of R73 (CUT) for EDIT FOR— WARD in which the tape (same diameter) stands still.
- Remove short-circuit of microswitch.

### Check with tentelometer:

- The maximum admissible tape tension of 120g should not be exceeded when alternating the spooling direction in EDIT mode.
- Correction is possible by reducing the tape tension on R72 (counterclockwise) and subsequent alignment with R73 as described above.

  Repeat check with tentelometer.




Fig.4.8

### 4.PLAY tape tension between the capstans

Refer to Section 4.2 5

"Capstan motor alignment".

#### 4.2.4 Brake control

The following procedure for adjusting brake control is based on the tape tension for play-back.

It is therefore most important that the tape tensions for PLAY/REPRODUCE are set correctly before adjusting the brake control electronics (Section 4.2.3).

The brake control system comes into operation when the STOP button is depressed while in fast wind or PLAY mode (K-BRAKE). The right-hand tape tension sensor (T-TT2) is employed as the control element (sensor).

Depending on the direction the tape is moving, the spooling motor on the respective take-up side is connected to the circuit of the brake control electronics.

-> Fig.4.9
Tape tension occuring during braking can be limited at trimmer potentiometer R9.
(The limiting point depends on the angle of rotation of the right-hand tape tension sensor and the reference voltage set R9).
The braking voltage can be adjusted with the

aid of a multimeter as shown in Fig. 4.10.

### Adjustment

Fit a full reel and wind forward some 10 to 20m. Press PLAY button and mark the resulting position of the right-hand tape tension sensor. Remove tape. Connect meter to test points TP2 (yel,-) and TP3 (wht,+) (measuring range >20V)

To simulate movement of tape, drive the motion sensor with a eubber band fitted over the capstan shaft and the right-hand guide roller.

Briefly depress REW or FORW button.

### Caution

Do not keep the machine in the braked condition longer than 2 minutes. To discontinue the braking action, stop right-hand guide roller (remove rubber band).

Turn right-hand tape tension sensor to the previously marked PLAY position. Adjust trimmer potentiometer R9 to a meter reading of  $4V_{\bullet}$ 

Check that the control signal corresponds to the curve shown in the opposite diagram (Fig.4.10) moving the right-hand tape tension sensor.

When the optical tape end sensor responds light barrier not covered) and the tape tenssion sensor is at rest, full braking is applied to both motors until the right-hand guide roller stops, i.e. YBI-MOVE becomes "L".




Fig. 4.9




Fig.4.10

### 4.2.5 Capstan motor control alignment

-> Fig.4.11

The alignments of the capstan tacho and the tape tension between the capstan shafts are interrelated:

The speed of the two capstan motors is controlled through separate servo electronics

CAPSTAN SERVO PCB 1.080.371. The control unit defined as the MASTER ensures that the corresponding capstan motor runs exactly at the nominal tape speed.

The control unit defined as the SLAVE ensures that the corresponding capstan motor runs at a speed that is slightly higher than the nominal tape speed.

The effect of this adjustable speed deviation is a small, controllable tape slip on the SLAVE-controlled capstan and permits accurate setting of the tape tension between the capstan shafts.

The assignment of the capstan motor to the MASTER and the SLAVE control depends on the preselected PLAY direction (PLAY forward / PLAY (PLAY forward / PLAY reverse).

#### Important notes

The following are basic preconditions for effective alignment of the capstan motor control:

- All mechanical adjustments have been performed conscientiously
   Section 3.2
- The previously described tape tensions and tension limitations of the spooling motors are correct
  -> Section 4.2.3
- All alignment are to be made with the recorder at operating temperature.
- The tape transport must be positioned horizontally while alignments are made.
- The tape contact surfaces of the capstan shafts and the pinch rollers must be clean and free of grease.

### Required measuring instruments and aids

-> Fig.4.12

- Extender board

21.080.941.00

Measuring arrangement {A}

- Oscilloscope (preferably 2-channel model)
- Quartz oscillator 400Hz

Measuring arrangement {B}

- If no 400Hz oscillator is available, capstan alignment is to a limited extend possible with a
- Frequency counter (preferably quartz-stab.)

An oscilloscope is required for wobble measurement. A wow-and-flutter meter is a possible alternative, however only for record/reproduce machines.




Fig.4.11




Fig.4.12

### Alignment elements

-> Fig.4.12 - CAPSTAN SERVO PCB "MASTER" CAPSTAN SERVO PCB "SLAVE" 1.080.371 1.080.371 Ll Discriminator coil (Tacho alignment, coarse) R46 Trimmer potentiometer (Tacho alignment, fine) TP1 Test point ground (+0.0V)
M.alignment A: TP2 test point signal (Y-TAC)
M.alignment B: R42 signal (collector Q4) -> Fig.4.13 - DUAL CAPSTAN DIRECTION PCB 1.080.369 Regulator for wobble alignment: R1 SLAVE capstan R2 MASTER capstan Regulator for capstan acceleration control: SLAVE capstan, signalization through DL1 MASTER capstan, RR

### 1.Preliminary adjustments

The following adjustments establish the basic condition from the alignment procedure can be initiated (e.g. after replacement of a control PCB).

Fine-adjustments necessary during normal maintenance intervals can be made directly on the corresponding elements.

-> Fig.4.12 CAPSTAN SERVO PCB (MASTER and SLAVE):

- Set R46 to the middle of its range of travel.

Screw trimmer slug L1 approximately 1mm into the coil body (corresponds to a tacho frequency of approximately 400Hz).

DUAL CAPSTAN DIRECTION PCB:

 Set R1, R2, R7 and R8 to the middle of their adjustment ranges.

Only record machines (A80/QC-REC):

-> Section 4.2.3, Fig. 4.5

 Set jumper {JS2} to the position {B} (forward and reverse PLAY).

### 2.Capstan acceleration control

During the acceleration phase of the capstan motors, or when the machine is switched on, or when changing the capstan direction, PLAY (and REC) mode is interlocked until the capstan motors have attained the desired speed. The acceleration phase is signalled by LEDs DL1 and DL2. As soon as a capstan motor has attained its tacho frequency of 400Hz within a certain tolerance, the corresponding LED turns

off again. The motor assignment depends on the preselected PLAY direction:

PLAY > DL1. Capstan right in Slave function

DL2. Capstan left in Master function

PLAY < DL1. Capstan right in Slave function

DL2. Capstan left in Master function

### Preliminary adjustments

(DUAL CAPSTAN DIRECTION PCB) -> Fig.4.13/4.14

- Select STOP mode.

 Set trimmer potentiometer R7 and R8 to the CCW limit position - DL1 and DL2 turn on.

Slowly open R7 and R8 and determine and mark the position in which the corresponding LED {A},{B} turns off and subsequently on again when the potentiometers are turned further.

 Set potentiometers midway {C} between the two markings.




Fig.4.12




Fig. 4.13 Fig. 4.14

### 3.MASTER capstan tacho alignment

-> Fig.4.12

- Mount MASTER CAPSTAN SERVO PCB on extender board and slide it into the rack.
- Establish measuring arrangement {A} or {B}.
- Switch machine on and press preselector PLAY forward.

### Aligning the tacho frequency

Coarse-adjustment with slug L1 Fine-adjustment with potentiometer R46

Measuring arrangement {A}:

Synchronize sine wave on screen (tacho signal) with quartz frequency (400Hz, externally triggered): adjust L1 in such a way that the sine-wave representation on the screen stands still (no horizontal drift). Fine-adjust with R46.

- Measuring arrangement {B}:

Coarse-adjust with L1 and fine-adjust with R46 to obtain a reading of 400Hz +/-0.1Hz on the frequency counter.

#### Wow-and-flutter correction

-> Fig.4.13

DUAL CAPSTAN DIRECTION PCB:

- Connect oscilloscope to TP1 (OV) and TP2 on the MASTER CAPSTAN PCB.
- Adjust with R1 on the DUAL CAPSTAN DIRECTION PCB for minimal horizontal jitter.

### 4. SLAVE capstan alignment

Same alignments as for MASTER capstan, but with SLAVE CAPSTAN SERVO PCB.

Wow-and-flutter is corrected with R2 on the DUAL CAPSTAN DIRECTION PCB.

Retain measuring arrangement for the subsequent alignment.

### 5. Tape tension between capstans

-> Fig.4.12

- Thread tape and distribute tape supply evenly to both reels (same pancake diameter).

  Guide tape across tentelometer

-> Section 4.2.3 "Preparatory steps"
Start machine in PLAY FORWARD (PLAY>) mode:

- CAPSTAN SERVO SLAVE PCB:

Adjust tape tension with R46, depending on the type of tape (18u\*): Fe 80g +/-5g Cr 60g +/-5g

\* (for thinner tapes, reduce correspondingly)

Only for A80/QC-REPRO without record mode:

- Start machine in PLAY REVERSE mode.
- Measure tape tension. Correct if necessary by varying the mechanical pressure of the pinch rollers within 600g #/-50g -> Section 3.2.2, paragraph 4, PLAY< mode. Increasing the pressure of the left-hand
- PLAY> mode: Decreasing the pressure of the right-hand pinch roller = lower tape tension.

pinch roller = greater tape tension.

## 6.Final inspections

After one hour's operation in PLAY mode: Recheck the alignments in Section 4.2.5, Items 2...5 and correct it necessary.

Only for A80/QC-REC:
Restore jumper JS2 (DUAL CAPSTAN DIRECTION PCB 1.080.369) to position {A} (disables PLAY REVERSE (PLAY<) mode). -> Fig.4.5

5	AUDIO ELEKTRONIK		5	AUDIO ELECTRONICS	
an my ath an an an a		Seite	elile elili filili dan trin ena e		page
5.1	ALLGEMEINES	5/2	5 • 1	GENERAL	5/16
5.1.1 5.1.2	Varianten Uebersicht Bezeichnung der Regler	5/ 2	5.1.1 5.1.2	Summary of machine versions Identification of controls	5/16
	und Anschluesse	5/3		and connections	5/17
5.1.3	Bonoetigte Messgeraete	-, -	5.1.3	Measuring instruments and aids	5/17
	und Hilfsmittel	5/3	5.1.4	Important hints	5/18
5.1.4 5.1.5	Wichtige Hinweise Kontrolle	5/4	5.1.5	Checks the audio supply voltages	5/18
	der Audio-Speisespannungen	5/4	5 • 2	REPRODUCE ADJUSTMENT	5/19
5.2	WIEDERGABE-EINSTELLUNGEN	5/5	5.2.1	Adjusting the level of the reproduce amplifier	5/19
5.2.1	Wiedergabe Pegel- Einstellung	5/5	5.2.2	Reproduce head azumuth alignment	5/19
5 • 2 • 2 5 • 2 • 3	Wiedergabekopf-Spalteinstellung Wiedergabe-Frequenzgang-Abgleich	5/ 5 5/ 6	5.2.3	Reproduce frequency response alignment	5/20
5.3	AUFNAHME-EINSTELLUNGEN	5/7	5.3	RECORD ADJUSTMENTS	5/21
5.3.1	Kontrolle		5.3.1	Check of oscillator frequency	5/21
	der Oszillator-Frequenz	5/7	5.3.2	Record amplifier	
5.3.2	Pegeleinstellung			level adjustments	5/21
	der Aufnahmeverstaerker	5/7	5.3.3	Record head azimuth alignment	5/22
5.3.3	Aufnahmekopf- Spalteinstellung	5/8	5.3.4	Bias	5/23
5.3.4	vormagnetisierung	5/9	5.3.5	Frequency response alignment	5/24
5.3.5	Frequenzgang-Abgleich	5/10	5.3.6	Crosstalk adjustment	5/25
5.3.6	Einstellung	•		-	
	der Uebersprech-Kompensation	5/11	5.4	VU MONITOR	5/27
5 • 4	VU-MONITOR	5/13	5 • 4 • 1 5 • 4 • 2	Operating hints Calibration of VU meters	5/27 5/27
5.4.1	Bedienungshinweise	5/13			•
5.4.2	Abgleich der VU-Meter	5/13			

#### 5.1 ALLGEMEINES

## Varianten Uebersicht

### A80/QC-2REPRO

Wiedergabemaschine mit 2 Stereo-Halbspur-Wiedergabekoepfen

mit Stummschaltkreis)
1 Stabilisator-Steckkarte 1.080.988.00
(hinter Anschlussfeld)
[4] 1 Umsetzer

fuer Geschwindigkeits-Signal 1.080.979.81 {6} 1 Entzerrungs-Umschalter 1.081.355.81




Fig. 5.1

### A80/QC-2REC/2REPRO

mit Vollspur-Aufnahmekopf und Stereo-Halbspur-Wiedergabekopf

Audio-Elektronik bestehend aus: -> Fig.5.2

{1} 2 Wiedergabe-Verstaerker 1.081.952.81 mit Entzerrung (IEC I/II-IV) 1.081.965.00 1 Wiedergabe-Vorverstaerker 2CH im Kopftraeger eingebaut 1.020.708.00 1.080.989.00 {2} 1 Anschlussfeld /1.080.997.00 mit Stummschaltkreis) 1.080.988.00 1 Stabilisator-Steckkarte (hinter Anschlussfeld) {3} 2 Aufnahmeverstaerker 1.081.960.81 1.081.964.00

mit Entzerrung (IEC I/II-IV) 1.081.964.00 {5} 1 Oszillator 1.080.984.00 {6} 1 Entzerrungs-Umschalter 1.081.955.81




Fig. 5.2

### A80/QC-1REC/2REPRO

mit Stereo-Halbspur-Aufnahmeund Wiedergabekoepfen

1 Wiedergabe-Vorverstaerker 2CH
im Kopftraeger eingebaut 1.020.708.00
{2} 1 Anschlussfeld 1.081.989.00
mit Stummschaltkreis) /1.080.997.00

mit Stummschaltkreis) /1.080.997.00
1 Stabilisator-Steckkarte (hinter Anschlussfeld)

[3] 1 Aufnahmeverstaerker 1.081.960.81

mit Entzerrung (IEC I/II-IV) 1.081.964.00 {5} 1 Oszillator 1.080.984.00 {6} 1 Entzerrungs-Umschalter 1.081.955.81




Fig. 5.3

### 5.1.2 Bezeichnung der Regler und Anschluesse

Auf der mit FAST beschriebenen, oberen Haelfte der Einschub- Frontplatte befinden sich die Einstellregler fuer die IEC-I Entzerrungsnorm.

Wiede	ergabe-Verstaerker	REPRO AMP -> Fig.5.4
<pre>{1} {2} {3}</pre>	Pegelregler Hoehenregler Tiefenregler	LEVEL TREBLE IEC-I BASS
{4}	Uebersprechregler	CROSSTALK
{5} {6} {7}	Pegelregler Hoehenregler Tiefenregler	LEVEL TREBLE IEC-I/IV BASS
Aufna	ahme-Verstaerker	RECORD AMP -> Fig.5.5
{8} {9} {10}	Pegelregler Hoehenregler Vormagnetisierungs- regler	LEVEL TREBLE IEC-I BIAS
{11}	Anschluss fuor Aufnahmestrom- Messung	RECORD CURR RECORD CURR
{13}	Pegelregler Hoehenregler Vormagnetisierungs- regler	LEVEL TREBLE IEC-I/IV BIAS
Ansch	nlussfeld	-> Fig•5•6
{16} {17}	Leitungs-Eingang CH Leitungs-Ausgang CH Leitungs-Eingang CH Leitungs-Ausgang CH	1
Oszi	llator 	-> Fig.5.6
		ED . CE CIID D

ERASE CURR {19} Anschluss fuer Loeschstrom-Messung

### 5.1.3 Benoetigte Messgeraete und Hilfsmittel

- (Klirrfaktor 0,5%) - Tonfrequenz-Generator - Tonfrequenz-Millivoltmeter
- (Frequenzbereich bis max.20kHz)
- Messbaender
- 2-Kanal-Oszilloskop
- Digital-Frequenzzaehler
- Frequenz-Analysator (nur fuer Uebersprech- Einstellungen erforderlich)
- Entmagnetisierungsdrossel - Verlaengerungsprint

10.042.002.01 1.080.940

- Abgleich-Schraubenzieher




Fig. 5.4




Fig.5.5




Fig.5.6

#### 5.1.4 Wichtige Hinweise

- Bevor Steckkarten aus dem Rack gezogen, respein des Rack eingeschoben werden, muss des Geraet mindestens 5 Sekunden ausgeschaltet sein.
- Entriegeln der Einschuebe: Randrierte Knoepfe durch eine Vierteldrehung gegen den Uhrzeigersinn loesen.
- Vor Einstellungen an der Audio- Elektronik sind die Speisespannungen. wie in Kap. 4.2.2 beschrieben, zu kontrollieren.
- Vor Einstellarbeiten sind die Bandfuehrungs-Elemente und Tonkoepfe sorgfaeltig zu reinigen und zu entmagnetisieren.

### 5.1.5 Kontrolle der Audio-Speisespannungen

### Wichtig

Vor Einstellungen an der Audio- Elektronik muss die Spannungs-Stabilisierung von +/-12V auf korrekten Wert ueberprueft werden.

#### Vorgehen:

Nach dem Entfernen des Audio- Anschlussfeldes (4 Raendelschrauben entriegeln), wird die Stabilisator-Steckkarte STABILIZER 1.980.988 zugaenglich.

-> Fig.5.7

- DC-Voltmeter an Testpunkte TP blk (0.0V) und TP red anschliessen und an Trimmpotentiometer R5 auf +12V abgleichen.
- DC-Voltmeter an Testpunkte TP blk (0.0V) und TP blu anschliessen und an Trimmpotentiometer R11 auf -12V abgleichen.




Fig.5.7

### 5.2 WIEDERGABE-EINSTELLUNGEN

## Pegeleinstellungen an Wiedergabe- Verstaerker

-> Fig.5.8

- 1. Geraet einschalten.
- 2. Band einlegen und Entzerrungswahlschalter
  {20} auf die, der verwendeten Bandsorte entsprechende Entzerrung IEC-I oder -II/IV einstellen.
- 3. Tonfrequenz- Millivoltmeter am Leitungsausgang CH1 {16} anschliessen (Ausgang mit 200 Ohm, resp. 600 Ohm abschliessen).
- 4. Messband auf Wiedergabe starten (Abschnitt Bezugspegel 333Hz).
- 5. Erforderlichen Leitungspegel einstellen: IEC-I Einschub REPROD AMP. CH1 Regler {1} LEVEL (FAST) IEC-II/IV Einschub REPROD AMP. Regler {5} LEVEL (SLOW)
- 6. Bei 2-Kanal-Geraeten: Einstellung analog 1...5 jedoch am Einschub REPROD. AMP. CH2

### 5.2.2 Wiedergabe- Kopfspalteinstellung (Azimuth)

Die folgende Phaseneinstellung kann mit einem 2- Kanal- Oszilloskop (Abschnitt A) oder nach der Phasen- Methode (Abschnitt B) durchge-fuehrt werden. Die Wahl der Methode richtet sich nach den verfuegbaren Messgeraeten.

# A Messmethode mit 2-Kanal-Oszilloskop -> Fig.5.9

- 1. Geraet einschalten.
- 2. Oszilloskop an Leitungsausgaenge {16} CH1 und CH2 anschliessen.
- 3. Testband im Abschnitt "Spalteinstellung 10kHz" auf Wiedergabe starten. 4. Die beiden Ausgangspegel des Geraetes auf
- identische Amplitude vorabgleichen Einschuebe REPRO AMP Regler {2} TREBLE/IEC-I (FAST)
- 5. Wiedergabekopf mittels Azimuth- Einstellknopf auf maximalen Ausgangspegel und auf geringste Phasenwinkel-Differenz einstellen.




Fig. 5.8




Fig. 5.9

#### Phasenmethode

-> Fig.5.9...5.11

- Geraet einschalten.
- Testband im Abschnitt "Spalteinstellung" 10kHz auf Wiedergabe starten.
- 3. Tonfrequenz-Millivoltmeter an Leitungs-Ausgang {16} CH1 und nachfolgend an {18} CH2 anschliessen. Mit den entsprechenden Reglern {2} TREBLE/IEC-I, an den Einschueben REPROD AMP. auf identische Ausgangspegel vorabgleichen.
- 4. Tonfrequenz- Millivoltmeter gegenphasig an die beiden Leitungsausgaenge CH1 {16} und CH2 {18} anschliessen -> Fig.5.10b
- 5. Wiedergabekopf mit dem Azimuth- Einstellknopf auf minimale Anzeige abgleichen. Diesen Differenzpegel Pd ablesen und notieren (dB).
- 6. Tonfrequenz- Millivoltmeter gleichphasig an die beiden Leitungsausgaenge CH1 {16} und CH2 {18} anschliessen -> Fig.5.10a
- 7. Ablesen des Summenpegels Ps.
- 8. Fuer die Ermittlung der Phasenwinkel-Differenz gemaess Fig.5.11 ist die Pegeldifferenz Ps-Pd zu bilden. Die vorhandene Phasenwinkeldifferenz kann aus dieser Kurve herausgelesen werden.

### 5.2.3 Wiedergabe- Frequenzgang Abgleich

-> Fig.5.9

- 1. Geraet einschalten.
- 2. Messband auflegen.
- 3. Tonfrequenz-Millivoltmeter an Leitungs-Ausgang CH1 {16} anschliessen.

  4. Messband im Abschnitt "Bezugspegel"
- Wiedergabe starten und Leitungspegel kontrollieren.
- 5. Messband im Abschnitt "Frequenzgang" Wiedergabe starten.
- 6. Hoehenkorrektur bei 10kHz vornehmen:
- Regler {2} TREBLE; Einschub REPROD AMP. CH1 7. Tiefenkorrektur im unteren Tonfrequenzbereich (100Hz) vornehmen: Regler {3} BASS, Einschub REPROD AMP. CH1
- 8. Fuer die Einstellungen des Verstaerkers CH2 gilt das gleiche Vorgehen.




Fig. 5.9




Fig. 5.10




Fig.5.11

#### 5.3 AUFNAHME-EINSTELLUNGEN

#### Hinweis

Wo die Anwendung von neuem Band vorgeschrieben ist, kann auch bespieltes Band verwendet werden. Die Aufzeichnung wird beim Aufnahmevorgang geloescht.

### 5.3.1 Kontrolle der Oszillator-Frequenz

-> Fig.5.13/5.14

- Geraet einschalten.
- 2. Digital- Frequenzzaehler an Anschluss {19}
   (ERASE CURR) anschliessen.
- 3. Neues, unbespieltes Band der gewuenschten Bandsorte auflegen und das Geraet auf Aufnahme starten.
- 4. Oszillatorfrequenz messen. Diese soll 150kHz +/-3kHz betragen. Liegt die Oszillatorfrequenz ausserhalb des Toleranzbereiches, muss der Oszillator justiert werden.
  5. Geraet ausschalten.
- 5. Geraet ausschalten. Oszillator-Einschub 1.080.984 herausziehen. Verlaengerungsprint 1.080.940 einsetzen und Oszillatorkarte aufstecken.
- 6. Geraet einschalten und auf Aufnahme starten
- 7. Oszillatorspule L2 auf 150kHz abgleichen.
- 8. Geraet ausschalten. Verlaengerungsprint herausziehen und Oszillatoreinschub in Verstaerkerkorb einstecken.
- 9. Geraet einschalten und auf Aufnahme starten.
- 10.Kontrollmessung der Oszillatorfrequenz: Liegt die Frequenz ausserhalb des Toleranzbereiches, sind die Einstellungen gemaess Position 5...7 zu wiederholen.

### 5.3.2 Pegeleinstellung der Aufnahme- Verstaerker

- 1. Geraet einschalten.
- 2. Tonfrequenz-Millivoltmeter an Leitungs-Ausgang {16} CH1 anschliessen.
- 3. Tonfrequenz- Generator an Leitungs- Eingang {15} CH1 anschliessen. Frequenz: lkHz, Pegel: Leitungspegel
- 4. Neues, leeres Band auflegen und auf Aufnahme starten.
- 5. Regler LEVEL {8} oder {12} am Einschub RE-CORD AMP. CH1 auf Leitungspegel einstellen.
- 6. Bei zwei Aufnahmekanaelen: Pegeleinstellung bei Kanal CH2 analog den Positionen 1...5 vornehmen.




Fig.5.13




Fig. 5.14

### 5.3.3 Aufnahme-Kopfspalteinstellung (Azimuth)

-> Fig.5.15/5.16
Die folgende Phaseneinstellung kann mit einem 2-Kanal- Oszilloskop (Abschnitt A) oder nach der Phasenmethode (Abschnitt B) durchgefuehrt werden. Die Wahl der Methode richtet sich nach den verfuegbaren Messgeraeten.

### A Messmethode mit 2-Kanal-Oszilloskop

- 1. Geraet einschalten.
- 2. Tonfrequenz-Generator parallel an die beiden Leitungs- Eingaenge Kanal CH1 {15} und Kanal CH2 {17} (CH1+CH2) anschliessen (Pegel 26dB unter Bezugspegel, Frequenz 1...10kHz).
- 3. 2-Kanal- Oszilloskop an Leitungs- Ausgaenge Kanal CH1 {16} und Kanal CH2 {18} (CH1+CH2) anschliessen.
- 4. Neuwertiges, leeres Band auflegen und auf Aufnahme starten.
- 5. Die beiden Ausgangspegel des Geraetes auf identische Amplitude abgleichen: Regler TREBLE {9} oder {13} der Einschuebe RECORD AMP.
- 6. Aufnahmekopf mittels Spaltjustier- Schraube {A} auf geringste Phasenwinkel- Differenz einstellen; bei schrittweiser Erhoehung der Frequenz von 1...10kHz. (Anzeigeverzoegerung beachten, deshalb besonders langsam einstellen).

### B Phasenmethode

- 1. Geraet einschalten.
- 2. Tonfrequenz-Generator an die beiden Leitungs-Eingaenge Kanal CH1 {15} und CH2 {17} (CH1+CH2) anschliessen. Pegel 15dB, Frequenz 10kHz
- Neuwertiges, leeres Band auflegen und das Geraet auf Aufnahme starten.
- 4. Die weiteren Einstell- und Messvorgaenge sind analog dem Kapitel 5.2.2, Abschnitt B durchzufuehren (anstelle Azimuth- Einstellknopf, Spaltjustierschraube A, Fig.5.15).

Zugehoerige Anschluesse und Regler: Leitungs-Ausgaenge {16} und {18}, Regler TREBLE {9} oder {13}.




Fig. 5.15




Fig.5.16

### 5.3.4 Vormagnetisierung (BIAS)

Bei der Wahl der Vormagnetisierungs- Einstellung ist ein Kompromiss zu schliessen zwischen Verzerrungsgrad, Frequenzgang, Modulationsrauschen und Aussteuerungsgrad. Die Vormagnetisierungs-Einstellung wird weiter nicht allein durch die Bandsorte bestimmt, sondern ist stark abhaengig von der Spaltbreite des Aufnahmekopfes.

Bei der Vormagnetisierungs- Einstellung wird der HF-Strom (bei konstantem NF-Signal) soweit ueber das Empfindlichkeits- Maximum des entsprechenden Bandes erhoeht, bis die NF- Ausgangs-Spannung um einen bestimmten Betrag, (Delta U) abgesunken ist. -> Fig. 5.17 Fuer die ueblicherweise verwendeten Bandsorten betraegt diese Absenkung ca. -5dB.

Die Vormagnetisierungs-Einstellung erfolgt mit einer Modulationsfrequenz von 8kHz• Um Uebersteuerungen und Fehlmessungen zu vermeiden, ist der Eingangspegel auf -26dB gegenueber dem Bezugspegel (Operating Level) zu reduzieren•

### Vormagnetisierung

-> Fig.5.17

- Geraet einschalten.
- 2. Tonfrequenz-Millevoltmeter an Leitungs-Ausgang {16} Kanal CH1 anschliessen.
- 3. Tonfrequenz- Generator an Leitungs- Eingang {17} Kanal CHl anschliessen. Frequenz: 8kHz. Peqel: 26dB unter Bezugspegel
- 4. Neuwertiges oder leeres Band auflegen und Geraet auf Aufnahme starten.
- 5. Regler LEVEL, {8} oder {12} Einschub RECORD AMP, CH1 vorlaeufig so einstellen, dass das Tonfrequenz- Millivoltmeeinen Ausschlag von 26dB unter Bezugspeanzeigt.
- 6. Regler BIAS, {10} oder {14}
  Einschub RECORD AMP., CH1: -> Fig.5.17
  vom linken Anschlag {CCW BACK STOP} im Uhrzeigersinn {CW} aufdrehen, bis die Maxianzeige {MAX.} am Tonfrequenz- Millivoltmeter erreicht ist (=Empfindlichkeits- Maximum des Tonbandes). Den Regler im Uhrzeigersinn {CW} weiterdrehen, bis die Anzeige am Millivoltmeter um -5dB gesunken ist.
  7. Tonfrequenz-Generator auf 1kHz einstellen
- 7. Tonfrequenz-Generator auf 1kHz einstellen und Pegeleinstellung kontrollieren.
- 8. Bei 2-Kanal-Geraeten: Vormagnetisierungs- Abgleich fuer Kanal CH2 analog dem Einstellablauf 1...7 ausfuehren. Anschluesse: Leitungs- Eingang {17} Leitungs- Ausgang {18}

### Achtung

Die Kanaele beeinflussen sich gegenseitig.




Fig.5.17




Fig.5.18

#### 5.3.5 Frequenzgang-Abgleich

-> Fig.5.19

- Tonfrequenz- Generator an Leitungs- Eingang {15}, Kanal CH1 anschliessen. Frequenz: 10kHz 26dB unter Bezugspegel
- 2. Neuwertiges, leeres Band auflegen und auf Aufnahme starten.
- 3. Hoehenkorrektur mit Regler TREBLE {9} oder {13}, Einschub RECORD AMP., CHl vornehmen.
- 4. Tonfrequenz- Generator im unteren Frequenzbereich (30...100Hz) variieren.
- 5. Tiefenkorrektur mit Regler BASS (3) oder {7} , Einschub REPROD AMP., CH1 vornehmen. Auf linearen Ausgangspegel einstellen.
- 6. Bei 2-Kanal-Geraeten: Frequenzgang-Abgleich fuer Kanal CH2 analog dem Einstellvorgang 1 ... 5 ausführen. Anschluesse: Leitungs- Eingang {17} Leitungs- Ausgang {18}

### Frequenzgang "Ueber Band" kontrollieren

- Geraet einschalten.
- 2. Tonfrequenz-Millivoltmeter an Leitungs-Ausgang {16}, Kanal CH1 anschliessen.
- 3. Neuwertiges Band der gewuenschten Bandsorte auflegen.
- 4. Tonfrequenz- Generator an Leitungs- Eingang {15}, Kanal CH1 anschliessen.
- 5. Geraet auf Aufnahme starten.
- 6. Tonfrquenz- Generator innerhalb des gesamten Tonspektrums (30...18000Hz) durchstimmen; positive und negative Abweichungen notieren.
- 7. Bei 2-Kanal-Geraeten:

Frequenzgang-Kontrolle fuer Kanal CH2 analog dem Einstellablauf 1...6 vornehmen. Anschluesse: Leitungs- Eingang {17} Leitungs- Ausgang {18}

80 Hz • • • 12 KHz +/-1 dB +1•5 dB -3 dB 30 Hz...16 kHz 16 Hz...18 kHz +1,5 dB -5 dB

### Anmerkung

Liegt der Frequenzgang nicht innerhalb der garantierten Daten, so sind zunaechst folgende Punkte zu ueberpruefen:

- Tonkoepfe verschmutzt oder magnetisiert.
- Spalteinstellung des Aufnahmekopfes nicht korrekt.
- Aufnahmepegel fuer die verwendete Bandsorte zu hoch; das Band arbeitet bei hohen Frequenzen im Saettigungsbereich.
- Vormagnetisierungs-Einstellung nicht korrekt durchgefuehrt oder falsche Bandsorte.
- Hoeheneinstellung (TREBLE) nicht korrekt.




Fig. 5.19

### 5.3.6 Einstellung der Uebersprech- Kompensation

-> Fig.5.20

- Geraet einschalten.
- 2. Tonfrequenz- Generator an Leitungs- Eingang
  {15}, Kanal CH1 anschliesen.
  Pegel: Bezugspegel
  Frequenz: 3kHz
- 3. Frequenz. Analysator an Leitungs- Ausgang [18], Kanal CH2 anschliessen.
- 4. Neuwetiges, leeres Band der gewuenschten Bandsorte auflegen und Geraet auf Aufnahme starten.
- 5. Mit Regler {4} CROSSTALK, Einschub REPROD AMP. CH1, Uebersprechen auf Minimum Anzeige am Freguenz- Analysator einstellen.
- am Frequenz- Analysator einstellen.

  6. Uebersprechen in vertauschter Reihenfolge:
  Tonfrequenz- Generator an Leitungs- Eingang
  {17}, Kanal CH2, Frequenz- Analysator an
  Leitungs- Ausgang {16}, Kanal CH1 anschliessen. Mit Regler {4} CROSSTALK, Einschub
  REPROD AMP., Uebersprechen auf Minimum Anzeige abgleichen (analog dem Einstellvorgang 1...5).






Fig.5.20





5.4 VU-MONITOR

(OPTION)

-> Fig.5.21/5.22

Hinweis

Alle Standard- Ausfuehrungen der Bandmaschine A80/QC koennen, unter Verwendung des Nachruestsatzes,

Bestell- Nummer 220.020.301.31 mit dem VU-Panel erweitert werden.

#### 5.4.1

### Bedienungshinweise

Die beiden VU- Meter zeigen die Leitungs- Ausgangspegel der, mit dem Umschalter (4) angewaehlten Kanaele an.

## Wichtiger Hinweis fuer A80/QC-REPRO mit umschaltbarar PLAY-Bandlaufrichtung:

Die Bandlaufrichtungs- Umschaltung PLAY > - PLAY < hat keinen Einfluss auf die Kanal- Anwahl der VU- Meter;

-> Fig.5.23 Folge: Bei entgegengesetzt zur Modulationsrichtung {<} oder {>} gewaehlter PLAY-Richtung {>} oder
{<} erfolgt die Wiedergabe invers zur Aufnahme</pre> {<>/><}, mit entsprechender Aussteuerungs- Anzeige an den VU-Metern.

Gleichgerichtete Pfeile bedeuten Aufnahme-gerechte Wiedergabe.

### 5.4.2 Abgleich der VU-Meter

### Voraussetzung

Korrekte Einstellung der Audio- Elektronik, nach Kapitel 5.

### Vorbereitung

Brueckenstecker JS1 (VU-METER AMP 1.167.750) auf Position 1 setzen (+6dB).

### Aufnahme/Wiedergabe-Maschinen A80/QC-REC/REPRO

Wahlschalter {4} in Stellung REPRO:

- Maschine mit Testband, im Abschnitt "Bezugspegel", starten.
- (VU-METER AMP 1.167.750): - Potentiometer R2 Abgleich der Anzeige auf o VU.
  Wahlschalter {4} in Stellung INPUT:
  - Leitungspegel in Leitungs-Eingang einspeisen
  - Potentiometer R3 und R4 (MONITOR BOARD

- 1.081.900.81):

Abgleich der Anzeige auf 0 VU.

### Wiedergabe-Maschinen A80/QC-REPRO

Wahlschalter {4} in Stellung CH1+2.

- Maschine mit Testband, im Abschnitt "Bezugspegel" starten.
- (VU-METER AMP 1.167.750): - Potentiometer R2 Abgleich der Anzeige auf 0 VU. Wahlschalter {4} in Stellung CH3+4.
- Maschine mit Testband, im Abschnitt "Bezugspegel" starten.
- Potentiometer R3 und R4 (MONITOR BOARD 1.081.900.00):

Abgleich der Anzeige auf O VU.




Fig.5.23

### 5 AUDIO ELECTRONICS

		page
5.1	GENERAL	5/16
5.1.1 5.1.2	Summary of machine versions Identification of controls	5/16
> 0 1 0 L	and connections	5/17
5.1.3	Measuring instruments and aids	5/17
5.1.4	Important hints	5/18
5.1.5	Checks the audio supply voltages	5/18
5 • 2	REPRODUCE ADJUSTMENT	5/19
5.2.1	Adjusting the level	
30202	of the reproduce amplifier	5/19
5.2.2	Reproduce head azumuth alignment	5/19
5.2.3	Reproduce frequency response	2/1/
	alignment	5/20
5.3	RECORD ADJUSTMENTS	5/21
5.3.1	Check of oscillator frequency	5/21
5.3.2	Record amplifier	-,
	level adjustments	5/21
5.3.3	Record head azimuth alignment	5/22
5.3.4	Bias	5/23
5.3.5	Frequency response alignment	5/24
5.3.6	Crosstalk adjustment	5/25
5 • 4	VU MONITOR	5/27
5.4.1	Operating hints	5/27
5.4.2	Calibration of VU meters	5/27

#### 5.1 GENERAL

#### 5.1.1

Summary of machine versions

### A80/QC-2REPRO

Reproduce-only version with 2 stereo half-track reproduce heads

Audio-Electronics comprising:	-> Fig.5.1
<pre>{1} 4 Reproduce amplifiers   with equalization IEC I/II-IV   1 Reproduce preamplifier 2x2Cm</pre>	1.081.952.81
<pre>(installed in headblock) {2} 1 Line connection panel   (with muting circuit)</pre>	1.020.709.00 1.081.959.00
1 Stabilizer PCB (behind connector panel)	1.080.988.00
<pre>{4} 1 Tacho signal converter {6} 1 Equalization selector</pre>	1.080.979.81 1.081.355.81

### A80/QC-2REC/2REPRO

With full-track record head and stereo half-track reproduce head

Audio electronics comprising: -> Fig.5.2
<pre>{1} 2 Reproduce amplifiers</pre>
(installed in headblock) 1.020.708.00
{2} 1 Line connection panel 1.080.989.00
/1.080.997.00
1 Stabilizer PCB 1.080.988.00
(behind connector panel)
[3] 2 Record amplifiers 1.081.960.81
with equalization IEC I/II-IV 1.081.964.00
[5] 1 Oscillator 1.080.984.00
<pre>{6} 1 Equalization selector 1.081.955.81</pre>

### A80/QC-1REC/2REPRO

With stereo half-track record and reproduce heads.

Audio electronics comprising:	-> Fig.5.3
<pre>{1} 2 Reproduce amplifiers   with equalization IEC I/II-IV   1 Reproduce amplifier 2CH</pre>	1.081.952.81 1.081.965.00
<pre>(installed in headblock) {2} 1 Line connection panel</pre>	1.020.708.00 1.081.989.00 (1.080.997.00
<pre>1 Stabilizer PCB (behind connector panel)</pre>	1.080.988.00
{3} 1 Record amplifier with equalization IEC I/II-IV	1.081.960.81 1.081.964.00
<pre>{5} 1 Oscillator {6} 1 Equalization selector</pre>	1.080.984.00 1.081.955.81




Fig. 5.1




Fig.5.2




Fig. 5.3

## 5.1.2 Identification of controls and connections

The controls for tape in accordance with IEC-I are located on the upper front side of module (inscription FAST)

Reproduce amplifier	REPRO AMP -> Fig.5.4
<pre>{1} Level control {2} Treble control {3} Bass control</pre>	LEVEL TREBLE IEC-I BASS
{4} Crosstalk control	CROSSTALK
<pre>{5} Level control {6} Treble control {7} Bass control</pre>	LEVEL TREBLE IEC-I/IV BASS
Record amplifier	RECORD AMP -> Fig.5.5
<pre>{8} Level control {9} Treble control {10} Bias control</pre>	LEVEL TREBLE IEC-I BIAS
Connection for {11} record current measurement	RECORD CURR
(12) Level control	i EVEI

measurement		
{12} Level control	LEVEL	
{13} Treble control	TREBLE	IEC-I/IV
{14} Bias control	BIAS	
***		

Line connection p	anel	->	Fig. 5.6
{15} Line input	CH1		
{16} Line output	CH1		

- (17) Line input CH2
- {18} Line output CH2
- -> Fig.5.6 Oscillator
- {19} Connector ERASE CURR for erase current measurements

#### 5.1.3 Measuring instruments and aids

- Audio generator AF millivoltmeter (distortion 0,5%)
- (frequency range up to 20kHz)
- Calibration tapes
- 2-channel oscilloscope
- Digital frequency counter
- Frequency analyzer
   (only required for cross-talk alignments)
- Demagnetizing chockeExtender board (audio)Alignment screwdrivers 10.042.002.01 1.080.940




Fig. 5.4




Fig.5.5




Fig. 5.6

# 5.1.4 Important hints

- The recorder must have been switched off for at least 5 seconds before any circuit boards are removed from or inserted into the rack.
- Unlatching the moduls: unfasten the knurled knobs by giving them 1/4 CCW turn.
- Check the supply voltages according to Section 4.2.2 before making any adjustments to the audio electronics.
- Carefully clean and demagnetize the tape guidance elements and the soundheads before proceding with the alignment.

# 5.1.5 Checking the audio supply voltages

#### Important!

Check that the +/-12V stabilization is correct before making any adjustments to the audio electronics •

#### Procedure:

The STABILIZER PCB 1.980.988 becomes accessible after the audio connector panel has been removed (releasing 4 knurled thump screws).

-> Fig.5.7

- Connect DC voltmeter to TP blk (0.0V) and TP red and adjust with trimmer potentiometer R5 to +12V.
- Connect DC voltmeter to TP blk (0.0V) and TP blu and adjust with trimmer potentiometer R11 to  $-12\text{V}_{\bullet}$




Fig.5.7

# 5.2 REPRODUCE ADJUSTMENTS

# 5.2.1 Adjusting the level of the reproduce amplifier

-> Fig.5.8

- Switch recorder on.
- 2. Thread tape and set equalization selector {20} to the position that corresponds to the mounted tape IEC-I or IEC II/IV.
- 3. Connect AF millivoltmeter to line output CH1 {16} (terminate output with 200ohms or 600ohms respectively).
   4. Play "reference level 333Hz" section of
- Play "reference level 333Hz" section of calibration tape.
- 5. Adjust required line level:

  IEC-I module REPROD AMP. CH1

  control LEVEL FAST {1}

  IEC-II/IV module REPROD AMP. CH1

  control LEVEL SLOW {5}
- 6. For 2-channel versions: Adjustments similar to steps 1...5, however on module REPROD AMP. channel CH2.

### 5.2.2 Reproduce head azimuth alignment

The following phase adjustment can be carried out either with a 2-channel scope (section A) or according to the phase method (section B). The method chosen depends on the test equipment available.

# A Test method with 2-channel oscilloscope -> Fig.5.9

- Switch on machine.
- 2. Connect scope to line outputs {16} CH1 and CH2.
- 3. Start test tape with playback at section "azimuth adjustment 10kHz adjustment 10kHz".
- 4. Preadjust the two machine output levels to the same amplitude with controls {2} on REP-ROD AMP modules.
- 5. Align reproduce head with azimuth adjustment knob to maximum output level and minimum phase angle difference between the channels.




Fig. 5.8




Fig. 5.9

#### B Counter phase method

-> Fig.5.9...5.11

- 1. Switch on machine.
- 2. Start test tape with playback at section "azimuth adjustment 10kHz".
- 3. Connect AF millivoltmeter to line output {16} CH1 and then to line output {18} CH2. Preadjust to identical output levels with the corresponding controls {2} TREBLE/IEC-I
- 4. Conect AF millivoltmeter with reversed phases to the two line outputs {16} CH1 and {18} CH2 according to fig. 5.10b
- 5. Align reproduce head with azimuth adjustment screw to minimum reading. Make a note of the difference in level Pd (dB).
- 6. Connect AF millivoltmeter with correct phasing to the two line outputs {16} CH1 and {18} CH2 according to fig. 5.10a.
- 7. Read total level Ps.
- 8. To find the phase angle difference according to fig.5.11 take the difference in level Ps - Pd. The angle of error can be read from the curve.




Fig. 5.9

5.2.3 Reproduce frequency response alignment

-> Fig.5.9

- 1. Switch on machine.
- 2. Thread test tape.
- 3. Connect AF millivoltmeter to line output {16} CH1.
- 4. Start test tape with playback at section "operation level" and check line level.
- 5. Start test tape with playback at section "frequency response".
- 6. Correct treble with control {2} TREBLE on
- REPROD AMP module CH1 at 10kHz.

  7. Correct bass in lower frequency range (100Hz) with control {3} BASS on REPROD AMP module CH1.
- 8. Same procedure for further amplifiers.




Fig.5.10




Fig.5.11

#### 5.3 RECORD ADJUSTMENTS

Whereever the use of blank tape is specified, prerecorded tape can also be used. The recording is erased during the recording process.

### 5.3.1 Check of oscillator frequency

- 1. Switch on machine.
- 2. Connect a digital frequency meter to socket {19} ERASE CURR.
- 3. Thread a blank tape of the required type and start on record.
- 4. Measure the oscillator frequency which should be 150kHz +/- 3kHz. If the frequency lies beyond the tolerance, the oscillator must be adjusted.
- 5. Switch off machine. Take out oscillator module 1.080.984. Insert extension board 1.080.940 and plug oscillator module into extension board.
- 6. Switch on machine and start on record.
- 7. Adjust oscillator coil L2 to 150kHz.
- 8. Switch off machine. Take out extension board. Insert oscillator module in amplifier bay.
- 9. Switch on machine and start on record.
- 10.Check measurement of oscillator frequency. If the frequency of the fitted oscillator module lies beyond tolerance, repeat adjustments 5...7.

# Record amplifier level adjustments

- Switch on machine.
   Connect AF millivoltmeter to line output {16} CH1.
- 3. Connect AF oscillator to line input {15} CHI Frequency: 1kHz
- line level level:
- 4. Thread a blank tape of the required type and start on record.
- 5. Set control {8} resp. {12} LEVEL on RECORD AMP module CH1 to line level.
- 6. With two record channels: Adjust level of channel 2 (CH1) according to steps 1...5 above.




Fig.5.13




Fig.5.14

#### 5.3.3 Record head azimuth alignment

-> Fig.5.15/5.16
The following phase adjustment can be carried out either with a 2-channel scope (section A) or according to the phase method (section B). The method can chosen depends on the test equipment available.

### A Test method with 2-channel oscilloscop

- 1. Switch on machine.
- 2. Connect AF oscillator in parallel to the two line inputs channel 1 {15} and channel 2 {17} (CH1+CH2). Level: 26dB below reference level. Frequency: 1...10kHz.
- 3. Connect 2-channel scope to line outputs channel 1 {16} and channel 2 {18} (CH1+CH2)
- 4. Thread blank tape of the required type and start machine on record.
- 5. Adjust the two machine output levels to the same amplitude (control {9} resp. {13} TREBLE on RECORD AMP modules).
- 6. Adjust record head with azimuth adjusting screw {A} to minimum phase angle difference, starting at lkHz and raising the frequency step by step to 10kHz. (Note: the reading is delayed, therefore, adjust especially slowly).

### B Counter phase method

- 1. Switch on machine.
- 2. Connect AF oscillator to the two line input
   channels 1 {15} and 2 {17} (CH1+CH2)
   Level: 15dB Frequency: 10kHz
- 3. Thread blank tape of the required type and start the machine on record.
- 4. The subsequent measuring and adjusting procedure is carried out according to section 5.2.2 (instead of azimuth adjustment knob, azimuth adjustment screw {A} fig.5.15).

The corresponding controls and connections are: line outputs {16} and {18}, control TREBLE {9} resp. {13}.




Fig. 5.15




Fig.5.16

#### 5.3.4 Bias

When chosing a bias setting a compromise has to be made between distortion, frequency response, modulation noise and modulation level.

Also the bias setting is determined not only by the kind of tape, but to large extend also by the gab width of the recording head.

To adjust the bias, the HF curent is raised (while the AF signal is constant) beyond the maximum output level of the tape in question until the AF output voltage falls by an amount? U.

-> fig.5.17 Bias is adjusted at a modulation frequency of 8kHz. To avoid saturation and incorrect measurements, the input level has to be reducted -26dB below the operating level.

#### Bias

-> Fig.5.17

- 1. Switch on machine.
- 2. Connect AF millivoltmeter to line output channel CH1 {16}.
- 3. Connect AF oscillator to line input channel CH1 {17}. Frequency: 8kHz
- Level: 26dB below operating level. 4. Thread blank tape and start on record.
- 5. Adjust control LEVEL (8) resp. (12) on module RECORD AMP CH1 provisionally so that the AF millivoltmeter indicates 26dB below operating level.
- 6. Turn control BIAS {10} resp. {14} on RECORD AMP module CH1 clockwise from its left stop until AF millivoltmeter shows maximim reading (maximum tape sensitivity). Continue turning AF millivoltmeter clockwise until reading has dropped by -5dB.
- 7. Set AF oscillator to 1kHz and check level adjustment.
- 8. With 2-channel machines:

Adjust bias for channel CH2 according to steps 1...7 above.

The corresponding connections and controls are:

Line input {17}

Line output {18}

### Caution:

The two channels interfere with each other.




Fig.5.17




Fig.5.18

#### 5.3.5 Frequency response alignment

-> Fig.5.19 1. Connect AF oscillator to line input channel CHI {16}. Level: 26dB below operating level Frequency: 10kHz

2. Thread tape and start machine on record.

3. Correct treble with control TREBLE {9} resp. {13} on RECORD AMP modul CH1.

4. Sweep AF oscillator in the lower frequency range (30...100Hz).

5. Correct bass with control BASS {3} resp. {7} on REPROD AMP. modul CH1. Adjust on linear output level.

6. With 2-channels machines: Adjust frequency response for channel CH2 as described in steps 1...5. The corresponding connections are: Line input {17} Line output {18}

#### Checking the overall frequency response

- 1. Switch on machine.
- 2. Connect AF millivoltmeter to line output {16} channel CH1.
- 3. Thread blank tape of required tape.
- 4. Connect AF oscillator to line input {15} channel CH1.
- 5. Start machine on record.
- 6. Sweep AF oscillator across the whole audio range (30 • • • 18000Hz) and note the positive and negative deviations.
- 7. With 2-channel machines: Check frequency response of channel CH2 as describet in steps 1...6. The corresponding connections are: Line input: {17} Line output: {18}

80Hz . . . 12kHz +/-1dB 30Hz • • • 16kHz +1.5dB -3dB 16Hz...18kHz +1.5dB -5dB

### Note

If the frequency response does not lie within guaranteed range, check the following:

- Heads soiled or magnetized.
- Azimuth adjustment of record head not correct
- Record level to high for the type of tape used. Tape is saturated at high frequencies.
- Bias not correctly adjusted or wrong type of tape.
- Treble adjustment not correct.




Fig.5.19

### 5.3.6 Crosstalk adjustment

-> Fig.5.20

- Switch on machine.
- 3. Connect frequency analyser to line output {18} channel CH2.
- 4. Thread blank tape of the required type and start machine on record.
- 5. With control {4} CROSSTALK on REPROD AMP. CH1 adjust crosstalk to give minimum reading on frequency analyser.
- 6. Crosstalk in reverse sequence:
  Connect AF oscillator to line input {17}
  channel CH2, frequency analyser to line
  output {16} channel CH1.
  Adjust crosstalk with control {4} on REPROD
  AMP. module CH2 to give minimum reading on
  frequency analyser (as in steps 2...5).






Fig. 5.20





5.4 VU MONITOR

(OPTION)

-> Fig.5.21/5.22

All standard versions of the ABOQC tape machine can be retrofitted with a VU panel (kit No. 20.020.301.31).

### 5.4.1 Operating hints

The two VU meters display the line output levels of the channels selected with switch {4}.

Important note concerning A80/QC-REPRO with switch-selectable tape direction:

Changing over the tape direction (PLAY>/PLAY<) has no influence on the channel assignment of the VU meters.

-> Fig.5.23 Consequence: If the selected PLAY direction {</>> is opposed to the modulation direction {</>>}, reproduction is inverse to the recording {></</>} with the corresponding output indicated on the  $\ensuremath{\mathsf{VU}}$  meters. Arrows pointing in the same direction indicate that the PLAY direction is the same as the record direction.

#### 5.4.2 Calibration of VU meters

-> Fig.5.21/5.22

Prerequisite

Correct allignment of the audio electronics according to section 5.

Preparatory steps
Set jumper JS1 (VU-METER AMP 1.167.750.00) to position 1 (+6dB).

### Record/reproduce version A80/QC-REC/REPRO

Set selector {4} to REPRO position:

- Play "reference level" section of calibration tape.
- Adjust potentiometer R2 (VU METER AMP 1.167.750.00) to optain a VU Meter reading of 0 VU.

Set selector {4} to input position: - Feed line level into line input.

- Adjust potentiometer R3 and R4
- (MONITOR BOARD 1.081..900.81) to obtain a VU-meter reading of 0 VU.

### Reproduce-only machines A80/QC-REPRO

- Channel selector {4} in position CH1+2 Play "reference level" section of calibration tape.
- Adjust potentiometer R2 (VU METER AMP 1.167.750.00) to obtain a VU-

- meter reading of 0 VU.
  Channel selector {4} in position CH3+4:
   Play "reference level" section of calibration tape.
- Adjust potentiometer R3 and R4 (MONITOR BOARD 1.081.900.00) to obtain a VU-meter reading of 0 VU.




Fig. 5.23

#### 6 VERDRAHTUNG

LAUFWERK-ELEKTRONIK

Bei Geraeten mit umfangreicher Elektronik sind Verdrahtungs-Schaltbilder unuebersichtlich und geben Anlass zu Fehlinterpretationen. Deshalb wurde die zuverlaessigere Methode mit Computer-Verdrahtungslisten gewaehlt. Diese informieren lueckenlos ueber jede Verbindung innerhalb der Laufwerk-Elektronik.

Es wird zwische zwei, zur Verfuegung stehenden Listen unterschieden:

1.LOCATION PIN LIST -> Kap.6.2 Nach Funktionsgruppen (GR) numerisch geordnet. Die Kenntnis der Gruppen-Nummer oder Gruppen-Benennung, gibt Aufschluss ueber

- Aufgliederung in Funktions-Elemente (EL)
- Anschluss- Bezeichning (PT)
- Signal- Namen

2.SIGNAL WIRE LIST -> Kap.6.3 Signal- Namen, alfanumerisch geordnet. Die Kenntnis des Signal- Namens gibt Aufschluss ueber dessen gesamte Signal- Verknuepfungen zwischen den Gruppen (GR) und Elementen (EL), bis hin zur Spezifikation der Anschlusspunkte (PT).

#### 6 WIRING

TAPE TRANSPORT ELECTRONICS

For equipment with complex electronics, wiring diagrams would be difficult to follow and could possibly be missinterpreted.

This is why the more reliable computer wiring lists are used.

These lists provide complete information on each connection within the tape transport electronics.

Two different wiring lists are available:

1.LOCATION PIN LIST -> Section 6.2
Arranged in numeric sequence by group.
The group mumber or group designation provides information concerning.

- Breakdown into function elements (EL)
- Designations of connecting points (PT)
- Signal names.

The **signal name** provides information concerning complete signal gating between the groups (GR) and the elements (EL) up to the specification of the connecting points (PT).

#### GRUPPEN-UEBERSICHT SURVEY OF GROUPS GR01 Netz- Eingangseinheit GRO1 Power input assembly Netz- Einheit GR 02 GR02 Power supply assembly Verbindung Netzteil - Netzschalter Leistungs- Transistoren und Phasenschieber- Kondensatoren GR03 GRO3 Intercon. power supply - mains switch GR 04 GRC4 Power transistors and phase shift capacitors Netzschalter- Einheit GR 0 5 GR05 Power switch assembly GR 06 GR06 GR07 Steuerung Wickelmotor, links GR07 Control unit, supply motor. left SUPPLY MOTOR M1 SUPPLY MOTOR M1 GR 08 Brems- Lueftungsmagnet, links GR08 Brake lift solenoid, left GR09 Brems- Luefytungsmägnet, rechts GR09 Brake lift solenoid, right Control unit spooling motor GR10 Steuerung Wickelmotor, rechts GR10 TAKE-UP MOTOR M2 TAKE-UP MOTOR M2 Bandzug- Steuerung, links GR11 GR11 Tape tension control, left Bandzug- Steuerung, rechts Bandende- Lichtschranke GR12 GR12 Tape tension control, right GR13 GR 13 Tape-end sensor GR14 Bandrichtungs-Sensor GR14 Tape-direction sensor Bandbewegungs-Sensor Tape-move sensor GR15 Andruckaggregat GR15 Tape pressure roller assembly GR16 Capstan-Motoren GR16 Capstan motors

M3 / M6

Tape timer

GR23 Time elapse meter

Local command switches

control unit, cutter control
Tape transport control

Capstan transformer (additional) remot mode control (connection)

GR17

GR18

GR19

GR20

GR21

GR 2 2

M3 / M6

Bandzaehler

Laufwerksteuerung

Capstan- Transformator

Laufwerk- Bedienungstasten, lokal

Steuerung zu EDIT- Betriebsmodus

GR23 Steuerung fuer Betriebsstunden-Zaehler

Anschluss fuer Fernsteuerung

GR17

GR18

GR19

GR 20


GR 21

GR 22

#### 6.2 LOCATION PIN LIST

#### Erklaerung

#### Explanation



#### DRAHTFARBE

0 = schwarz 1 = braun 2 = rot 3 = orange 4 = gelb 5 = gruen 6 = blau

7 = violett 8 = grau 9 = weiss

### SIGNAL NAME

siehe

- rueckseitige Auflistung der Signalnamen

- SIGNAL WIRE LIST


### **VERDRAHTUNGS-POSITION**

farblos (transparent)



auf Wire-Wrap-Stift,
Gueltigkeit bei Anschluss- Typ
"W", exkl. "WT" (TERMI POINT)

### ANSCHLUSS-PUNKT



Numerisch geordnet.
Korrespondiert mit Anschlussbezeichnung auf Schaltbild.
Fuer Printstecker gilt:

.A = Bestueckungsseite

.B = Loetseite

### ANSCHLUSS-TYP

Beispiele: F = MOLEX-Stecker G = Loetstift H = Litze/Draht 6mm, verzinnt K = abisoliert 11 1 = 4mm, verzinnt M = MOLEX Kontaktstift P = Print-Federleiste S = Litze/Draht 4mm, abisoliert, verzinnt T = TERMI POINT (Steckkontakt auf Wire-Wrap-Stift) W = Wire-Wrap-Verbindung

Y = AMP-Flachstecker

WIRE COLOR

0	=	black		(blk)
1	=	brown		(brn)
2	=	red		(red)
3	=	orange		(org)
4	=	yellow		(yel)
5	=	green		(grn)
6	=	blue		(blu)
7	=	violet		(vio)
8	=	grey		(gry)
9	=	white		(wht)
-		colourless	(transp.)	(unc)

### SIGNAL NAME

please refer
- table of signal names
 (on reverse page)
- SIGNAL WIRE LIST

### WIRING POINT

on wire wrap pin,
applicable to connection type
"w", excl. "WT" (TERMI POINT)

### CONNECTION POINT

In numeric sequence.
Corresponds with terminal numbering on the circuit diagram.
Applicable to card edge connectors: ..A = component side
..B = solder side

### CONNECTION TYPE

## SIGNAL-NAMES

-----

AC	alternierend	alternating
ACCEL	beschleunigend	accelerate
AN	analog	analog
В	Laempchen	bulb
BRAKE	Bremse	brake
C	Kondensator	capacitor
CAPLET	Kapstan links	capstan left
CAPRGT	Kapstan rechts	capstan right
CLK	Takt	clock
CUT	editieren (manuell)	edit
CUTAUT	editieren (automatisch)	auto-edit
DIRL	Bandbewegung vorwaerts	tape move direction forward
DIR2	Bandbewegung rueckwaerts	tape move direction reverse
END	Bandende	tape end
EQUAL	Entzerrung	equalizing
F	Sicherung	fuse
FAD	Regler-Start	fader start
FF	Flip-Flop	flip-flop
FL	Filter	filter
FORW	Band Vorspulen	
GRD MAIN	Haupt-Erdung	main ground
GROUND	Masse/Erde	grounding/earthing
IC	Integrierte Schaltung	integrated circuit
INDIC	Signalisations-Lampe	indicator
K	Elektromagnet, Relais	solenoid, relay
LIFT	abheben (Bremsen)	lift brake
LINEL	Netzanschluss: Null-Leiter	power neutral wire
LINE2	Netzanschluss: Phase	power phase wire
LINE3	Schutzerde	safety earth
LOW	niedrige Bandgeschwindigkeit	low tape speed
M1	linker Wickelmotor (SUPPLY)	SUPPLY spooling motor lehe
M2	rechter Wickelmotor (TAKE-UP)	TAKE-UP " " r.h.
		TAILE OF
M3	linker Kapstanmotor (SLAVE)	capstan motor 1.h. (SLAVE)
M4	Bandzaehler	counter
	-1 -> Y-CLK	-1 -> Y-CLK
	-2 -> Y-REVRS	-2 -> Y-REVRS
	-3 -> Y-ICLK	-3 -> Y-ICLK
	-4 -> Y-FORW	-4 -> Y-FORW
M5	(wird nicht benutzt)	(not used)
M6	rechter Kapstanmotor (MASTER)	capstan motor 1.h. (MASTER)
MM	Kapstan-Servo MASTER	capstan servo MASTER
MOVE	(Band-) Bewegung	tape move
MS	Kapstan-Servo SLAVE	capstan servo SLAVE
P	Stecker	plug
PRESS	Andruck (Andruckrolle)	pressure
PS	Impuls	pulse
Q	Transistor	transistor
	-1 = Emiter	-1 = emitter
	-2 = Basis	-2 = base
	-3 = Kollektor	-3 = collector
QP	Foto-Transistor	photo transistor
QPWR	Leistungs-Transistor	power transistor
REC	Aufnahme	recording
R	Widerstand	resistor
REM	Fernsteuerung	remote
REPR	Wiedergabe	reproduce
RESET	Rueckstellen	reset
RP	Foto-Widerstand	photo resistor
S	Schalter (Mikroswitch)	micro switch
J	· · · · · · · · · · · · · · · · · · ·	
	-1 = Gemeinsamer Anschluss	- 1 = common
	-2 = Ruhekontakt	- 2 = closed
CTOD	-3 = Arbeitskontakt	- 3 = open
STOP	Band-Stop	stop (tape)
T	Transformator	transformator
ŢŢ	Bandzug-Regelung	tape tension
Y	Signal	signal

PROFESSIONAL TAPE TRANSPORT DECK \*\* STUDER A 80 Q/C \*\* 1.080.002.00 83/01/26

EL: 02 GROUND POST, EXTERNAL TYPE PT LV SIG.NAME COLOR F X Y L 01 1 GRD MAIN 4/5 EL: 04 MAIN FUSE, TAPE DECK TYPE PT LV SIG-NAME COLOR F X Y 01 2 F-LINE2 1 02 2 LINE2 1 EL: 05 MAINS FILTER TYPE PT LV SIG.NAME COLOR F X Y 01 2 LINE1 6 01' 2 FL-LINE1 6 02 2 FL-LINE2 1 02' 2 FL-LINE2 1 03 2 GRD MAIN 4/5 EL: 08 POWER FEED CONNECTOR, MAINS TYPE PT LV SIG.NAME COLOR F X 1 FL-LINE1 6 1 1 FL-LINE2 1 01 02 03 04 05 06 07 FL-LINE2 1 EL: 09 POWER INPUT CONNECTOR TYPE PT LV SIC-NAME COLOR F X Y

L 01 2 LINE1 6
L 02 2 LINE2 1
L 03 2 GRD MAIN 4/5 EL: 10 GROUND CONNECTOR SCREW TYPE PT LV SIG.NAME COLOR F X LS 01 2 GRD MAIN 4/5

EL: 01 POWER INPUT FEED CONNECTOR TYPE PT LV SIG.NAME COLOR F X Y M 01 1 FL-LINE1 6 02 1 M 03 1 FL-LINE2 1 04 1 M 05 1N GROUND 4/5 EL: 02 VOLTAGE SELECTOR TERMINAL BLOCK TYPE PT LV SIG.NAME COLOR F X Y L 01 3\* S-LINE1 6 L 02 2 T-5 1 L 03 2 T-6 4 L 04 2 T-7 6 L 05 2 T-2 0 L 06 2 T-3 8 L 07 3\* T-4 3 L 08 2\* S-LINE2 1 EL: 03 SCREEN CHASSIS CONNECTION TYPE PT LV SIG.NAME COLOR F X Y LS 01 1 SCREEN 0 EL: 04 POWER TRANSFORMER TYPE PT LV SIG.NAME COLOR F X Y 01 1 S-LINE1 2
02 1 T-2 0
03 1 T-3 8
04 1 T-4 5
05 1 T-5 1
06 1 T-6 4
07 1 T-7
08 1 S-LINE2 9
09 1 SCREEN 0
10 1 T-10 0
11 1 T-11 0
12 1 T-12 2 (5) 18 T-20 T-21 T-22 T-22 T-23 T-24 T-25 T-26 T-27 T-28 T-29 T-30 T-31 EL: 05 RECTIFIER & CONNECTOR PC CARD TYPE PT LV SIG.NAME COLOR F X 

16 17

18 19

5.8

2 Y-CAPLF 2N RES 1' 2\* Y-STOP 2\* S-EQUAL' 2N RES 2' 2\* Y-PRESS 2\* Y-RECORD

TYPE PT LV SIG.NAME COLOR F X 1 O-AC2
1 AC1
1 AC2
1N O-AC3
1N O-AC4
1N AC3
1N AC4
1 T-24
1 T-25
1 T-26
1 T-27
1 T-28
1 T-29 T-29 T-30 T-31 +24.0(1) + 0.0(1) F-M1(0) T-17 T-18 T-20 T-21 F-M2(0) T-23 F-M3(0) F-M3(0) 78 79 80 81 82 83 84 85 10.0(0) -10.0(0) F(- 5.8) T-15 6 +10.0(0) 8 +10.0(0) 8 +10.0(0) 8 + 0.0(4) 0 + 0.0(4) 0 F(+ 5.8) 2 T-13 2 EL: 06 GROUND CHASSIS CONNECTION TYPE PT LV SIG-NAME COLOR F X Y
LS 01 1 GROUND 4/5 EL: 08 POWER SWITCH FEED, RECEPTACLE TYPE PT LV SIG.NAME COLOR F X Y EL: 10 FUSE, SUPPLY MOTOR TYPE PT LV SIG.NAME COLOR F X Y 01 1 F-M1(0) 4 02 1 T-16 4 EL: 11 FUSE, TAKE-UP MOTOR TYPE PT LV SIG.NAME COLOR F X Y 01 1 F-M2(0) 5 02 1 T-19 5 EL: 12 FUSE, CAPSTAN TYPE PT LV SIG.NAME COLOR F X Y 01 1 F-M3(0) 8 02 1 T-22 8 (CONTINUATION) EL: 13

```
GR: 05 1.080.284.00
POWER SWITCH ASSEMBLY
GR: 02 (CONTINUATION)
                                                               EL: 01 TAKE-UP MOTOR CAPACITOR, ADD.
                                                                                                                              EL: 01 POWER SWITCH FEED, JACK
EL: 13 FUSE, - 5.8 V
                                                                                                                              TYPE PT LV SIG.NAME COLOR F X
TYPE PT LV SIG.NAME COLOR F X Y
                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                               L 01 2 M2-2 7
L 02 2 C-M2-2 8
     01 1 F(- 5.8) 6
02 1 T-14 6
EL: 14 FUSE, + 5.8 V
                                                               EL: 03 DC CHASSIS CONNECTION
                                                                                                                              M 04 1 S-LINE2 1
M 05 1 S-LINE1 6
TYPE PT LV SIG.NAME COLOR F X Y
L 01 1 F(+ 5.8) 2
L 02 1 T-12 2
                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                              EL: 02 POWER SWITCH, REAR

TYPE PT LV SIG.NAME COLOR F X Y
                                                               SL 01 1a + 0.0 0
                                                              EL: 04 +24.0 V STABILIZER TRANSISTOR

TYPE PT LV SIG.NAME COLOR F X Y

H 01 1 +24.0 2
H 02 1 QPMR7-2 1
L 03 2D +31.0 9
                                                                                                                                   01 1 FL-LINE1 6
02 1
03 1 S-LINE1 6
EL: 15 FUSE, +24.0 V
TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                              EL: 03 POWER SWITCH, FRONT
                                                                                                                              TYPE PT LV SIG.NAME COLOR F X Y
                                                               EL: 05 TAKE-UP MOTOR TRANSISTOR PAIR
EL: 16 CHARGE CAPACITOR, +24.0 V (1)
                                                                                                                                    01 1 FL-LINE2 1
02 1
03 1 S-LINE2 1
                                                               TYPE PT LV SIG.NAME COLOR F X Y
TYPE PT LV SIG.NAME COLOR F X Y
                                                                   01 2 QPWR2-1 1
02 2 QPWR2-2 4
03 2 QPWR2-3 9
EL: 17 CHARGE CAPACITOR, +24.0 V (2)

TYPE PT LV SIG.NAME COLOR F X Y
                                                               EL: 06 SUPPLY MOTOR CAPACITOR, ADD.
                                                                                                                              GR: 07 1.080.412.00
CONTROL UNIT, SUPPLY MOTOR, CABLE PLUG
                                                               TYPE PT LV SIG.NAME COLOR F X Y
     01 1 +31.0(0) 9
02 1 + 0.0(2) 0
                                                                                                                              EL: 01 SUPPLY MOTOR (M1)
                                                               L 01 2 M1-2 4
L 02 2 C-M1-2 5
EL: 18 CHARGE CAPACITOR, + 5.8 V
                                                                                                                              TYPE PT LV SIG-NAME COLOR F X Y
                                                               EL: 07 CAPSTAN MOTOR CAPACITOR (SLAVE)
                                                                                                                                   01 1 M1-1 1 02 1 03 1 M1-2 4 04 1 05 1 C-M1-2 5
TYPE PT LV SIG.NAME COLOR F X Y
                                                               TYPE PT LV SIG.NAME COLOR F X Y
EL: 19 CHARGE CAPACITOR, - 5.8 V

TYPE PT LV SIG.NAME COLOR F X Y

L 01 2* + 0.0(3) 0
L 02 2* -10.0(0) 6
                                                               EL: 08 +20.0 V STABILIZER TRANSISTOR
                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                               H 01 1 +20.0 3
H 02 1 QPWR6-2 6
L 03 10 +24.0 2
                                                                                                                              GR: 08 1.080.412.00
FEED TO BRAKE LIFT SOLENCID LEFT
EL: 20 CHANNEL FEED CONNECTOR
                                                                                                                              EL: 01 BRAKE LIFT SOLENCID, LEFT
                                                               EL: 09 + 5.8 V STABILIZER TRANSISTOR
TYPE PT LV SIG.NAME COLOR F X Y
                                                               TYPE PT LV SIG.NAME COLOR F X Y
H 01 1 QPWR5-1 5
H 02 1 QPWR5-2 7
L 03 1 QPWR5-3 9
                                                                                                                              TYPE PT LV SIG.NAME COLOR F X
F 01 10 +24.0 2
F 02 1 K-LIFT 3
03 1
     O1 1 Y-CAPLE 1
02 1 Y-STOP 0
03 1 S-EQUAL 3
04 1N RES 1 4
05 1 +24-0(1) 2
06 1 0-AC1 6
07 1 0-AC2 7
08 1N RES 2 7
08 1N RES 2 8
09 1 Y-PRESS 0
                                                               EL: 10 - 5.8 V STABILIZER TRANSISTOR
                                                               TYPE PT LV SIG-NAME COLOR F X Y
         1 Y-PRESS 0
1
1 Y-RECORD 9
                                                               EL: 11 CAPSTAN PWR TRANS. SLAVE MOTOR
                                                                                                                               EL: 01 BRAKE LIFT SOLENOID, RIGHT
                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                              TYPE PT LV SIG.NAME COLOR F X Y

F 01 10 +24.0 2
F 02 1 K-LIFT 3
03 1
                                                                     01 1 QPWR3-1 4
02 1 QPWR3-2 9
03 1 QPWR3-3 7
EL: 12 SUPPLY MOTOR TRANSISTOR PAIR
EL: 01 EXTENSION CABLE, SUPPLY SIDE
                                                               TYPE PT LV SIG.NAME COLOR F X Y
L 01 2 QPHR1-1 2
L 02 2 QPHR1-2 5
L 03 2 QPHR1-3 8
TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                              EL: 13 TAKE-UP MOTOR CAPACITOR, MAIN

TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                               EL: 01 TAKE-UP MOTOR (M2)
                                                                                                                              TYPE PT LV SIG.NAME COLOR F X Y

F 01 1 M2-1 6
02 1
F 03 1 C-M2-2 8
EL: 02 EXTENSION CABLE, SWITCH SIDE
TYPE PT LV SIG.NAME COLOR F X Y
                                                                EL: 14 SUPPLY MOTOR CAPACITOR, MAIN
                                                                                                                                   04 1
05 1 M2-2
                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                                L 01 1 M1-2 4
L 02 1 C-M1-2 5
                                                                EL: 15 CAPSTAN MOTOR CAPACITOR (MASTER)
                                                                                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                               EL: 01 TAPE TENSION CONTROL ASSY, LEFT
                                                                                                                               TYPE PT LV SIG.NAME COLOR F X Y
                                                                EL: 16 CAPSTAN PWR TRANS. MASTER MOTOR
                                                                                                                                 01 10 +20.0

02 1 R-TT1

03 10 + 0.0

04 1 K-TT1/2

05 1 S-TT
                                                               TYPE PT LV SIG.NAME COLOR F X Y
H 01 1 QPHR0-1 4
H 02 1 QPHR0-2 9
L 03 1 QPWR0-3 7
```

```
GR: 12 1.080.412.00
PEED TO TAPE TENSION CONTROL RIGHT
                                                                                                                                              EL: 01 COMMAND SWITCHES, LOCAL
 EL: 01 TAPE TENSION CONTROL ASSY, RIGHT
                                                                                                                                                                                                                                                                                            EL: 01 POWER CONNECTOR PC CARD
 TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                              TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                           TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                             TYPE PT LV SIG.NAME CT

WTL 01 3D + 0.0 0

WTL 02 3D + 0.0 0

WTL 03 3N RES 1 4

HTL 04 3 S-EQUAL 5

WTL 05 3 Y-REC 5

WTL 06 3 K-PRESS 2

WTL 08 3 B-STOP 0

WTL 09 3 Y-CAPLET 1

WTL 10 3

WTL 10 3

WTL 10 5 TMS 5 7
             01 1a +20.0 3
02 1 R-TT2 2
03 1a + 0.0 0
             04 1 K-TT 9
05 1 K-TT1/2 7
                                                                                                                                                                                                                                                                                           MIL 09 3 Y-CAPL MIL 10 3 MTL 11 0 T-MS MTL 12 3 F-M3 MTL 13 3 F-M2 MTL 15 3 F-M2 MTL 16 3* T-M1 MTL 17 3* F-M1 MTL 18 3 MTL 19 3# +31.0 MTL 20 3 +31.0 MTL 22 3 +10.0 MTL 22 3 +24.0 MTL 24 3 +0.0 MTL 25 3 +5.8
GR: 13 1.080.412.00
FEED TO OPTICAL TAPE SENSOR
                                                                                                                                EL: 02 FEED TO TAPE DIRECTION SWITCHES
 EL: 01 OPTICAL TAPE END SENSOR
TYPE PT LV SIG.NAME COLOR F X Y
           01 1 +16.0 3
02 1 +0-END 0
03 1 RP-END 8
04 1
05 1 B-END 7
                                                                                                                                            TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                            F 01 10 + 0.0 0
F 02 10 + 24.0 2
F 03 1 S-CAPLFT 6
F 04 1 B-CAPLFT 9
F 05 1 B-CAPRGT 7
                                                                                                                                                                                                                                                                                            EL: 02 +24/+20/+6/-6V STABIL. PC CARD
 GR: 14 1.080.412.00
FEED TO TAPE MOVE & DIRECTION SENSOR
                                                                                                                                                                                                                                                                                            TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                          TYPE PT LV SIG.NAME CC

HT 01 3 + 0.0
HT 02 3 + 0.0
HT 03 3 QPMR6-2 6
HT 04 3
HT 05 3N +31.0(N)
HT 06 3 +31.0
HT 07 3 QPMR7-2
HT 09 3 +20.0
HT 10 3 +20.0
HT 11 3 +24.0
HT 12 3 +24.0
HT 13 3 S-EQUAL 5
HT 14 3 - 5.8 6
HT 15 3 QPMR7-2
HT 17 3 QPMR4-1
HT 18 3 -10.0
HT 11 3 QPMR4-1
HT 18 3 -10.0
                                                                                                                                             GR: 18 1.080.412.00
FEED TO LOCAL TAPE TIMER
 EL: 01 TAPE MOVE SENSOR
TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                            01 10 +24.0 2

02 10 +5.8 5

03 1 QP-MOVE 4

04 1 +0-MOVE 0

05 1

06 1 B-MOVE 6
                                                                                                                                             EL: 01 TIMER FEED PC-CARD PLUG
                                                                                                                                             TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                         01 10 - 5.8

02 10 + 0.0

03 1 K-RESET

04 10 +24.0

05 1 M4-1

06 1 M4-2

07 1 M4-3

08 1 M4-4

09 10 + 5.8
EL: 02 TAPE DIRECTION SENSOR
TYPE PT LV SIG.NAME COLGR F X Y
            01 1a +24.0 2
02 1a + 5.8 5
03 1 QP-DIR2 7
04 1 +0-DIR1 0
05 1 QP-DIR1 8
06 1 B-DIR 9
                                                                                                                                                                                                                                                                                                        19 3 + 0.0
20 3 + 0.0
21 3 +10.0
                                                                                                                                                                                                                                                                                                      21 3 +10.0

22 3 QPWR5-3 9

22K 0 KEY

23 3 QPWR5-2 7

24 3 QPWR5-1 5

25 3 + 5.8
                                                                                                                                             GR: 19 1.080.412.CO
CONTROL UNIT, CUTTER CONTROL, CABLE PLUG
GR: 15 1.080.412.00
FEED TO PRESSURE ROLLER ASSEMBLY
                                                                                                                                             EL: 01 CUTTER CONTROL ASSEMBLY
                                                                                                                                                                                                                                                                                           EL: 04 CONTACTOR PC CARD
                                                                                                                                             TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                         TYPE PT LV SIG.NAI

TYPE P
                                                                                                                                                                                                                                                                                          TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                            M 01 1 R-CUT-1 5
M 02 1a +20.0 3
F 03 1 R-CUT-3 7
M 04 1 S-CUTAUT 1
M 05 1 +0-CUTAU 0
EL: 01 PRESSURE ROLLER ASSEMBLY
TYPE PT LV SIG.NAME COLOR F X Y
           01 10 +24.0 2
02 1 K-PRESS 8
03 1 Y-ACCEL 6
04 1 K-CUT 5
05 1 S-TT 4
                                                                                                                                                                                                                                                                                                                                                  7
                                                                                                                                                                                                                                                                                           1
 EL: 01 CAPSTAN MOTOR ASSEMBLY M3
TYPE PT LV SIG.NAME COLOR F X Y
            01 1 M3-1 6
02 1 M3-3 1
03 1 M3-2 8
04 1 0YAC1-M3 0
05 1 YAC1-M3 4
                                                                                                                                                                                                                                                                                                                        B-INDIC 9
                                                       6
                                                                                                                                                                                                                                                                                                                3 +24.0
3 - 5.8
3 + 5.8
            06 1
07 1 0YAC2-M3 0
08 1 YAC2-M3 5
EL: 02 CAPSTAN MOTOR ASSEMBLY M6
TYPE PT LV SIG-NAME COLOR F X Y
            01 1 M6-1 6
02 1 M6-3 1
03 1 M6-2 8
04 1 0YAC1-M6 0
05 1 YAC1-M6 4
             06 1
07 1 0YAC2-M6 0
08 1 YAC2-M6 5
                                                                                                                                                                                                                                                                                          EL: 05 (CONTINUATION)
```

# GR: 20 (CONTINUATION) CONTROL UNIT, CARD CHASSIS

```
EL: 09 IC MEMORY & COUNTER PC CARD
                                                                                                                                                                                                                                     EL: 07 (CONTINUATION)
EL: 05 SPOOLING MOTOR CONTROL PC CARD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                            TYPE PT LV SIG.NAME COLOR F X
                                                                                                                                                                                                                                      TYPE PT LV SIG.NAME COLOR F X Y
TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              3 + 0.0
3 + 0.0
3 + 0.0
3 QPWR2-1
3 QPWR2-2
3 B-FORN
3 T-M2
3 QPWR2-3
3 R-TT2
3 Y-ACCEL
3 YBI-MOVE
3 Y-CUTAUT
C KEY
                                                                                                                                                                                                                                                           09A 3 MM-1
10A 3
10B 3 M3-1
11A 3 MS-1
11B 3 M6-1
12A 3 C-MS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     0
                                                                                                                                                                                                                                                            128 3
138 3
138 3
14A 3
14B 3
15A 3
15B 3
16A 3
16B 3
17A 3
                                                                                                                                                                                                                                                                                       Y-REPR
T-MS
S-REPR
QPWRO-2
M6-2
                      10
WT
WT
                      11
12
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               07A 3 YPS-REPR
07B 3 YBI-FF0
08A 3 YPS-F0RW
08B 3 YBI-FF2
09A 3 YPS-REW
09B 3 YBI-FF3
10A 3 YPS-CUT
10B 3 YBI-FF4
11A 3
11B 3 YBI-FAD
12A 3 YPS-CUT
12B 3 QP-DIR1
13A 3N +0-DIR2
13B 3 QP-DIR2
14A 3
14B 3
15B 3
15B 3
16A 3
16A 3
16A 3
16A 3
16A 3
                     12K 0
13 3
14 3
15 3
16 3
17 3
19 3
20 3
21 3
22 3
23 3
24 3
                                                KEY
R-CUT-3 7
                                                R-CUT-3 7
K-LIFT
R-CUT-1 5
R-TT1 1
B-REW
T-M1
YAN-M1
QPWR1-3 8
QPWR1-2 5
QPWR1-2 5
420.0 3
- 5.8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                            WTTTTTTWT
                                                                                                                                                                                                                                                                                      S-CAPRGT 7
QPWR3-2
YTAC-MM
                                                                                                                                                                                                                                                          B-REPR
KEY
                                                                                                                                                                                                                                                                                        S-REC 5
Y-CAPLFT
S-STOP
B-CAPRGT 8
                                                                                                                                                                                                                                                                                      B-CAPLFT 9
YAC-MM-1
+24.0
+24.0
EL: 06 SLAVE CAPSTAN SERVO PC CARD
TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  16A 3 M4-4
16B 3
17A 3N +0-CLK
17B 3N YBI-CLK
18A 3
18B 3 YBI-DIR
19A 3
                     01A 3
01B 3
01B 3
02A 3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                   J 3 N 17A 3N 17B 3N 17B 3N 17B 3N 17B 3N 11BA 3 WI 19B 3 WI 19B 3 WI 20B 3 EV 10B 20K 0 KEV 21B 3 B-R WI 21B 3 B-R WI 21B 3 M4-1 T 22B 3 M4-1 T 22B 3 M4-2 23B 3 +24.0 23B 3 +24.0 24A 3 22A 3 22B 3 +5.8 10 ATTENUATOR
WT
WT
WT
WT
WT
WT
WT
                     018 3
018 3
02A 3
02B 3
02B 3
02K 0
03A 3
03B 3
04A 3
05A 3
                                                  OYAC1-M3 O
                                                                                                                  3
                                               + 0.0
0YAC2-M3 0
KEY
                                                                                                                                                                                                                                      EL: 08 IC DECODER PC CARD
                                                                                                                                                                                                                                       TYPE PT LV SIG.NAME COLOR F
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               K-RESET 1
                                                                                                                                                                                                                                                          WT
WT
WT
WT
WT
WT
                                                 YTAC-MS
                       06A
                       06B
                       07A
07B
                      08A
08B
09A
09B
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       5
                                                YAC-MS-1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                            EL: 10 ATTENUATOR & PREAMP. PC CARD
                                                                                                                                                                                                                                                             08A 3* B-REPR
08B 3 K-CUT
09A 3
09B 3 YBI-FF3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                            TYPE PT LV SIG.NAME COLOR F X Y
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                01A 3 + 0.0
01B 3 + 0.0
02A 3 + 0.0
02B 3 + 0.0
03B 3 + 0.0
03B 3 + 0.0
04B 3 + 0.0
04B 3 + 0.0
04B 3 RP-END
                                                                                                                                                                                                                                                  09A 3
09B 3
09B 3
10B 3
10B 3
10B 3
10B 7

                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       0
                                                                                                                                                                                                                                        WT
WT
                                                 +20.0
                                                                                                                                                                                                                                        WT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              RP-END
Y-REC
Q-MOVE
YBI-REC
YBI-END
K-PRESS
+16.0
B-FAD
YPS-REC
REM-IN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                05A 3
05B 3
06B 3
07A 3
07B 3
08B 3
09B 3
10A 3
11A 3
11B 3
11B 3
12A 3
12B 3
14A 3
15B 3
16B 3
16B 3
17A 3
                       16A 3
16B 3
17A 3
17B 3 F-M3
18A 3
18B 3 MS-1
19A 3
                                                 QPWR3-3 7
                       21A 3
21B 3
22A 3
22B 3
23A 3
23B 3
24A 3
24B 3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              S-CUT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             S-REC*
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              YPS-REPR
FAD-2
Y-REPR
                                                - 5.8
                       25B 3 + 5.8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               YPS-FORW
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                FAD-1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              FAD-1
S-FORW
YPS-MOVE
YPS-REW
KEY
YPS-STOP
  EL: 07 DUAL CAPSTAN DIRECTION PC CARD
 TYPE PT LV SIG.NAME COLOR F X Y
                     01A 3 + 0.0

01B 3 + 0.0

02A 3 + 0.0

02B 3 + 0.0

03A 3 YAC2-M3

03B 3 YAC2-M6

04A 3 YAC1-M6

05A 3 YAC1-M6

05A 3 YAC1-M6

05A 3 S-REC*

06B 3 S-REC*

06B 3 M3-2

07A 3

07B 3 M3-2

08A 3 T-MM+2
                                                                                                                                                                                                                                                                                                                                  5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               S-REW
S-LOW
S-STOP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    19A
19B
20A
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              YPS-CUT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   208 3 YBI-FAD
21A 3N YBI-LOW
21B 3 K-FAD-1 8
22A 3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    22B 3 B-END
                                                    M3-2 8
T-MM+2 9
S-CAPLFT 6
                        07B 3
08A 3
08B 3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                               EL: 10 (CONTINUATION)
```

```
GR: 20 (CONTINUATION)
CONTROL UNIT, CARD CHASSIS
EL: 10 (CONTINUATION)
TYPE PT LV SIG.NAME COLOR F X Y
     23A 3 +24.0 2
23B 3 +24.0 2
24A 3 - 5.8
24B 3 - 5.8
25B 3 + 5.8
25B 3 + 5.8
WT
EL: 12 MASTER CAPSTAN SERVO PC CARD
TYPE PT LV SIG.NAME COLOR F X Y
        01A 3
01B 3 + 0.0
01B 3 OYAC1-M6 0
       018 3 OYACI-M6 O
02A 3 OYACI-M6 O
02B 3 + 0.0
02B 3 OYAC2-M6 O
02K 0 KEY
03A 3
03B 3
04A 3
04B 3
04B 3
05B 3
05B 3
06B 3
07B 3
06B 3
07B 3
07B 3
08B 3
07B 3
08B 3
09B 3
09B 3
10B 3
         10B 3
11A 3
11B 3
         12A 3
12B 3
        138 3

14A 3

14B 3 +20.0

15A 3

15B 3

16A 3

16B 3

17A 3

17B 3

17B 3

18B 3

18B 3

18B 3

18B 3

18B 3
         19A 3
19B 3
        198 3
20A 3
20B 3 QPWRO-3 7
21A 3
21B 3* QPWRO-2 9
22A 3
22B 3 QPWRO-1 4
23A 3
        23A 3
23B 3 +24.0
24A 3
24B 3 - 5.8
25A 3
25B 3 + 5.8
                  +24.0
EL: 13 BUSS BARS, UPPER
TYPE PT LV SIG.NAME COLOR F X Y
                                2
        01 9# +24.0
02 9# + 5.8
EL: 14 BUSS BARS, LOWER
TYPE PT LV SIG.NAME COLOR F X Y
         01 9# + 0.0
02 9# - 5.8
```

EL: 01 TRANSFORMER FOR MASTER CAP.MOTOR

TYPE PT LV SIG.NAME COLOR F X Y

01 0 T-M1 1 0 F-M1 4 03 0 0 04 0 T-MM-1 3 0 05 0 T-MM-2 9 06 0

```
GR: 22 1.080.410.00
MODE CONTROL CONNECTOR, REMOTE

EL: 22 MODE CONTROL CONNECTOR, REMOTE

TYPE PT LV SIG.NAME COLOR F X Y

L 01 1 8-INDIC 9

L 02 1 18-REH 2

L 03 1 8-FORW 3

L 04 1 8-REPR 4

L 05 1 8-STOP 1

L 06 1 8-REC 5

L 07 1 8-CUT 6

L 08 1 8-CAPRG 8

L 09 1 VPS-MOVE 7

L 10 1 8-AD 1

L 11 1 FAC-1 8

L 12 1 3 +24.0 2

L 13 1

L 14 1 B-CAPLFT 9

L 15 1 8-5.8 6

L 16 1 1 8-24.0 2

L 17 1 M4-4 6

L 18 1 3-24.0 2

L 19 1 REM-IN 7

L 20 1 S-REW 2

L 21 1 S-FORW 3

L 22 1 S-REPR 4

L 23 1 S-STOP 1

L 24 1 S-REC 5

L 25 1 S-CUT 6

L 26 1 S-CAPRG 7

L 27 1 S-EQUAL 5

L 28 1 S-CAPLFT 6

L 29 1 FAD-2 9

L 30 1 R-SEST 1

L 34 1 M4-3 5


L 36 18 + 0.0 0
```

#	PINS	PINS	PINS	KEYS	MNTS	DESCRIPTION OF GROUP	PART # OF GR
01	14	6	20	0		POWER INPUT ASSEMBLY POWER SUPPLY ASSEMBLY	
02	158	8	166		18	POWER SUPPLY ASSEMBLY	1.080.322.00
03	8	2	10	0		EXTENSION CABLE, PWR SUPPLY-MAINS SWITCH	
04	37		37	0	15	PWR TRANSISTORS & PHASE SHIFT CAPACITORS	1.080.411.00
05	8	3	11	0	3	POWER SWITCH ASSEMBLY	1.080.284.00
07	3	2	5	0	1	CONTROL UNIT, SUPPLY MOTOR, CABLE PLUG	1.080.412.00
08	2	1	3	0	1		
09	2	1	3	0	1	FEED TO BRAKE LIFT SOLENOID RIGHT	1.080.412.00
10	3	2	5	0	1	FEED TO TAKE-UP MOTOR, CABLE PLUG	1.080.412.00
11	3 5 5	0	5	0 0 0	1	FEED TO TAPE TENSION CONTROL LEFT	
12	5	0	5	0	1	FEED TO TAPE TENSION CONTROL RIGHT	1.080.412.00
13	4	1	5	0	1	FEED TO OPTICAL TAPE SENSOR	1.080.412.00
14	11	1	12	0	2	FEED TO TAPE MOVE & DIRECTION SENSOR	1.080.412.00
15	5	0	5	0	1	FEED TO PRESSURE ROLLER ASSEMBLY	1.080.412.00
16	14	2	16	0 0	2	FEED TO TWO CAPSTAN MOTORS	
17	21	0	21	0	2	FEED TO LOCAL COMMAND SWITCHES	
18	9		9	ō	1	FEED TO LOCAL TAPE TIMER	1.080.412.00
19	5	0	5	0	1	CONTROL UNIT, CUTTER CONTROL, CABLE PLUG	
20	292	116			12	CONTROL UNIT, CARD CHASSIS ADDITIONAL CAPSTAN TRANSFORMER	1.080.349.00
21	4	2	6	0			
22	35	1	36	0	1	MODE CONTROL CONNECTOR, REMOTE	1.080.410.00
23	2	0	2	0	1	FEED TO TIME ELAPSE METER	1.080.410.00
TOT.	647	148	795	9	75	DISTRIBUTED IN 22 GROUPS	
		======	======	====	== ==		

6.3 SIGNAL WIRE LIST

Erklaerung

Explanation



#### ANSCHLUSS-PUNKT

Numerisch geordnet. Korrespondiert mit Anschlussbe-zeichnung auf Schaltbild. Fuer Printstecker gilt: ••A = Bestueckungsseite

••B = Loetseite

#### ELEMENT

mit Benennung

#### **GRUPPE**

siehe - Gruppen-Uebersicht, Kap. 6.1

### ANSCHLUSS-TYP

Beispiele: F = MOLEX-Stecker

G = Loetstift H = Litze/Draht 6mm,

verzinnt abisoliert 4mm, ver-K = " L = "

M = MOLEX Kontaktstift P = Print-Federleiste

S = Litze/Draht

4mm, abisoliert, verzinnt T = TERMI POINT (Steckkontakt auf Wire-Wrap-Stift)

W = Wire-Wrap-Verbindung Y = AMP-Flachstecker

### DRAHTFARBE

0	=	schwarz	(blk)
1	=	braun	(brn)
2	=	rot	(red)
3	=	orange	(org)
4	=	gelb	(yel)
5	=	gruen	(grn)
6	=	blau	(blu)
7	=	violett	(vio)
8	=	grau	(gry)
9	=	weiss	(wht)
-		farblos (transparent)	(unc)
	•	•A = Bestueckungsseite	<del>)</del>
	•	•B = Loetseite	

## SIGNAL NAME

(alphabetisch geordnet) Erklaerung der Abkuerzungen: Siehe rueckseitige Auflistung Beispiel: YBI-DIR Y: Signal / \ Richtung BI: binaer

#### CONNECTION POINT

In numeric sequence. Corresponds with terminal numbering on the circuit diagram. Applicable to card edge connectors: ..A = component side ••B = solder side

#### ELEMENT

with designation

### GROUP

please refer - Survey Of Groups, Section 6.1

### CONNECTION TYPE

F = MOLEX connector G = Solder pin H = Stranded/solid wire, tinned stripped L = tinned

M = MOLEX contact pin

P = Multipin card edge connector

S = Stranded/solide wire 4mm, stripped and tinned T = TERMI POINT (plug contact

on wire wrap pin) W = Wire wrap connection Y = AMP flat-pin terminal

### WIRE COLOR

0 = black	(blk)
1 = brown	(brn)
2 = red	(red)
3 = orange	(org)
4 = yellow	(yel)
5 = green	(grn)
6 = blue	(blu)
7 = violet	(vio)
8 = grey	(gry)
9 = white	(wht)
<ul><li>colourless (transp.)</li></ul>	(unc)
tors:A = component sid	e ,
••B = solder side	
33.33.	

### SIGNAL NAME

```
(in alphabetic order)
For explanation of abbreviations
BI: binary
```

### SIGNAL-NAMES

alternating AC alternierend accelerate ACCEL beschleunigend analog analog AN bulb В Laempchen brake BRAKE Bremse capacitor Kondensator CAPLET Kapstan links capstan left CAPRGT Kapstan rechts capstan right clock CLK Takt editieren (manuell) edit CUT editieren (automatisch) auto-edit CUTAUT tape move direction forward DIR1 Bandbewegung vorwaerts Bandbewegung rueckwaerts tape move direction reverse DIR2 tape end END Bandende equalizing Entzerrung EQUAL Sicherung fuse Regler-Start fader start FAD flip-flop FF Flip-Flop filter FI Filter FORW Band Vorspulen main ground GRD MAIN Haupt-Erdung grounding/earthing GROUND Masse/Erde Integrierte Schaltung integrated circuit ΙC indicator Signalisations-Lampe INDIC solenoid, relay K Elektromagnet, Relais LIFT abheben (Bremsen) lift brake Netzanschluss: Null-Leiter power neutral wire LINE1 power phase wire LINE2 Netzanschluss: Phase LINE3 Schutzerde safety earth niedrige Bandgeschwindigkeit low tape speed LOW linker Wickelmotor (SUPPLY) rechter Wickelmotor (TAKE-UP) SUPPLY spooling motor l.h.
TAKE-UP " " r.h. M1 M2 linker Kapstanmotor (SLAVE) capstan motor 1.h. (SLAVE) M3 Bandzaehler counter M4 -1 -> Y-CLK -2 -> Y-REVRS -1 -> Y-CLK -2 -> Y-REVRS -> Y-ICLK -3 -3 -> Y-ICLK -> Y-FORW -4 -> Y-FORW -4 (not used) M5 (wird nicht benutzt) capstan motor 1.h. (MASTER) rechter Kapstanmotor (MASTER) M6 capstan servo MASTER Kapstan-Servo MASTER MM (Band-) Bewegung Kapstan-Servo SLAVE tape move MOVE capstan servo SLAVE MS Р pluq Stecker PRESS Andruck (Andruckrolle) pressure pulse Impuls PS transistor ۵ Transistor -1 = -2 = emitter -1 = Emiter -2 = Basis base -3 = collector -3 = Kollektor QP Foto-Transistor photo transistor QPWR Leistungs-Transistor power transistor REC Aufnahme recording resistor Widerstand REM remote Fernsteuerung reproduce REPR Wiedergabe RESET Rueckstellen reset Foto-Widerstand photo resistor RP Schalter (Mikroswitch) micro switch S -1 = common-1 = Gemeinsamer Anschluss - 2 = closed - 3 = open -2 = Ruhekontakt -3 = Arbeitskontakt Band-Stop stop (tape) STOP transformator Transformator TT Bandzug-Regelung tape tension Signal signal

PROFESSIONAL TAPE TRANSPORT DECK \*\* STUDER A 80 Q/C \*\* 1.080.002.00 83/01/26 SIG.NAME COLOR TYPE GR EL PT S DESCRIPTION OF ELEMENT SIG.NAME COLOR TYPE GR EL PT S DESCRIPTION OF ELEMENT L 22 22 31 R MGDE CONTROL CONNECTOR, REMOTE RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR +O-TYPE 02 05 38 02 20 06 0-AC1 02 05 19 20 01 22 20 02 21 +10.0 RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR PCWER CCNNECTOR PC CARD +24/+20/+6/-6V STABIL. PC CARD WTL WT +10.0(0) 8 Y 02 05 91 RECTIFIER & CONNECTOR PC CARD 02 05 42 N RECTIFIER & CONNECTOR PC CARD 02 05 92 RECTIFIER & CONNECTOR PC CARD 02 18 01 \* CHARGE CAPACITOR, + 5.8 V + 0.0 OPTICAL TAPE END SENSOR ATTENUATOR & PREAMP. PC CARD +16.0 13 01 01 20 10 07B +20.0 V STABILIZER TRANSISTOR

TAPE TENSION CONTROL ASSY, LEFT

TAPE TENSION CONTROL ASSY, RIGHT

CUTTER CONTROL ASSEMBLY

+24/+20/+6/-6V STABIL. PC CARD

+24/+20/+6/-6V STABIL. PC CARD

CONTACTOR PC CARD

SPODLING MOTOR CONTROL PC CARD

SLAVE CAPSTAN SERVO PC CARD

MASTER CAPSTAN SERVO PC CARD +20.0 11 01 01 12 01 01 19 01 02 20 02 09 3 20 02 10 20 04 17 20 05 23 3 20 12 149 MASTER CAPSTAN SERVU PC CARD

02 05 06 a RECTIFIER & CONNECTOR PC CARD

04 04 01 +24-0 V STABILIZER TRANSISTOR

08 01 01 a BRAKE LIFT SOLENDID, RIGHT

14 01 01 a TAPE MOVE SENSOR

14 02 01 a TAPE DIRECTION SENSOR

15 01 01 a PRESSURE ROLLER ASSEMBLY

17 02 02 a FEED TO TAPE DIRECTION SWITCHES

18 01 04 a TIMER FEED PC-CARD PLUG

20 01 23 POWER CONNECTOR PC CARD

20 02 11 +24/+20/+6/-6V STABIL. PC CARD

20 04 03 CONTACTOR PC CARD

20 07 23A DUAL CAPSTAN DIRECTION PC CARD

20 07 23B DUAL CAPSTAN DIRECTION PC CARD

20 08 23B IC DECODER PC CARD

20 08 23B IC DECODER PC CARD

20 09 23B IC MEMORY & COUNTER PC CARD

20 09 23B IC MEMORY & COUNTER PC CARD

20 09 23B IC MEMORY & COUNTER PC CARD

20 10 23B ATTENUATOR & PREAMP. PC CARD

20 12 23B MASTER CAPSTAN SERVO PC CARD

21 30 1 # BUSS BARS, UPPER

22 22 12 a MODE CONTROL CONNECTOR, REMOTE

23 23 01 a FEED TO TIME ELAPSE METER +24.0 2 2 2 2 2 2 2 2 2 WTL 2 2 2 + 0.0(1) 0 Υ 02 05 59 02 20 05 RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR +24.0(1) 2 RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD CHARGE CAPACITOR, +24.0 V (1) CHARGE CAPACITOR, +24.0 V (2) 02 05 73 02 05 74 02 16 02 02 17 02 + 0.0(2) 0 RECTIFIER & CONNECTOR PC CARD +24.0 V STABILIZER TRANSISTOR POWER CONNECTOR PC CARD POWER CONNECTOR PC CARD +24/+20/+6/-6V STABIL. PC CARD 02 05 17 04 04 03 20 01 19 20 01 20 20 02 06 L L WTL WTL WT +31.0 L 0 RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD \* CHARGE CAPACITOR, - 5.8 V 02 05 81 + 0.0(3) 0 02 05 82 02 19 01 0 L +31.0(N) WT. 20 02 05 N +24/+20/+6/-6V STABIL . PC CARD 02 05 93 RECTIFIER & CONNECTOR PC CARD 02 05 94 RECTIFIER & CONNECTOR PC CARD 02 18 02 \* CHARGE CAPACITOR, + 5.8 V + 0.0(4) 0 +31.0(0) 9 02 05 71 02 05 72 02 16 01 02 17 01 RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD CHARGE CAPACITOR, +24.0 V (1) CHARGE CAPACITOR, +24.0 V (2) ō Ĺ L + 5.8 a TIMER FEED PC-CARD PLUG

24/+20/+6/-6V STABIL. PC CARD

CONTACTOR PC CARD

SPCOLING MOTOR CONTROL PC CARD

B SLAVE CAPSTAN SERVU PC CARD

A LIC DECODER PC CARD

B IC DECODER PC CARD

A ATTENUATOR & PREAMP. PC CARD

MASTER CAPSTAN SERVU PC CARD

MASTER CAPSTAN SERVU PC CARD

MASTER CAPSTAN SERVU PC CARD

# BUSS BARS, LOWER

# MODE CONTROL CONNECTOR, REMOTE 18 01 01 20 02 14 20 04 24 20 06 248 20 06 248 20 07 248 20 08 24A 20 08 24A 20 10 24A 20 10 248 20 12 248 20 14 02 22 22 15 - 5.8 6 RECTIFIER & CONNECTOR PC CARD POWER CONNECTOR PC CARD +24/+20/+6/-6V STABIL PC CARD -10.0 20 01 21 20 02 18 02 05 83 02 05 84 02 19 02 RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD CHARGE CAPACITOR, - 5.8 V 20 09 17A N IC MEMORY & COUNTER PC CARD -10.0(0) 6 +0-CLK Ĺ 19 01 05 20 08 21A CUTTER CONTROL ASSEMBLY IC DECODER PC CARD +O-CUTAU O RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR AC1 02 05 40 02 20 13 6 Y L +0-DIR1 0 TAPE DIRECTION SENSOR
IC MEMORY & COUNTER PC CARD 14 02 04 20 09 12A WT AC2 RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR Y 02 05 41 02 20 14 +0-DIR2 WT 20 09 13A N IC MEMORY & COUNTER PC CARD AC3 6 Υ 02 05 44 N RECTIFIER & CONNECTOR PC CARD OPTICAL TAPE END SENSOR ATTENUATOR & PREAMP. PC CARD +O-END 13 01 02 20 10 04A M WT AC4 02 05 45 N RECTIFIER & CONNECTOR PC CARD +0-MOVE 0 TAPE MOVE SENSOR ATTENUATOR & PREAMP. PC CARD

14 01 04 20 10 03A

SIG.NAME	COLOR	TYPE	GR	EL	PT	s	DESC	RIPTI	ON (	DF E	LEME	NT				SIG.NAME	COLOR	TYPE	GR	EL	PT	s	DESCRIPTION	OF ELI	EMENT	
B-CAPLFT	9 9 9	F WT L	17 20 22	07	22 A		DUAL	TO T CAPS CONT	TAN	DIR	<b>ECTI</b>	ON F	PC C	AR D		FAD-1	8 8	WT L			15A 11		ATTENUATOR MODE CONTRO			
B-CAPRGT	8	.F WT	17 20		05 21A		FEED	TC T	APE	DIR	ECTI	ON S	SWIT	CHES		FAD-2	9 9	WT L			13A 29		ATTENUATOR MODE CONTRO			
B-CUT	8 6 6	P WT WT L	22 17 20	01 08 10	08 02 18A 09B	*	COMM IC D ATTE	AND S ECODE NUATO CONT	ROL WITC R P	CON CHES PC C	NECT , LO ARD AMP.	OR, CAL PC	CAR	C		FL-LINE1	6 6 6 6	Z F M F M	01 02 02 03 03	08 01 08 01 02	01 01 01 01		MAINS FILTE POWER FEED POWER INPUT POWER SWITC EXTENSION C EXTENSION C	CONNECT FEED ( H FEED, ABLE, S ABLE, S	CONNECTO RECEP SUPPLY SWITCH	OR TACLE SIDE
B-DIR	9 9	P WT	14 20		06 06A			DIRE ECODE				R					6	M L		01 02			POWER SWITC POWER SWITC	H FEED.	, JACK R	
B-END	7	F	13	01	05		CPTI	CAL T	APE	END	S EN	SOR				FL-LINE2	1 1	Z F M	01		02' 03		MAINS FILTE POWER FEED POWER INPUT	CONNECT	TOR, MAI	INS
	7	WT			22B			NUATO									1	F M	02 03	08 01	02 02		POWER SWITC EXTENSION C	H FEED, ABLE, S	, RECEPT	TACLE SIDE
B-FAD	1	WT L	20 22		08A 10			CONT									1 1 1	F M L	05	02 01 03	02		EXTENSION C POWER SWITC POWER SWITC	H FEED,	, JACK	SIDE
B-FORW	3 3	P WT WT L	17 20 20 22	05 08	05 13B	#	SPOO IC D	AND SI LING I ECODEI CONTI	MOTO R P	OR CO	ONTR ARD	OL	PC (			GRD MAIN		L		02			GROUND POST	, EXTER		
B-INDIC	9	Р	17	01	01		COMM	AND S	WITC	HES	, LO			012			4/5 4/5 4/5	K L LS	01	05 09 10	03		MAINS FILTE POWER INPUT GROUND CONN	CONNEC		
	9	WT L	20 22	22	01		MODE	CONT	ROL	CONI	NECT	OR,	REMO	OTE		GROUND	4/5 4/5	M LS			05 01		POWER INPUT GROUND CHAS			
B-MOVE	6	P WT	14 20		06 07A			MOVE ECODE								K-BRAKE		WT WT		04	15 18B		CONTACTOR IC DECODER	PC CARE	D	
B-REC	5 5 5	P WT L	17 20 22	09	21A		IC M	AND SI EMORY CONTI	& C	COUNT	TER	PC				K-CUT	5	M WT	15	01	04 08B		PRESSURE RO	LLER AS	SSEMBLY	
B-REPR	4	P WT	17	01			COMM	AND SI	WITC	HES	, LO	CAL				K-DIR	5	wT	20	04	16		CONTACTOR	PC CARE	D	
	4 4	WT L		80	A80	*	IC D	ECODE	R P	C C	ARD					K-FAD-1	8	WT P			20A		IC DECODER COMMAND SWI			
B-REW	2	P WT	17 20					AND SI						CARD		K-LIFT	8	WT F		10 01	218		ATTENUATOR BRAKE LIFT			
	2	WT L	20 22			#	IC D	CONTR	R P	C C	ARD						3	F WT WT	09 20	01 05	02 14		BRAKE LIFT SPOOLING MO IC DECODER	SOLENO:	ID, RIGH NTROL I	4T
B-STOP	0 1 0	L P	17	01	04	a	COMM	IFIER AND SI	WITC	HES	, LO	CAL		ARD			3	G	23	23	02		FEED TO TIM	E ELAPS	SE METER	
	1	WTL WT L	20 20 22	8 0	12B		IC D	R CONI ECODEI CONTI	R P	C C	ARD			OTE		K-PRESS	0 8 0	L M WTL	02 15 20	01	02		RECTIFIER & PRESSURE RO POWER CONNE	LLER AS	SSEMBLY	CARD
C-MM	8	L WT	04 20		02 05A			TAN MO									8	WT WT			15A 07A		IC DECODER ATTENUATOR			CARD
C-MS	8	L WT	04 20		02 12A			TAN MO								K-RESET	1 1 1	P WT + L	20	09	03 20A 33		TIMER FEED IC MEMORY & MODE CONTRO	COUNTE	ER PC	
C-M1-2	5 5 5	L L F	04 04 07	14	02		SUPP	LY MOT	TOR	CAPA	ACIT	OR,	ADD.	N		K-TT	9 9	M WT		01 08	04 22A		TAPE TENSIO			, RIGHT
	5	WT +	20	04	14	#	CONT	LY MOT ACTOR	PC	CAF	RD					K-TT1/2	7 7	M M	11 12	01	05		TAPE TENSIO	N CONTR	ROL ASS'	Y, LEFT Y, RIGHT
Ç-M2−2	8 8 8	L F WT +	04 04 10 20	13 01	02 03		TAKE	-UP MO -UP MO -UP MO ACTOR	OTOR OTOR	CAF	PACI:	ror,	MAI	IN		LINE1	7 6 6	WT +	01	08 05 09	01		IC DECODER MAINS FILTE POWER INPUT	R		
F(+ 5.8)	2 2	L L	02 02					IFIER			ЕСТОІ	R P	,C C	ARD		LINE2	1	L L	01 01	04	02		MAIN FUSE, POWER INPUT			
F(+24.0)	9	L L	02 02		75 01		RECT	IFIER , +24.	& C	ONNI	ECTO	R P	יכ כו	AR D		MM-1		WT WT			09A 18B		DUAL CAPSTA MASTER CAPS	N DIREC	CTION PO	
F(- 5.8)		L L	02	05	85		RECT	IFIER	£ C	ONNE	ECTO	₹ P	'C C/	AR D		MS-1		WT WT	20	06	18B 11A		SLAVE CAPS DUAL CAPSTA	TAN SEF	RVO PC (	CARD
F-LINE2	1 1	L Z	01 01				MAIN	FUSE S FILT	<b>,</b> TA		DECK					M1-1	1	F WT		01 04			SUPPLY MOTO			
F-M1	4 4	L WTL WT L	02 20 20 21	01 04	17 13	*	POWE CONT	IFIER R CCNN ACTOR SFORME	NECT PC	OR CAF	PC ( RD	AR D	)			M1-2	4 4 4	L L F WT	04	06 14 01	01 03		SUPPLY MOTO SUPPLY MOTO SUPPLY MOTO CONTACTOR	R CAPAC R (M1)	CITOR, M	
F-M1(0)	4	L	02	05	61		RECT	IFIER	& C	ONNE	ECTO					M2-1	6	F	10	01	01		TAKE-UP MOT	DR (M2)	)	
F-M2	9	L	02 02 20	05	09		RECT	IFIER	٤ c	ONNE	ECTO			ARD		M2-2	7	WT L	04	01	01		CONTACTOR TAKE-UP MOT	DR CAPA	ACITOR,	
F-M2(0)	9 5	WTL WT L	20 20 02	04	07		CONT.	R CCNI ACTOR IFIER	PC & C	CAR	RD EC T OF			AR D			7 7 7	L F WT		13 01 04	05		TAKE-UP MOTI TAKE-UP MOTI CONTACTOR	OR (M2)	)	MAIN
F-M3	5	Ĭ.	02	11	01		FUSE	, TAKE	E-UP	МОТ	ror					M3-1	6 6	M WT		01 07	01 10B		CAPSTAN MCT DUAL CAPSTAI			
	5	WTL WT	20 20	01	12		POWE	R CONN	NECT	OR	PC (	ARD	)			M3-2	8	M. WT	16 20		03 07B		CAPSTAN MOTO			
F-M3(0)	8	L L	02 02					IFIER , CAPS			EC T OF	R P	C CA	AR D		M3-3	1	M WT	16 20		02 06B		CAPSTAN MOTO			

SIG.NAME	COLOR	TYPE	GR	EL	PT	S	DESCRIPTION OF ELEMENT
M4-1	3 3 3	P WT L	18 20 22	01 09 22	05 22A 34		TIMER FEED PC-CARD PLUG IC MEMORY & COUNTER PC CARD MODE CONTROL CONNECTOR, REMOTE
M4-2	4	P WT	18	01	06 22B		TIMER FEED PC-CARD PLUG IC MEMORY & COUNTER PC CARD
M4-3	5	L P	18	01	07		MCDE CONTROL CONNECTOR, REMOTE TIMER FEED PC-CARD PLUG
	5	WT L	20	09 22	15B 35		IC MEMORY & COUNTER PC CARD MODE CONTROL CONNECTOR, REMOTE
M4-4	6 6	P WT L	18 20 22	01 09 22	08 16A 17		TIMER FEED PC-CARD PLUG IC MEMORY & COUNTER PC CARD MODE CONTROL CONNECTOR, REMOTE
M5-1	9	Y	02	05	69	N	RECTIFIER & CONNECTOR PC CARD
M5-2	9	Υ	02	05	70	N	RECTIFIER & CONNECTOR PC CARD
M6-1	6	M WT	16 20	02 07	01 11B		CAPSTAN MOTOR ASSEMBLY M6 DUAL CAPSTAN DIRECTION PC CARD
M6-2	8	M WT	16 20	02 07	03 15B		CAPSTAN MOTOR ASSEMBLY M6 DUAL CAPSTAN DIRECTION PC CARD
M6-3	1	M WT	16 20	02 07	02 12B		CAPSTAN MOTOR ASSEMBLY M6 DUAL CAPSTAN DIRECTION PC CARD
Q-MCVE		WT WT	20 20	08 10	04B 05B		IC DECCDER PC CARD ATTENUATOR & PREAMP. PC CARD
QP-DIR1	8	P WT	14 20	02 09	05 12B		TAPE DIRECTION SENSOR IC MEMORY & COUNTER PC CARD
QP-DIR2	7 7	P WT	14 20	02 09	03 13B		TAPE DIRECTION SENSOR IC MEMORY & COUNTER PC CARD
QP-MOVE	4	P WT	14 20	01 10	03 03B		TAPE MOVE SENSOR ATTENUATOR & PREAMP. PC CARD
QPWR0-1	4	H WT	04 20	16 12	01 22B		CAPSTAN PWR TRANS. MASTER MOTOR MASTER CAPSTAN SERVO PC CARD
QPWR0-2	9	H WT WT	04 20 20	16 07 12	02 15A 21B	*	CAPSTAN PWR TRANS. MASTER MOTOR DUAL CAPSTAN DIRECTION PC CARD MASTER CAPSTAN SERVO PC CARD
QPWRO-3	, 7 7	L WT	04	16	03 20B	T	CAPSTAN PWR TRANS. MASTER MCTOR MASTER CAPSTAN SERVO PC CARD
QPWR1-1	2 2	L WT	04	12	01		SUPPLY MOTOR TRANSISTOR PAIR SPOOLING MOTOR CONTROL PC CARD
QPWR1-2	5 5	L WT	04 20	12 05	02 21		SUPPLY MCTOR TRANSISTOR PAIR SPOOLING MCTOR CONTROL PC CARD
QPWR1-3	8 8	L WT	04 20		03 20		SUPPLY MOTOR TRANSISTOR PAIR SPODLING MOTOR CONTROL PC CARD
QP WR 2-1	1	L WT			01 03		TAKE-UP MOTOR TRANSISTOR PAIR SPOOLING MOTOR CONTROL PC CARD
QPWR2-2	4 4	L WT			02 04		TAKE-UP MOTOR TRANSISTOR PAIR SPOOLING MOTOR CONTROL PC CARD
QPWR2-3	9 9	L WT		05 05			TAKE-UP MOTOR TRANSISTOR PAIR SPOOLING MOTOR CONTROL PC CARD
QP WR 3-1	4 4	H WT			01 22B		CAPSTAN PWR TRANS. SLAVE MOTOR SLAVE CAPSTAN SERVO PC CARD
QPWR3-2	9 9	H WT WT	20		02 21B 17A		CAPSTAN PWR TRANS. SLAVE MOTOR SLAVE CAPSTAN SERVO PC CARD DUAL CAPSTAN DIRECTION PC CARD
QPWR3-3	7 7	L WT	04 20	11 06	03 20B		CAPSTAN PWR TRANS. SLAVE MOTOR SLAVE CAPSTAN SERVO PC CARD
QPWR4-1		H WT	04 20				- 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
QPWR4-2		H WT	04 20				- 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
		L WT	04 20				- 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
			04 20				+ 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
QP WR 5-2		H WT	04 20				+ 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
QPWR5-3		L WT	04 20				+ 5.8 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
		H WT	04 20				+20.0 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD
	1	H WT WT	04 ( 20 ( 20 (	02	07		+24.0 V STABILIZER TRANSISTOR +24/+20/+6/-6V STABIL. PC CARD +24/+20/+6/-6V STABIL. PC CARD

SIG.NAME	COLOR	TYPE	GR 	EL	PT	s -	DESCRIPTION OF ELEMENT
R-CUT-1	5 5	M WT	19 20	01 05	01 15		CUTTER CENTROL ASSEMBLY SPOOLING MOTOR CONTROL PC CARD
R-CUT-3	7 7	F WT	19 20	01 05	03 13		CUTTER CONTROL ASSEMBLY SPOOLING MOTOR CONTROL PC CARD
R-TT1	1	M WT	11 20	01 05	02 16		TAPE TENSION CONTROL ASSY, LEFT SPGOLING MOTOR CONTROL PC CARD
R-TT2	2 2	M WT WT	12 20 20	01 04 05	02 18 09		TAPE TENSION CONTROL ASSY, RIGHT CONTACTOR PC CARD SPOOLING MOTOR CONTROL PC CARD
REM-IN .	7 7 7	P WT + L	17 20 22	01 10 22	14 09A 19		COMMAND SWITCHES, LOCAL ATTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
RES 1	4 4	L WTL	02 20	05 01		N N	
RES 1º	4	Y L	02 02	05 20	32 04	N N	RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
RES 2	3	L WTL	02 20	05 01	03 07	N	RECTIFIER & CONNECTOR PC CARD POWER CONNECTOR PC CARD
RES 2	8	Y	02 02	05	35 08	N N	RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
RP-END	8	M WT	13	01	03 04B		OPTICAL TAPE END SENSOR ATTENUATOR & PREAMP. PC CARD
S-CAPLFT	6 6	F WT L	17 20 22	02 07 22	03 08B 28		FEED TO TAPE DIRECTION SWITCHES DUAL CAPSTAN DIRECTION PC CARD MODE CONTROL CONNECTOR, REMOTE
S-CAPRGT	7 7 7	F WT L	17 20 22	02 07 22	06 16B 26		FEED TO TAPE DIRECTION SWITCHES DUAL CAPSTAN DIRECTION PC CARD MCDE CCNTROL CONNECTOR, REMOTE
S-CUT	6 6 6	P WT L	17 20 22		13 10B 25		COMMAND SWITCHES, LOCAL ATTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
S-CUT AUT	1	м	19	01	04		CUTTER CONTROL ASSEMBLY
S-EQUAL	5	WT	02	05		a	IC DECODER PC CARD  RECTIFIER & CONNECTOR PC CARD
	5 5 5	WTL WT L	20 20 22	01 02 22			POWER CONNECTOR PC CARD +24/+20/+6/-6V STABIL. PC CARD MODE CONTROL CONNECTOR, REMOTE
S-EQUAL'	3	Y L	02 02	05 20		*	RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
S-FORW	3 3 3	P WT L	17 20 22	01 10 22	10 15B 21		COMMAND SWITCHES, LOCAL ATTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
S-LINE1	6 2 6 6 6 6 6	L F M F M L	02 02 02 03 03 05	02 04 08 01 02 01 02	01 01 05 05 05 05	*	VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER POWER SWITCH FEED, RECEPTACLE EXTENSION CABLE, SUPPLY SIDE EXTENSION CABLE, SWITCH SIDE POWER SWITCH FEED, JACK POWER SWITCH, REAR
S-LINE2	1 9 1 1 1 1	L F M F M L	02 03 03	04 08 01 02	08 08 04 04 04 04	*	VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER POWER SWITCH FEED, RECEPTACLE EXTENSION CABLE, SUPPLY SIDE EXTENSION CABLE, SWITCH SIDE POWER SWITCH FEED, JACK POWER SWITCH, FRONT
S-LOW		WT	20	10	18A	N	ATTENUATOR & PREAMP. PC CARD
S-REC	5 5 5	P WT L	20	01 07 22	19B		COMMAND SWITCHES, LOCAL DUAL CAPSTAN DIRECTION PC CARD MODE CONTROL CONNECTOR, REMOTE
S-REC*		WT WT			06A 11B		DUAL CAPSTAN DIRECTION PC CARD ATTENUATOR & PREAMP. PC CARD
S-REPR	4 4 4	P WT L	20	01 07 22	14B		COMMAND SWITCHES, LOCAL DUAL CAPSTAN DIRECTION PC CARD MODE CONTROL CONNECTOR, REMOTE
S-REW	2 2 2	P. WT L	20	01 10 22	17B		COMMAND SWITCHES, LOCAL ATTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
S-STOP	1 1 1	P WT WT L	20 20		2 0B 1 8 B	*	COMMAND SWITCHES, LOCAL DUAL CAPSTAN DIRECTION PC CARD ATTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
S-TT	4 4 4	M M	11 15	01 01	05 05	#	TAPE TENSION CONTROL ASSY, LEFT PRESSURE ROLLER ASSEMBLY IC DECODER PC CARD
							****

SIG.NAME	COLOR	TYPE	GR	EL	PT	s	DESCRIPTION OF ELEMENT	SIG.NAME	COLOR	TYPE	GR	EL	PT	s	DESCRIPTION OF ELEMENT
SCREEN	0	LS L		03			SCREEN CHASSIS CONNECTION POWER TRANSFORMER	T-4	3 (5)	L			07 04	*	VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER
T-MM-1	3	WT L	20	12	178	В	MASTER CAPSTAN SERVO PC CARD TRANSFORMER FOR MASTER CAP. MOTOR	T-5	1	L	02 02				VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER
T-MM-2	9	L WT	04	15	01	4	CAPSTAN MOTOR CAPACITOR (MASTER) DUAL CAPSTAN DIRECTION PC CARD	T-6	4	L L	02 02				VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER
T-MS	9 7	L			05 21	a	TRANSFORMER FOR MASTER CAP.MOTOR RECTIFIER & CONNECTOR PC CARD	T-7	6	L L	02 02				VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER
	7 7	L WTL WT	20	07 01 07		Δ.	CAPSTAN MOTOR CAPACITOR (SLAVE) POWER CONNECTOR PC CARD DUAL CAPSTAN DIRECTION PC CARD	TEST-B		WT WT			20 158	3	CENTACTER PC CARD IC DECODER PC CARD
T-M1	1		20	01	11 16	*	RECTIFIER & CONNECTOR PC CARD PCWER CONNECTOR PC CARD	Y-ACCEL	6 6	M WT	15 20		03 10		PRESSURE ROLLER ASSEMBLY SPOOLING MOTOR CONTROL PC CARD
	1	WT L	21	01			SPECILING MOTOR CONTROL PC CARD TRANSFORMER FOR MASTER CAP-MOTOR	Y-CAPL F	1	Y L	02 02		31 01		RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
T-M2	6	L WTL WT	20	01	16 14 06		RECTIFIER & CONNECTOR PC CARD PGWER CCNNECTOR PC CARD SPOOLING MOTOR CONTROL PC CARD	Y-CAPLFT	1	L WTL		01	09		RECTIFIER & CONNECTOR PC CARD
T-10	0	L L		04			POWER TRANSFORMER FUSE, +24.0 V	Y-CUT AUT		WT WT	20	05	12		DUAL CAPSTAN DIRECTION PC CARD  SPECULING MOTOR CONTROL PC CARD IC DECODER PC CARD
T-11	0	L L		04			POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	Y-PRESS		Y	02	05			RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
T-12	2 2	L L			12 02		POWER TRANSFORMER FUSE, + 5.8 V	Y-REC	0 5 5	L L WTL	02	05	09 05 05		RECTIFIER & CONNECTOR PC CARD POWER CONNECTOR PC CARD
T-13	2	L L		04	13 96		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	Y-RECORD		WT	20	10	054		ATTENUATOR & PREAMP. PC CARD  RECTIFIER & CONNECTOR PC CARD
T-14	6 6	L L			14 02		POWER TRANSFORMER FUSE, - 5-8 V		9	Ĺ	02	20	11		CHANNEL FEED CONNECTOR  DUAL CAPSTAN DIRECTION PC CARD
T-15	6 6	L L			15 86		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	Y-REPR		WT	20	10	138	3	ATTENUATOR & PREAMP. PC CARD
T-16	4	L L			16 02		POWER TRANSFORMER FUSE, SUPPLY MOTOR	Y-STOP	0	L	02	20	02		RECTIFIER & CONNECTOR PC CARD CHANNEL FEED CONNECTOR
T-17	4	L L			17 62		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	YAC-MM-1		WT WT			22E 09E		DUAL CAPSTAN DIRECTION PC CARD MASTER CAPSTAN SERVO PC CARD
T-17/18	1	Y L			77 78		RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD	YAC-MS-1		WT WT			09 <i>1</i>		SLAVE CAPSTAN SERVO PC CARD DUAL CAPSTAN DIRECTION PC CARD
T-18	5 5	L L			18		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	YAC1-M3	4	M WT			05 04	A	CAPSTAN MOTOR ASSEMBLY M3 DUAL CAPSTAN DIRECTION PC CARD
T-19	5 5	L L			19		POWER TRANSFORMER FUSE, TAKE-UP MOTOR	YAC1-M6	4	M WT			05 048		CAPSTAN MOTOR ASSEMBLY M6 DUAL CAPSTAN DIRECTION PC CARD
T-2	0	L			05		VOLTAGE SELECTOR TERMINAL BLOCK POWER TRANSFORMER	YAC2-M3	5 5	M WT			08 03		CAPSTAN MOTOR ASSEMBLY M3 DUAL CAPSTAN DIRECTION PC CARD
T-20	8	L	02	. 04	20		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	YAC2-M6	5 5	M WT			08 038	3	CAPSTAN MOTOR ASSEMBLY M6 DUAL CAPSTAN DIRECTION PC CARD
T-20/21	6	Y	02	05	79		RECTIFIER & CONNECTOR PC CARD RECTIFIER & CONNECTOR PC CARD	YAN-M1		WT WT			11 19		CONTACTOR PC CARD SPOOLING MOTOR CONTROL PC CARD
T-21	6	L	02	04	21		POWER TRANSFORMER RECTIFIER & CONNECTOR PC CARD	YAN-M2		WT WT			05 07		CONTACTOR PC CARD SPOOLING MOTOR CONTROL PC CARD
T-22	8	L	02	2 04	22		POWER TRANSFORMER	YBI-CLK		WT WT					IC DECODER PC CARD  IC MEMORY & COUNTER PC CARD
T-23	8	L			23		FUSE, CAPSTAN POWER TRANSFORMER	YBI-CUT		WT WT	20	08	058	3	IC DECODER PC CARD IC MEMORY & COUNTER PC CARD
T-24	8	L L	02	2 04	24		POWER TRANSFORMER (ST)	YBI-DIR		WT WT	20	08	191	В	IC DECODER PC CARD IC MEMORY & COUNTER PC CARD
T-25	0	L	02	2 04	25		POWER TRANSFORMER (ST)	YBI-END		WT WT	20	04	19		CONTACTOR PC CARD IC MEMORY & COUNTER PC CARD
T-26	0	L	02	2 04	26		RECTIFIER & CONNECTOR PC CARD POWER TRANSFORMER (ST)	YBI-FAD		WT WT	20	10	06	В	ATTENUATOR & PREAMP. PC CARD  IC MEMORY & COUNTER PC CARD
T-27	1	L	02	2 04	27		POWER TRANSFORMER (ST)	YBI-FF0		WT	20	10	201	В	ATTENUATOR & PREAMP. PC CARD  IC DECODER PC CARD
T-28	2	L	02	2 04	28		POWER TRANSFORMER (ST)	YBI-FF1		WT WT	20	09	071	В	IC MEMORY & COUNTER PC CARD  IC DECODER PC CARD
T-29	2	L	02	2 04	29		POWER TRANSFORMER (ST)	YBI-FF2		WT WT	20	09	05/	A	IC MEMORY & COUNTER PC CARD  IC DECODER PC CARD
T-3	2 8	L	02	2 02	5 5 6		RECTIFIER & CONNECTOR PC CARD  VOLTAGE SELECTOR TERMINAL BLOCK			WT	20	09	08	В	IC MEMORY & COUNTER PC CARD
T-30	8 9	L	02	2 04	30		POWER TRANSFORMER POWER TRANSFORMER (ST)	YBI-FF3		WT	20	09	09	В	IC DECODER PC CARD IC MEMORY & COUNTER PC CARD
T-31	9	Ĺ	02	2 05	31		RECTIFIER & CONNECTOR PC CARD POWER TRANSFORMER (ST)	YBI-FF4		WT	20	09	10	В	IC DECODER PC CARD IC MEMORY & COUNTER PC CARD
, ,,	9	Ĺ			5 5 8		RECTIFIER & CONNECTOR PC CARD	YBI-LOW		WT	20	10	21	A N	ATTENUATOR & PREAMP. PC CARD


SIG.NAME	COLOR	TYPE	GR	EL	PΤ	s	DESCRIPTION OF ELEMENT
YBI-MOVE		WT WT WT	20	8 0	11 03B 05B		SPOOLING MOTOR CONTROL PC CARD IC DECODER PC CARD IC MEMORY & COUNTER PC CARD
YBI-MOV2		WT	20	09	06B	N	IC MEMORY & COUNTER PC CARD
YBI-REC		WT WT			2 2B 0 6 A		IC DECODER PC CARD ATTENUATOR & PREAMP. PC CARD
YPS-CUT		WT WT			1 0A 1 9B		IC MEMORY & COUNTER PC CARD ATTENUATOR & PREAMP. PC CARD
YPS-FORW		WT WT			08A 14B		IC MEMORY & COUNTER PC CARD ATTENUATOR & PREAMP. PC CARD
YPS-MOVE	7 7	WT L			16A 09		ÁTTENUATOR & PREAMP. PC CARD MODE CONTROL CONNECTOR, REMOTE
YPS-REC		WT WT			04A 08B		IC MEMORY & COUNTER PC CARD ATTENUATOR & PREAMP. PC CARD
YPS-REPR		WT	20	09	07A		IC MEMORY & COUNTER PC CARD
		WT	20	10	128		ATTENUATOR & PREAMP. PC CARD
YPS-REW		WT WT			09A 16B		IC MEMORY & COUNTER PC CARD ATTENUATOR & PREAMP. PC CARD
YPS-STOP		WT WT			06A 17A		IC MEMORY & COUNTER PC CARD ATTENUATOR & PREAMP. PC CARD
YTAC-MM		WT WT			17B 04B		CUAL CAPSTAN DIRECTION PC CARD MASTER CAPSTAN SERVO PC CARD
YTAC-MS		WT WT			04B 05B		SLAVE CAPSTAN SERVO PC CARD DUAL CAPSTAN DIRECTION PC CARD
OYAC1-M3	0	M WT			04 01B		CAPSTAN MOTOR ASSEMBLY M3 SLAVE CAPSTAN SERVO PC CARD
OYAC1-M6	0	M. WT	16 20	02 12	04 01B		CAPSTAN MOTOR ASSEMBLY M6 MASTER CAPSTAN SERVO PC CARD
OYAC2-M3	0	M WT			07 02B		CAPSTAN MOTOR ASSEMBLY M3 SLAVE CAPSTAN SERVO PC CARD
OYAC2-M6	0	M WT			07 02B		CAPSTAN MOTOR ASSEMBLY M6 MASTER CAPSTAN SERVO PC CARD

### CONTENTS


Description	Schema Nr.	Section/Page
GENERAL		7
STUDER ELECTRONIC CARDS		7/3
PRESENTATION OF GROUPS		7/5
POWER SUPPLY UNIT	1.080.322	7/6
- RECTIFIER PC	1.080,335 GR2 EL5	
- POWER CONNECTOR PC	1.080.373 GR20 EL1	
TAPE TRANSPORT CONTROL		8
TAPE TRANSPORT CONTROL/BLOCK DIAGRAM		8/3
STABILIZER/TAPE TRANSPORT	1.080.370-81 GR20 EL2	8/5
PRESSURE ROLLER ASSEMBLY	1.080.122 GR15 EL1	8/9
TAPE TENSION CONTROL ASSEMBLIES	1.080.142/1.080.146 GR11/12	8/11
CUTTER CONTROL ASSEMBLY	1,080,311 GR19 EL1	8/13
TAPE MOVE AND DIRECTION SENSOR UNIT	1,080.179 GR14	8/15
CONTACTOR	1.080.381 GR20 EL4	8/19
SPOOLING MOTOR CONTROL	1.080.387 GR20 EL5	8/23
CAPSTAN MOTOR CONTROL DIAGRAM	1.000.507 61125 225	8/27
CAPSTAN SERVO	1.080.371 GR20 EL6 (SLAVE) EL12 (MASTER)	8/28
DUAL CAPSTAN DIRECTION BOARD	1,080,369 GR20 EL7	8/31
DIRECTION SWITCH	1,080,259 GR17 EL2	8/35
IC DECODER AND DRIVER	1,080,391 GR20 EL8	8/37
IC MEMORY AND COUNTER	1.080,393 GR20 EL9	8/41
ATTENUATOR AND PREAMPLIFIER	1,080,396 GR20 EL10	8/45
COMMAND SWITCH BOARD	1.080,275 GR17 EL1	8/49
REMOTE MODE CONTROL	1,555,276 61117 22	8/51
TAPE TIME COUNTER UNIT	1.228.810 GR18	8/53
BASIS BOARD/COUNTER	1.228.812	8/55
COUNTER DECODER	1,228.811	8/59
COUNTER	1,228.813	8/63
DISPLAY	1.228.814	8/63
AUDIO		9
AUDIO BLOCKDIAGRAM 2CH RECORD/REPRODUCE VERS	SION	9/3
AUDIO BLOCKDIAGRAM 2+2CH REPRODUCE VERSION		9/5
BASIS BOARD UNIT/AUDIO A80 QC	1,081,951	9/7
REPRODUCE PREAMPLIFIER/2CH (ONLY A80 QC MKI)	1.020.683	9/9
REPRODUCE PREAMPLIFIER/2+2CH (ONLY A80 QC MKI)		9/13
STABILIZER/AUDIO	1,080,988	9/17
REPRODUCE AMPLIFIER	1.081.952-81	9/19
REPRODUCE EQUALISATION (ONLY A80 QC MKI)	1.081,953/963	9/21
RECORD AMPLIFIER	1.081.960–00/–81	9/23
RECORD EQUALISATION (ONLY A80 QC MKI)	1.081.958/962	9/25
OSCILLATOR	1.080.984	9/27
EQUALISATION CONVERTER BOARD	1.080.979-81	9/31
CONNECTION PANEL/2CH REP/RECORD VERSION	1.080.973/989/997	9/35
CONNECTION PANEL/2+2CH REP. VERSION	1.080.959 (WITH MUTE CIRCUIT)	9/39

### CONTENTS

Description	Schema Nr.	Section
ANNEX		
MODIFIED AND ADDITIONAL CIRCUITS FOR A80 QC M	KII:	
REPRODUCE PREAMPLIFIER 2CH	1,020,708–00	9/4
REPRODUCE PREAMPLIFIER 2+2CH	1.020.709-00	9/4
REPRODUCE EQUALISATION IEC I/II-IV	1.081.965-00	9/4
RECORD EQUALISATION IEC I/II-IV	1.081.964—00	9/4
OPTION FOR A80 QC VU:		
BASIS BOARD / AUDIO A80 QC VU	1.081.950-00	9/4
WIRE HARNESS BACK PANEL / VU+MONITOR PANEL	10.023.170.03	9/5
MONITOR PANEL A80 QC	1.081.900-81	9/5
- MONITOR AMPLIFIER	1.081.908-00	
VU-METER BOARD A80 QC	1.167.750-00	9/5
WIRE HARNESS VU/MONITOR PANEL	10.023.170.01	9/5




#### PRESENTATION OF GROUPS




#### POWER SUPPLY UNIT 1.080.320


#### RECTIFIER PC 1.080.335 GR 2 EL 5



#### POWER CONNECTOR 1.080.373 GR 20 EL 1



#### POWER SUPPLY UNIT 1.080.322




### CONTENTS

Description	Schema Nr.	Section/Page
GENERAL		7
STUDER ELECTRONIC CARDS		7/3
PRESENTATION OF GROUPS		7/5
POWER SUPPLY UNIT	1.080.322	7/6
- RECTIFIER PC	1.080,335 GR2 EL5	
– POWER CONNECTOR PC	1.080.373 GR20 EL1	
TAPE TRANSPORT CONTROL		8
TAPE TRANSPORT CONTROL/BLOCK DIAGRAM		8/3
STABILIZER/TAPE TRANSPORT	1.080.370-81 GR20 EL2	8/5
PRESSURE ROLLER ASSEMBLY	1,080,122 GR15 EL1	8/9
TAPE TENSION CONTROL ASSEMBLIES	1.080.142/1.080.146 GR11/12	8/11
CUTTER CONTROL ASSEMBLY	1,080,311 GR19 EL1	8/13
TAPE MOVE AND DIRECTION SENSOR UNIT	1,080.179 GR14	8/15
CONTACTOR	1.080.381 GR20 EL4	8/19
SPOOLING MOTOR CONTROL	1.080.387 GR20 EL5	8/23
CAPSTAN MOTOR CONTROL DIAGRAM	1.000.307 31120 223	8/27
CAPSTAN SERVO	1.080.371 GR20 EL6 (SLAVE) EL12 (MASTER)	8/28
DUAL CAPSTAN DIRECTION BOARD	1.080.369 GR20 EL7	8/31
DIRECTION SWITCH	1,080,259 GR17 EL2	8/35
IC DECODER AND DRIVER	1.080.391 GR20 EL8	8/37
IC MEMORY AND COUNTER	1,080,393 GR20 EL9	8/41
ATTENUATOR AND PREAMPLIFIER	1.080.396 GR20 EL10	8/45
COMMAND SWITCH BOARD	1,080,275 GR17 EL1	8/49
REMOTE MODE CONTROL	1,000.270 GIII7 LL1	8/51
TAPE TIME COUNTER UNIT	1,228,810 GR18	8/53
BASIS BOARD/COUNTER	1.228.812	
COUNTER DECODER	1.228.811	8/55
COUNTER	1.228.813	8/59 8/63
DISPLAY	1,228,814	8/63
AUDIO	1,220,014	9
AUDIO BLOCKDIAGRAM 2CH RECORD/REPRODUCE VERS	SION	9/3
AUDIO BLOCKDIAGRAM 2+2CH REPRODUCE VERSION	31014	9/5
BASIS BOARD UNIT/AUDIO A80 QC	1.081.951	9/7
	1.020.683	9/9
REPRODUCE PREAMPLIFIER/2+2CH (ONLY A80 QC MKI)		9/13
STABILIZER/AUDIO	1.080.988	9/17
REPRODUCE AMPLIFIER	1.081.952-81	9/19
REPRODUCE EQUALISATION (ONLY A80 QC MKI)	1.081.953/963	9/19
RECORD AMPLIFIER	1,081,960-00/-81	9/23
RECORD EQUALISATION (ONLY A80 QC MKI)	1.081,958/962	9/25
DSCILLATOR	1.080.984	9/27
EQUALISATION CONVERTER BOARD	1.080.979-81	9/31
CONNECTION PANEL/2CH REP/RECORD VERSION	1.080.973/989/997	9/35
JOHN TO FIGURE AND CONTRACT OF THE CONTRACT VEHICLON		5,55


### CONTENTS

Description	Schema Nr.	Section/Pag
ANNEX		
MODIFIED AND ADDITIONAL CIRCUITS FOR A80 QC	NKII:	
REPRODUCE PREAMPLIFIER 2CH	1.020.708-00	9/43
REPRODUCE PREAMPLIFIER 2+2CH	1.020.709-00	9/45
REPRODUCE EQUALISATION IEC I/II—IV	1,081.965-00	9/47
RECORD EQUALISATION IEC I/II—IV	1.081.964-00	9/48
OPTION FOR A80 QC VU :		
BASIS BOARD / AUDIO A80 QC VU	1.081.950-00	9/49
WIRE HARNESS BACK PANEL / VU+MONITOR PANEL	10.023.170.03	9/50
MONITOR PANEL A80 QC	1.081.900-81	9/51
– MONITOR AMPLIFIER	1.081.908-00	
VU-METER BOARD A80 QC	1.167.750—00	9/53
WIRE HARNESS VU/MONITOR PANEL	10.023.170.01	9/54


#### TAPE TRANSPORT CONTROL/BLOCK DIAGRAM A80 QC




# STABILIZER (TAPE TRANSPORT) / BLOCK DIAGRAM 1.080.370-81 GR 20 EL 2



# STABILIZER (TAPE TRANSPORT) 1.080.370-81 GR 20 EL 2




#### STABILIZER (TAPE TRANSPORT) 1.080.370-81 GR 20 EL 2




#### STABILIZER (TAPE TRANSPORT) 1.080.370-81 GR 20 EL 2

IND			PART NO	VALUE		SPECIFICATI	ONS/EQUIVALENT	MI
	C 01	59	.22.3101	100 µF	-10%	12V	EL	
	C 02	59	.22.3101					
	C 03		.25.4221	220 µF	-10%	257	EL	_
	C 04		.22.5470	47 μF	-10%	25V	EL	
_	C 05		.22.5470	100	1.00/	16V	EL	-
-	C 06		.25.3101	100 μF 220 μF	-1.0% -1.0%	40V	EL	-
-	C 08		.25.3221	220 µF	-10%	16V	EL	-
-	C 09		.25.3221	220 µF	-20,0	201		-
						*************		_
	D 01	5 C	.04.0125	1N4448			SI	
	D 02	50	.04.1102	6,8 V	5%	.40W	z	
	D 03		.04.0125	1N4448			SI	_
_	D 04		.04.1120	4,3 V	5%	.40W	Z	_
_	D 05		.04.1123	4,7 V	5% 5%	.40W	z	-
	D 06		0.04.1101	3,9 V 1N4448	5%	.4UW	SI	-
$\vdash$	D 08		0.04.0125	1N4448			SI	_
Н	D 00	30	7.04.0123	INTERIO			0.1	-
Т	Q 01	50	.03.0428	BC107A				
	Q 02		.03.0428	BC107A				
	Q 03		.03.0428	BC107A				
L	Q 04		.03.0307	BC177A				
_	Q 05		.03.0307	BC177A				_
-	Q 06		.03.0428	BC107A				_
_	Q 07 Q 08		0.03.0428	BC140-16				
-	Q 08 Q 09		0.03.0316	BC140-16				
-	Q 10		.03.0315	BC160-16				_
IND	DAT	E	NAME					
<ul><li>(4)</li><li>(3)</li></ul>				EL = Elec	ctrolyt	ic		
IND	POS NO							
-			PART NO	VALUE			ONS/EQUIVALENT	MI
$\dashv$	R 01	58	.01.7102	1 k	10%	.5W	LIN	М
	R 02	58 58	.01.7102	1 k 20 k	10%	.5W		M
-		58 58 57	.01.7102 .01.7203 .41.4332	1 k 20 k 3,3 k		.5W	LIN LIN	M
	R 02 R 03	58 58 57	.01.7102	1 k 20 k	10%	.5W	LIN LIN	M
-	R 02 R 03 R 04 R 05 R 06	58 58 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222	1 k 20 k 3,3 k 5,6 k 680 2,2 k	10%	.5W	LIN LIN	M
	R 02 R C3 R C4 R C5 R C6 R C7	58 58 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470	10%	.5W	LIN LIN	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08	58 58 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k	10%	.5W	LIN LIN	M
	R 02 R C3 R C4 R C5 R C6 R C7 R C8 R C9	58 58 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4102	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k	10%	.5W	LIN LIN	M
	R 02 R C3 R C4 R C5 R C6 R C7 R C8 R C9 R 10	58 58 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4102 .41.4471	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470	10%	.5W	LIN LIN	M
	R 02 R C3 R C4 R C5 R C6 R C7 R C8 R C9	58 58 57 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4102	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k	10%	.5W	LIN LIN	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11	58 58 57 57 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4102 .41.4471 .41.4103	1 k 20 k 3.3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k	10%	.5W .5W .25W	LIN LIN CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14	58 57 57 57 57 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4102 .41.4471 .41.4103 .42.4220 .41.422	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 22	10%	.5W .5W .25W	LIN LIN CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15	58 57 57 57 57 57 57 57 57 57 57 57 57	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.4103 .42.4220 .41.4222 .41.4472	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 4.7 k 1 k 470 10 k 22 2.2 k 22 4.7 k	10%	.5W .5W .25W	LIN LIN CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16	588 588 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4562 .41.4661 .41.422 .41.4471 .41.4472 .41.4103 .42.4220 .41.422 .41.4472 .41.4103 .42.4220 .41.422 .41.4472 .41.422	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 4.7 k 1 k 470 10 k 22 2.2 k 22 4,7 k 22	10% 5% 5% 5%	.5W .5W .25W	LIN LIN CF CF CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17	588 587 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4102 .41.4103 .41.4103 .42.4220 .41.422 .42.4220 .41.4472 .41.4472 .42.4220 .41.4472 .42.4220 .41.4472 .41.4472 .42.4220 .41.4472 .42.4220 .41.4472 .41.4472	1 k 20 k 3.3 k 5.6 k 680 2,2 k 470 1 k 470 10 k 22 2,2 k 22 4,7 k 22 3,9 k	10%	.5W .5W .25W	LIN LIN CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18	588 588 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4362 .41.4661 .41.4222 .41.4671 .41.4472 .41.4103 .42.4220 .41.4222 .41.4472 .41.4473 .42.4220 .41.4473 .42.4220 .41.4473 .43.4323 .43.4323 .44.4473 .44.4473 .44.4473 .45.4323 .46.4323 .47	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 4,7 k 22 4,7 k 22 3,9 k 3,9 k	10% 5% 5% 5%	.5W .5W .25W	LIN LIN CF CF CF CF	) he
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18	588 588 587 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4562 .41.4681 .41.4222 .41.4471 .41.4472 .41.402 .41.4471 .41.403 .42.4220 .41.422 .41.422 .41.423 .41.423 .41.423 .41.420 .39.3901 .39.3901 .39.3901 .41.4101	1 k 20 k 3,3 k 5,6 k 680 4,7 k 1 k 470 10 k 22 2,2 k 22 4,7 k 22 3,9 k 3,9 k 100	10% 5% 5% 5%	.5W .5W .25W	LIN LIN CF CF CF	1 10 10 10 10 10 10 10 10 10 10 10 10 10
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18	588 588 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4392 .41.4562 .41.4661 .41.4661 .41.4671 .41.4472 .41.4103 .42.4220 .41.4471 .41.4103 .42.4220 .41.4472 .41.4472 .41.420 .39.3901 .39.3901 .39.3901 .41.4101	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 4,7 k 22 4,7 k 22 3,9 k 3,9 k	10% 5% 5% 5%	.5W .5W .25W	LIN LIN CF CF CF CF	M
	R C2 R C3 R C4 R C5 R C6 R C7 R C8 R C9 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20 R 21	588 588 577 577 577 577 577 577 577 577	.01,7102 .01,7203 .01,7203 .41,4352 .41,4562 .41,4661 .41,4222 .41,4471 .41,4103 .42,4220 .41,4222 .41,4220 .41,420 .41,42	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 4,7 k 22 4,7 k 22 3,9 k 3,9 k 3,9 k 100	10% 5% 5% 5%	.5W .5W .25W .25W	LIN LIN CF CF CF CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20	588 588 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4392 .41.4562 .41.4661 .41.4661 .41.4671 .41.4472 .41.4103 .42.4220 .41.4471 .41.4103 .42.4220 .41.4472 .41.4472 .41.420 .39.3901 .39.3901 .39.3901 .41.4101	1 k 20 k 3,3 k 5,6 k 680 4,7 k 1 k 470 4,7 k 10 k 22 2,2 k 470 10 k 22 2,2 k 3,9 k 100 100	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W	LIN LIN CF CF CF CF	M
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 10 R 10 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20 R 21 R 21 R 21 R 21 R 20 R 21	588 588 577 577 577 577 577 577 577 577	.01,7102 .01,7203 .01,7203 .41,4312 .41,4562 .41,4661 .41,4621 .41,407	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 10 k 10 k 22 2,2 k 22 4,7 k 22 3.9 k 100 100 100 22 4,7 k 100 100	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W	LIN LIN CF CF CF CF	M
	R 02 R 03 R 04 R 05 R 05 R 07 R 08 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 19 R 20 R 21 R 22 R 23 R 24 R 24 R 25 R 26 R 27 R 27 R 27 R 28 R 29 R 20 R 20 R 20 R 20 R 20 R 20 R 20 R 20	588 588 587 577 577 577 577 577 577 577	.01,7102 .01,7203 .01,7203 .41,452 .41,4562 .41,461 .41,462 .41,471 .41,472 .41,410 .42,4220 .41,422 .41,472 .41,403 .42,4220 .41,422 .41,403 .42,4220 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410 .41,410	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 4.7 k 1 k 470 10 k 22 2.2 k 22 k 4.7 k 22 2.2 k 100 100 24 100 1 k 100	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W	LIN LIN CF CF CF CF	100
	R C2 R C3 R C4 R C5 R C6 R C7 R C6 R C9 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20 R 21 R 22 R 21 R 22 R 23 R 24 R 25 R 26	588 588 587 577 577 577 577 577 577 577	.01,7102 .01,7203 .01,7203 .41,4312 .41,4562 .41,4661 .41,4621 .41,402 .41,402 .41,4103 .42,4220 .42,4220 .42,4220 .42,4220 .41,4102 .41,412 .41,412 .41,412 .41,412 .41,412 .41,412 .41,412 .41,412 .41,412 .41,412 .41,410	1 k 20 k 3.3 k 5,6 k 680 2.2 k 470 1 k 470 10 k 22 2,2 k 4.7 k 22 3.9 k 3.9 k 100 22 4.7 k 100 100 22 4.7 k 100 100 22 4.7 k 22 4.7 k 22 2.2 k 22 2.2 k 22 2.3 k 22 2.3 k 22 2.3 k 22 3.9 k 3.0	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W	LIN LIN CF CF CF CF	
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20 R 21 R 21 R 22 R 23 R 24 R 25 R 26 R 27	588 588 588 587 577 577 577 577 577 577	.01,7102 .01,7102 .01,7203 .41,4332 .41,4562 .41,4562 .41,4614 .41,4614 .41,472 .41,4102 .41,4103 .42,4220 .41,4220 .41,4220 .41,420 .41,421 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4102	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 4.7 k 1 k 470 10 k 22 2.2 k 4.7 k 22 2.2 k 3.9 k 3.9 k 100 100 22 4.7 k 100 100 22 4.7 k 22 2.2 k 3.9 k 3.9 k 3.9 k 4.7 k	10% 5% 5% 5%	.5W .5W .25W	LIN LIN CF CF CF CF	l M
	R C2 R C3 R C4 R C5 R C6 R C7 R C8 R C9 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 19 R 20 R 21 R 21 R 22 R 21 R 24 R 25 R 26 R 27 R 28	588 588 577 577 577 577 577 577 577 577	.01,7102 .01,7203 .01,7203 .41,4323 .41,4562 .41,4662 .41,4671 .41,402 .41,402 .41,402 .41,402 .41,402 .42,4220 .42,4220 .42,4220 .41,422 .41,447 .41,410 .41,	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 22 4,7 k 3,9 k 3,9 k 100 100 22 4,7 k 100 1 k 5,6 k	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W .25W	LIN LIN CF CF CF CF CF	166
	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 10 R 11 R 12 R 13 R 14 R 15 R 16 R 17 R 18 R 19 R 20 R 21 R 21 R 22 R 23 R 24 R 25 R 26 R 27	588 588 577 577 577 577 577 577 577 577	.01,7102 .01,7102 .01,7203 .41,4332 .41,4562 .41,4562 .41,4614 .41,4614 .41,472 .41,4102 .41,4103 .42,4220 .41,4220 .41,4220 .41,420 .41,421 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4102	1 k 20 k 3.3 k 5.6 k 680 2.2 k 470 4.7 k 1 k 470 10 k 22 2.2 k 4.7 k 22 2.2 k 3.9 k 3.9 k 100 100 22 4.7 k 100 100 22 4.7 k 22 2.2 k 3.9 k 3.9 k 3.9 k 4.7 k	10% 5% 5% 5%	.5W .5W .25W .25W .33W .25W .25W .25W .25W .25W	LIN LIN CF CF CF CF	166
IND	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 12 R 13 R 14 R 15 R 16 R 17 R 16 R 17 R 20 R 21 R 22 R 23 R 24 R 25 R 25 R 26 R 27 R 28 R 26 R 27 R 28	588 588 588 588 588 588 588 588 588 588	.01,7102 .01,7102 .01,7203 .41,4332 .41,4562 .41,4562 .41,4621 .41,4222 .41,4102 .41,4103 .42,4220 .41,4220 .41,4220 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4101 .41,4102 .41,4101 .41,42,4220 .11,4471	1 k 20 k 3.3 k 5.6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 4,7 k 22 4,7 k 22 4,7 k 22 4,7 k 22 100 100 22 4,7 k 100 22 4,7 k 22 1 k 470 22 1 k 470 22 1 k 470 22 2 k 4,7 k 22 2 k 4,7 k 22 2 k 4,7 k 22 4,7 k 22 4,7 k 22 4,7 k 20 20 100 100 20 20 1 k 800	10% 5% 5% 5% 5%	.5W .25W .33W .25W .33W .25W .25W .25W .25W .25W .25W	LIN LIN CF CF CF CF CF	166
IND	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 12 R 13 R 14 R 15 R 16 R 17 R 16 R 17 R 20 R 21 R 22 R 23 R 24 R 25 R 25 R 26 R 27 R 28 R 26 R 27 R 28	588 588 588 588 588 588 588 588 588 588	.01.7102 .01.7203 .41.4332 .41.4562 .41.4661 .41.4022 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.402	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 22 4,7 k 20 100 100 1 k 2,2 k 1,0 k 1,0 k 2,0 k 1,0 k 2,0 k 1,0 k 1,0 k 2,0 k 1,0 k 1,0 k 2,0 k 1,0	10% 5% 5% 5% 1% 5%	.5W .5W .25W .33W .25W .25W .25W .25W .25W .25W	LIN LIN CF CF CF CF CF	
<ul><li>(4)</li><li>(3)</li></ul>	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 12 R 13 R 14 R 15 R 16 R 17 R 16 R 17 R 20 R 21 R 22 R 23 R 24 R 25 R 25 R 26 R 27 R 28 R 26 R 27 R 28	588 587 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4562 .41.4661 .41.4022 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.402	1 k 20 k 3.3 k 5.6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 4,7 k 22 4,7 k 22 4,7 k 22 4,7 k 22 100 100 22 4,7 k 100 22 4,7 k 22 1 k 470 22 1 k 470 22 1 k 470 22 2 k 4,7 k 22 2 k 4,7 k 22 2 k 4,7 k 22 4,7 k 22 4,7 k 22 4,7 k 20 20 100 100 20 20 1 k 800	10% 5% 5% 5% 1% 5%	.5W .5W .25W .33W .25W .25W .25W .25W .25W .25W	LIN LIN CF CF CF CF CF	166
IND @ @ @ @	R 02 R 03 R 04 R 05 R 06 R 07 R 08 R 09 R 10 R 12 R 13 R 14 R 15 R 16 R 17 R 16 R 17 R 20 R 21 R 22 R 23 R 24 R 25 R 25 R 26 R 27 R 28 R 26 R 27 R 28	588 587 577 577 577 577 577 577 577 577	.01.7102 .01.7203 .41.4332 .41.4562 .41.4661 .41.4022 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.407 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.401 .41.402	1 k 20 k 3,3 k 5,6 k 680 2,2 k 470 4,7 k 1 k 470 10 k 22 2,2 k 22 4,7 k 20 100 100 1 k 2,2 k 1,0 k 1,0 k 2,0 k 1,0 k 2,0 k 1,0 k 1,0 k 2,0 k 1,0 k 1,0 k 2,0 k 1,0	10% 5% 5% 5% 1% 5%	.5W .5W .25W .33W .25W .25W .25W .25W .25W .25W	LIN LIN CF CF CF CF CF	166


ND	POS NO	PART NO	VALUE	1	SPECIFICATI	IONS/EQUIVALENT	ME
	R 31	57.41.4332	3,3 k	5%	.25W	CF	
	R 32	57.41.4471	470				
	R 33	57.41.4222	2,2 k				
	R 34	57.41.4101	100				
	R 35	57.41.4472	4,7 k				
	R 36	57.41.4152	1,5 k				
	R 37	57.41.4222	2,2 k				
	R 38	57.41.4471	470				
	R 39	57.41.4471	470				
	TP 1	54.01.0010		Jack	2mm	blk	
	TP 2	54.01.0014				yel	
	TP 3	54.01.0012				red	
	TP 4	54.01.0016				blu	
	TP 5	54.01.0015				grn	
ND	DAT	E   VAME	1				
1			CF = Car	bon-Fil	m		
3)							
2							




# TAPE TENSION CONTROL ASSEMBLIES 1.080.142/1.080.146 GR11/12




CUTTER CONTROL ASSEMBLY 1.080.311 GR19 EL1






## TAPE MOVE AND DIRECTION SENSOR UNIT 1.080.179 GR14









TAPE SENSOR 1.080.188-00 (LAYOUT 1.080.187-12)

## TAPE MOVE SENSOR UNIT 1.080.186-00




TAPE DIRECTION SENSOR 1.081.185-01 (LAYOUT 1.081.186-11)



TAPE SENSOR 1.081.187-00 (LAYOUT 1.081.187-11)

TAPE DIRECTION SENSOR UNIT 1.081.185-00



Stk. Bemerkung

#### TAPE MOVE AND DIRECTION SENSOR UNIT 1.080.179 GR14

Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerkung
C 01	59,10,5689	C 6.8 JJ, 20%, 20 V=, TA	1	
		,		
D Cl	50.04.0109	D 1N 4448 AEQUIV., SI	1	
			-	
			-	
Q' C2	50.03.0407	Q BC 109 C, NPN	1	
OP C2	50.03.0407	QP LS 600, NPNSI	1	
Qr Ca	30.03.0455	gr 50 0007		
R CL	57.02.4102	R 1.0 K, 5%, .25 W, CMA	1	
R C2	57.02.5332	R 3.3 K, 10%, .25 W,	1	
R C3	57.02.4103	R 10 K, 5%, .25 W,	1	
			-	
			-	
			+-	-
	-		+	-
			+	
			-	
			-	
			-	
	-		+	-
	+	-	+	-
			+	
	+			
Aenrieru	ngen (1)	(2) (3) (4)		(5)

	ungen 1 18.12.	1		(3)		(4)		(5)
		+					_	
		+					-	-
		_					_	-
		1						
							_	
		+						
		+						
	_	+-						1
	-	+					-	
		+-					-	-
		-					-	-
		+-					-	-
		-					-	-
							_	
K OI	37.41.4330			5747		.,		
R Ol	57.41.4330	R	33	Eq/	25 5	V, CSCH	1	

POSNO PART NO VALUE SPECIFICATIONS COUIVALENT MFR
C 1 59:10.5689 6.8.WF 20 % 20 % TA

D 1 50.04.0109 1 % 4448 AEQUIV. SI

0 1 50.03.0437 810 109 C NIPRE 1
CP 2 50.03.0433 LE 600 NIPRE 1

TAPE MOVE SENSOR 1.080.186-12 (LAYOUT 1.080.186-12)


TAPE SENSOR 1.080.188-00 (LAYOUT 1.080.187-12)


Pos. Bauteil No. Bezeichnung

1 LED 01 50,04.2103 LE-Diode, Infrarot TIL 23 1


TAPE DIRECTION SENSOR 1.081.185-01 (LAYOUT 1.081.186-11)

TAPE SENSOR 1.081.187-00 (LAYOUT 1.081.187-11)





#### CONTACTOR 1.080.381 GR 20 EL 4




#### CONTACTOR 1.080.381 GR 20 EL 4

Pos	Bauteil No.	Bezeichnung	Stk.	Bemerkung
C 01	59.99.0450	C .47 μF 150 V∼ MP	1	
C 02	59.99.0450		1	
C 03	59.99.0450		1	
C 04	59.99.0450	·	1	
C 05	59.10.5470	C 47 µF 20 V TA	1	
C 06	59.10.2220	C 22 µF 6.3 V TA	1	
C 07	59.10.5339	C 3,3 µF 20 V TA	1	
D 01	50.04.0102	D 1 N 914, 1 N 4143 SI	1	
D 02	50.04.0102		1	
D 03	50.04.0102		1	
D 04	50.04.0102		1	
D 05	50.04.0102		1	
D 06	50.04.1506	D 30 V, 1,3 W, Z	1	
D 07	50.04.1506		1	
D 08	50.04.0102	D 1 N 914, 1 N 4143 SI	1	
D 09	50.04.0102		1	
D 10	50.04.0102		1	
			1	
D 11 D 12	50.04.0102		i	
	50.04.0102		1	
D 13	50.04.0102		1	
D 14	50.04.0102			-
D 15	50.04.0102	-	1	
K 01	56.02.0108	K 24 V, 10 A, 4 U,	1	
		0 00 107 3	<u> </u>	
0 01	50.03.0428	Q BC 107 A, NPN	1	
Q 02	50.03.0428		1	
Q 03	50.03.0428		1	
0 04	50.03.0428		1	-
Q 05	50.03.0306	Q BC 178 B, PNP	1	
Q 06	50.03.0428	Q BC 107 A, NPN	1	
Q 07	50.03.0428	Q BC 107 A, NPN	1	
Q 08	50.03.0315	Q BC 160 - 16, Siemens	1	
Q 09	50.03.0480	Q 2 N 5054, NPN	1	auf Kühlblec
Q 10	50.03.0315	Q BC 160 = 16, Siemens	1	
Q 11	50.03.0480	Q 2 N 5054, NPN	1	auf Kühlblec
Q 12	50.03.0428	Q BC 107 A, NPN	1.	
Q 13	50.03.0316	Q BC 140 = 16, Siemens	1	
Q 14	50.03.0336	Q 2 N 5783, BSS 18	1	
Q 15	50.03.0306	Q BC 178 B PNP	1	
Q 16	50.03.0428	Q BC 107 A NPN	1	
0 17	50.03.0306	Q BC 178 B PNP	1	
R Ol	57.41.4223	R 22 K, 5%, .12 W, CSCH	1	
R 02	57.41.4222	R 2,2 K,	1	
R 03	57.41.4471	R 470	1	
R 04	57.41.4471		1	
R 05	57.41.4332	R 3.3 K,	1	
R 06	57.41.4332	R 3.3 K,	1	
R 07	57.41.4102	R 1 K,	1	
R 08	57.41.4273	R 27 K, 5%, .12 W CSCH	1	
R 09	58.01.3502	R 5 K, LIN, .5 W P	1	
R 10	57.41.4822	R 8.2 K, 5%, .12 W, CSCH	1	
			1	
R 11	57.41.4104	R 100 K,	1	
R 12	57.41.4682	11 010 117	1	
R 13	57.41.4222	R 2.2 K,		
R 14	57.41.4332	R 3.3 K,	1	
R 15	57.41.4223	R 22 K,	1	
R 16	57.41.4104	R 100 K,	1	
R 17	57.41.4102	R 1 K,	1.	
R 18	57.41.4222	R 2.2 K, 5%, .12 W, CSCH	1	
R 19	57.41.4222		1	
R 20	57.41.4103	3 10 K,	1	
R 21	57.41.4222	3 2.2 K,	1	
R 22	57.41.4222		1	
	57.41.4472	3 4.7 K,	1	
R 23				
R 23	57.41.4102	R 1 K,	1	


Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerkung
R 25	57.41.4102	R 1 K, 5%, .12 W, CSCH	1	
R 26	57.02.5331	R 330,	1	
R 27	57.02.5102	R 1 K, 10%, .25 W, CMA	1	
R 28	57.02.5682	R 6.8 K,	1	
R 29	57.02.5102	R 1 K,	1	
R 30	57.02.5331	R 330 ,	1	
R 31	57.02.5682	R 6.8 K,	1	
R: 32	57.02.5479	R 4.7 ,	1	
R 33	57.02.5479		1	
R 34	57.02.5479		1	
R 35	57.02.5479		1	
R 36	57.99.0194	R 5.6 , 10%, 10 W, DR	1	erhöht montier
R 37	57.41.4182	R 1.8 K, 5%, .12 W, CSCH	1	
R 38	57.41.4473	R 47 K,	1	
R 39	57.41.4L83	R 18 K,	1	
R 40	57.41.4102	R 1 K, .12 W,	1	
R 41	57.56.4471	R 470, 5%, 4.2 W, DR	1	
R 42	57.41.4102	R 1 K, .12 W, CSCH	1	
R 43	57.41.4109	R 1 ,	1	
R 44	57.41.4102	R 1 K,	1	
R 45	57.41.4100	R 10 ,	1	
R 46	57.41.4472	R 4.7 K,	1	
R 47	57.41.4332	R 3,3 K.	1	
R 48	57.41.4332	·	1	
R 49	57.41.4102	R 1.0 K.	1	
R 50	57.02.5229	R 22 , 10%, .25 W, CMA	1	
TP 01	54.01.0010	Buchse 2 mm, sw	1	
TP 02	54.01.0014	Buchse 2 mm, gb	1	
TP 03	54.01.0019	Buchse 2 mm, ws	1	
TP 04	54.01.0016	Buchse 2 mm, bl	1	
	gen (1)	② 24,1,78 Ju(3) (4)	-	(6)

SECTION 8/22


# SPOOLING MOTOR CONTROL/BLOCK DIAGRAM 1.080.387 GR 20 EL 5



## SPOOLING MOTOR CONTROL 1.080.387 GR 20 EL 5



#### SPOOLING MOTOR CONTROL 1.080.387 GR 20 EL 5




### SPOOLING MOTOR CONTROL 1.080.387 GR 20 EL 5


IND	POS NO	PART NO	VALUE		SPECIFICATIO	NS/EQUIVALENT	MF
	C Ol	59.10.5150	15 U	20%	10V	TA	
	C OZ	59.05.2104	0.1 U	1.0%	100V	PC	
	C 03	59.10.4339	3.3 U	20%	16V	TA	
	C 04	59.10.5150	15 U		10V		
	C 05	59.05.2104	0.1 U	10%	100V	PC	
	C 05	59.10.5229	2.2 U	20%	2 OV	TA	
	C 07	59.10.5229	2.2 U				
		071201022					
	C 09	EO 10 2101	100 U		100		
-		59.10.3101	100 U		100		
-	C 10	59.10.3101	2.2 U		35V		-
-	C 11	59.10.7229			35V		_
-	C 12	59.10.7229	2.2 U				
-	C 13	59.99.0450	0.47 U	10%	150V	MP	
-	C 14	59.99.0450	0.47 U	,			
-							_
-							_
-	D 01	50.04.0125	1 N 4448			SI	
	D 02	50.04.0125	1 N 4448				
	D 03	50.04.0125	1 N 4448				
	D 04	50.04.0125	1 N 4448				
	D 05	50.04.0125	1 N 4448				
	D 05	50.04.0125	1 N 4448				
	D 07	50.04.0125	1 N 4448				
	D OB	50.04.0125	1 N 4448				
	D 03	50.04.0125	1 N 4448				
	D 10	50.04.0125	1 N 4448				
	D 11	50.04.0125	1 N 4448				_
-	D 12	50.04.0125	1 N 4448			SI	-
-				61-7	chrichter	VA.	
-	D 13 D 14	70.01.0226	2A, 280V 2A, 280V		chrichter		-
ND	DATE	70.01.0226 NAME	ZA, 2000	GIGI	SHEIGHTEEL		
(4)	DATE	NAME					
3			-				
			-				
2							
1							
	9.7.76	Nielsen/g					
0	POS NO	PART NO	VALUE		SPECIFICATIO	NS/EQUIVALENT	MF
0				5%	SPECIFICATIO	NS/EQUIVALENT	MF
0	POS NO D 15 D 16	PART NO	120 V 120 V				Mi
0	POS NO D 15	PART NO 50.04.1505	VALUE 120 V				MF
0	POS NO D 15 D 16	PART NO 50.04.1505 50.04.1505	120 V 120 V 120 V 120 V 120 V				ME
0	D 15 D 16 D 17	PART NO 50.04.1505 50.04.1505 50.04.1505	120 V 120 V 120 V				ME
0	D 15 D 16 D 17 D 19	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505	120 V 120 V 120 V 120 V 120 V			Z	MF
0	D 15 D 16 D 17 D 19	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505	120 V 120 V 120 V 120 V 120 V			Z	MF
0	POS NO D 15 D 16 D 17 D 19 D 19	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125	120 V 120 V 120 V 120 V 120 V			Z	MF
0	D 15 D 16 D 17 D 19	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505	120 V 120 V 120 V 120 V 120 V 1 N 4448	5%		Z	MF
0	POS NO D 15 D 16 D 17 D 19 D 19 D 19 Q 01 Q 02	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408	120 V 120 V 120 V 120 V 120 V 120 V 1 N 4448 BC107B	5% NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q O1 Q O2 Q O3	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408	120 V 120 V 120 V 120 V 120 V 1 N 4448 BC107B BC107B	NPN NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 Q O1 Q O2 Q O3 Q O4	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408 50.03.0408	VALUE  120 V  120 V  120 V  120 V  120 V  1 N 4448  BC107B  BC107B  BC107B  BC107B	NPN NPN NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 Q O1 Q O2 Q O3 Q O4 Q O5	PART NO 50. 04.1505 50. 04.1505 50. 04.1505 50. 04.1505 50. 04.1505 50. 04.0125 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408	120 V 120 V 120 V 120 V 120 V 1 N 4448 BC107B BC107B BC107B BC107B BC107B	NPN NPN NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 19 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 05	PART NO 50. 04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	DECIOTS BC107B	NPN NPN NPN NPN NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 19 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 05 Q 07	PART NO 50. 04.1505 50. 04.1505 50. 04.1505 50. 04.1505 50. 04.0125 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408 50. 03.0408	DECOTE BECOTE BE	NPN NPN NPN NPN NPN NPN NPN NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03	PART NO 50: 04:1505 50: 04:1505 50: 04:1505 50: 04:1505 50: 04:0125 50: 03:0408 50: 03:0408 50: 03:0408 50: 03:0408 50: 03:0408 50: 03:0408 50: 03:0408 50: 03:0408	VALUE   120 V   120 V   120 V   120 V   120 V   1 N 4448   BC107B   BC107	NPN		Z	Mi
0	POS NO D 15 D 16 D 17 D 19 D 19 D 19 Q 01 Q 02 Q 03 Q 03 Q 04 Q 05 Q 05 Q 05 Q 07 Q 03	50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	VALUE 120 V 120 V 120 V 120 V 120 V 1 N 4448  BC107B	NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 19 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03 Q 07 Q 03	PART NO 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	DALUE 120 V 120 V 120 V 120 V 120 V 1 N 4448 BC107B	NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 05 Q 07 Q 03 Q 09 Q 10 Q 11	50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	VALUE   120 V   1 N 4448   BC107B	NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03 Q 09	50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125  50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	DALUE 120 V	NPN		Z	Mi
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 05 Q 07 Q 03 Q 09 Q 10 Q 11	50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	VALUE   120 V   1 N 4448   BC107B	NPN		Z	All
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03 Q 09	50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.1505 50.04.0125  50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408 50.03.0408	DALUE 120 V	NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03 Q 07 Q 07 Q 08 Q 10 Q 11 Q 12 Q 12 Q 13	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1005 50, 04, 0408 50, 03, 0408	DALUE 120 V	NPN		Z	Mi
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 05 Q 07 Q 03 Q 07 Q 03 Q 09 Q 10 Q 11 Q 12 Q 13	PART NO 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 0125 50, 03, 0408 50, 03, 0408	VALUE   120 V   1 N 4448   BC107B	NPN		Z	MF
0	POS NO D 15 D 16 D 17 D 18 D 19 D 19 Q 01 Q 02 Q 03 Q 04 Q 05 Q 05 Q 07 Q 03 Q 07 Q 07 Q 08 Q 10 Q 11 Q 12 Q 12 Q 13	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1005 50, 04, 0408 50, 03, 0408	DALUE 120 V	NPN		Z	MF
0	POS NO   D   15   D   16   D   17   D   18   D   19   D   19   D   19   D   19   D   19   D   10   D	PART NO 50, O.4, 1505 50, O.4, 1505 50, O.4, 1505 50, O.4, 1505 50, O.4, 1505 50, O.4, 0125 50, O.4, 0125 50, O.3, 0408 50, 0408 50	DALUE 120 V 120 V 120 V 120 V 120 V 1 N 4448 BC107B BC107T BC107B	NPN	1.3%	ST	MF
0	POS NO D 15 D 16 D 17 D 18 D 17 D 18 D 19	50, 03, 0408 50, 03, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1025 50, 03, 0408 50, 0	VALUE   VALU	NPN		Z	ME
0	POS NO 1 D 15 D 16 D 17 D 16 D 17 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 0505 50, 04, 0605 50, 03, 0408 50, 04, 0408 50, 04, 0408 50, 04, 0408 50, 0	NALUE   120 V   120	NPN	1.3%	ST	MF
0	POS NO 1 15 1 15 1 15 1 15 1 15 1 15 1 15 1	50, 03, 0408 50, 03, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 04, 0408 50, 0408	VALUE   VALU	NPN	1.3%	ST	MI
0	POS NO 1 D 15 1 D 16 D 17 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 0408 50, 03, 0408 50, 04, 1400	VALUE   120 V   120	NPN	1.3%	ST	1 Million
0	POS NO D 15 D 16 D 17 D 19	PART NO 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 0408 50, 03, 0408 50, 04, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50,	VALUE   VALU	NPN	1.3%	ST	MI
O	POS NO 1 D 15 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 03, 03, 0408 50, 03, 03, 03, 03, 03, 03, 03, 03, 03, 0	VALUE   120 V   120	NPN	1.3%	ST	) All
NND	POS NO D 15 D 16 D 17 D 19	PART NO 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 0408 50, 03, 0408 50, 04, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50, 0408 50,	VALUE   VALU	NPN	1.3%	ST	M
ND ND	POS NO 1 D 15 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 03, 03, 0408 50, 03, 03, 03, 03, 03, 03, 03, 03, 03, 0	VALUE   VALU	NPN	1.3%	ST	
ND ND @ @	POS NO 1 D 15 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 03, 03, 0408 50, 03, 03, 03, 03, 03, 03, 03, 03, 03, 0	VALUE   VALU	NPN	1.3%	ST	MI
NND ND O	POS NO 1 D 15 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 03, 03, 0408 50, 03, 03, 03, 03, 03, 03, 03, 03, 03, 0	VALUE   VALU	NPN	1.3%	ST	M
ND ND O	POS NO 1 D 15 D 16 D 17 D 18 D 19	50, 03, 0408 50, 03, 0408 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1505 50, 04, 1015 50, 04, 1015 50, 03, 0408 50, 03, 03, 0408 50, 03, 03, 03, 03, 03, 03, 03, 03, 03, 0	VALUE   120 V   1 N 4448   8 El07B	NPN	1.3%	ST	MF

ID POS NO	PART NO	VALUE	SPECIFICATIO	NS/EQUIVALENT	MF
R 07	57.41.4471	470	5% .12W	CSCH	
R 08	57.41.4332	3.3 k			
R 09	57.41.4332	3.3 k			
R 10	57.41.4471	470			
R 11	57.41.4682	6,8 k			
R 12	57.41.4682	6.8 k			
R 14	57.41.4101	100			
R 15	57.41.4682	6.8 k			
R 16	57.41.4332	3.3 k			
R 17	57.41.4101	100			
R 18	57.41.4103	10 k			
R 19	57.41.4472	4.7 k			
R 20	57.41.4472	4.7 k			
R 21	57.41.4153	15 k			
R 22	57.41.4102	1.0 k			
R 23	57.41.4102	1.0 k			
R 24	57,41,4123	12 k			
R 25	57.41.4682	6.8 k			
R 26	57.41.4562	5.6 k			
R 27	57.41.4562	5.6 k			
R 28	57.41.4682	6.8 k			
R 29	57.41.4103	10 k			
R 30	57.41.4332	3.3 k			
R 31	57.41.4682	6.8 k			
R 32	57.41.4682	6.8 k			
R 33	57.41.4332	3.3 k			
R 34	57.41.4103	10 k			
R 35	57.41.4471	470			
R 36	57.41.4221	220			
		1			
0 3 2 0					
9 3 2 0 9.7.7	5 Nielsen/G				
9 9.7.70	5 Nielsen/c	VALUE		NS/EQUIVALENT	ME
9 9.7.70 10 POS NO	5 Nielsen/c PART NO 57.41.4471	VALUE 470	SPECIFICATIO 5% .12W		MF
9 9.7.70 10 POS NO R 37 R 38	5 Nielsen/c PARTNO 57.41.4471 57.41.4471	470 470			ME
9 9.7.70  10 9.7.70  10 POS NO  10 R 37  10 R 38  10 R 39	5 Nielsen/c PARTNO 57.41.4471 57.41.4473	470 470 470 47 k			MF
9 9.7.79 D 9.7.79 D POS NO R 37 R 38 R 39 R 40	Nielsen/ PARTNO 57.41.4471 57.41.4473 57.41.4473	470 470 470 47 k 47 k			ME
9 9.7.7 10 9.7.7 10 POS NO R 37 R 38 R 39 R 40 R 41	5 Nielsen/c PARTNO 57.41.4471 57.41.4471 57.41.4473 57.41.4473	470 470 470 47 k 47 k 47 k			MF
① 9.7.7. D POS NO R 37 R 38 R 39 R 40 R 41 R 42	5 Nielsen/ PART NO 57.41.4471 57.41.4473 57.41.4473 57.41.4473 57.41.4473	470 470 470 47 k 47 k 47 k 47 k			MF
9 9.7.70 POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43	5 Nielsen/c PART NO 57.41.4471 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473	470 470 470 47 k 47 k 47 k 47 k 47 k			MF
9 9.7.70 POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44	5 Nielsen/6 PART NO 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473	470 470 470 47 k 47 k 47 k 47 k 47 k 330 820			MF
① 30 20 20 20 20 20 20 20 20 20 20 20 20 20	5 Nielsen/c PARTNO 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4321 57. 41.4821	470 470 47 k 47 k 47 k 47 k 47 k 330 820 3.9 k			MF
① 9.7.7· DO POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46	5 Nielsen/ PART NO 57.41.4471 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4331 57.41.4331 57.41.4321 57.41.4325	470 470 47 k 47 k 47 k 47 k 47 k 330 820 3.9 k 15 k			ME
9 9.7.7. DP POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47	PARTNO 57, 41, 4471 57, 41, 4471 57, 41, 4471 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4331 57, 41, 4321 57, 41, 4321 57, 41, 4352 57, 41, 4152	470 470 47 k 47 k 47 k 47 k 330 820 3.9 k 15 k			MF
① 9.7.70 D POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 44 R 45 R 46 R 47 R 48	PART NO 57. 41.4471 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4821 57. 41.4821 57. 41.4152 57. 41.4152	470 470 47 k 47 k 47 k 47 k 330 820 3.9 k 1.5 k 3.9 k			ME
9 9.7.7 D POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47 R 48	5 Nielsen, PANT NO. 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4331 57. 41.4331 57. 41.4331 57. 41.4352 57. 41.4152 57. 41.4152 57. 41.4152 57. 41.4152	470 470 470 47 k 47 k 47 k 47 k 330 820 3.9 k 15 k 1.5 k 3.9 k			MF
① 9.7.7. D 9.7.7. D 9.7.7. D POS NO R 37 R 38 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47 R 48 R 49	5 Nielsen/ PARTNO 57. 41. 4471 57. 41. 4471 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4331 57. 41. 4392 57. 41. 4152 57. 41. 4152 57. 41. 4152 57. 41. 4152 57. 41. 4152	470 470 470 47 k 47 k 47 k 47 k 330 820 3.9 k 1.5 k 3.9 k 100 820			MF
① 9,7.7. D POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 44 R 45 R 46 R 47 R 48 R 49 R 50 R 51	5 Nielsch/, PARTNO 57, 41, 4471 57, 41, 4471 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4182 57, 41, 4152	470 470 47 k 47 k 47 k 47 k 47 k 47 k 330 820 3.9 k 15 k 1.5 k 3.9 k 100 820			ME
① 9.7.7. DO 9.7.7. DO 9.7.7. DO POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47 R 48 R 49 R 49 R 50 R 51	5 Nietsch/, 197, 41, 4471 57, 41, 4471 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4192 57, 41, 4192 57, 41, 4193 57, 41, 4193 57, 41, 4192 57, 41, 4192 57, 41, 4192 57, 41, 4192 57, 41, 4192	470 470 47 k 47 k 47 k 47 k 47 k 47 k 330 820 3.9 k 1.5 k 1.5 k 1.00 820 820 820	5% .12W	CSCH	MF
9 9.7.7. DP POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47 R 48 R 49 R 50 R 51 R 52 R 53	PRINTED 7. 41.4471 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4473 57.41.4139 57.41.4139 57.41.4152 57.	470 470 47 k 47 k 47 k 47 k 47 k 330 820 3.9 k 1.5 k 3.9 k 1.5 h 3.9 k 1.00 820 2.2 k 1.20 k 820	5% .12W	CSCH	MF
① 9.7.7. DO 9.7.7. DO 9.7.7. DO POS NO R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 44 R 45 R 46 R 47 R 48 R 49 R 49 R 50 R 51	MILLSEN/JOYAUANA NO. 157. 41, 4471 57. 41, 4471 57. 41, 4473 57. 41, 4473 57. 41, 4473 57. 41, 4473 57. 41, 4473 57. 41, 4473 57. 41, 4139 57. 41, 4	470 470 470 47 k 48 k 48 k 49 k 49 k 40	5% .12W	CSCH	MF
① ② ③ ③ ③ ③ ③ ③ ⑤ ⑤ ⑤ ⑤ ⑤ ⑤ ⑤ ⑤ ⑤ ⑥ ⑥ ⑥ ⑥ ⑥	Мыцей// матио 57, 41, 4471 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4133 57, 41, 4182 57, 41, 4183 57, 41, 4183	VALUE 470 470 47 k 470 47 k 47 k 47 k 47 k 47 k 47 k 50 620 3.9 k 1.5 k 1.5 k 1.00 820 2.2 k 120 k 68	5% .12W	CSCH	AAF
© 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	PARTHO 57. 41.4471 57. 41.4471 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4331 57. 41.4332	470 470 47 k 470 47 k 330 820 3.9 k 1.5 k 1.5 k 1.00 820 2.2 k 120 k	5% .12W	ESCH  DR  CSCH	MF
© 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Nielsen/V PARTNO 57, 41, 4471 57, 41, 4471 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 4473 57, 41, 433 57, 41, 433 57, 41, 432 57, 41, 4152 57, 42, 4212 57, 42, 4212 57, 42, 4212 57, 42, 4212 57, 42, 4124	VALUE 470 470 470 470 471 k 470 471 k 471	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	PARTHO  PARTHO  57. 41, 4471  57. 41, 4473  57. 41, 4473  57. 41, 4473  57. 41, 4473  57. 41, 4473  57. 41, 4473  57. 41, 4331  57. 41, 4332  57. 41, 4332  57. 41, 4392  57. 41, 4392  57. 41, 4192  57. 41, 4192  57. 41, 4192  57. 41, 4124  57. 42, 4221  57. 42, 4221  57. 42, 4221  57. 43, 4221  57. 43, 4221  57. 43, 4231  57. 44, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4231  57. 43, 4331	470 470 47 x 470 47 x	5% .12W	ESCH  DR  CSCH	MF
D D D D D D D D D D D D D D D D D D D	5 Nietsen/V PMRTV0 57. 41.4471 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4921 57. 41.4921 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4152 57. 41.4152 57. 41.4152 57. 41.4152 57. 41.4152 57. 41.4152 57. 41.4153 57. 41.4152 57. 41.4152 57. 41.4153 57. 41.4152 57. 41.4153 57. 41.4152 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4153 57. 41.4154 57. 41.4154 57. 41.4154 57. 41.4154 57. 41.4154 57. 41.4154	VALUE 470 470 471 k 470 47 k 48 k 330 820 820 15 k 3.9 k 15 k 3.9 k 100 820 2.2 k 68 68 2.2 k 68 68 2.2 k 47 k	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	PRINTED TO THE PRINT OF THE PRI	VALUE 470 470 470 477 k 470 477 k 470 k 470 k 477 k 470 k 477 k 470 k 477 k 470 k 477 k 47	5,5W 5,5W 33W 12w 5,5W	DR CSCH	ME
D D D D D D D D D D D D D D D D D D D	5 Nielsen/ 77. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4159	VALUE   VALUE   470   470   470   470   471 k   470   471 k	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	PRINTED TO THE PRINT OF THE PRI	VALUE 470 470 470 477 k 470 477 k 470 k 470 k 477 k 470 k 477 k 470 k 477 k 470 k 477 k 47	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	5 Nielsen/ 77. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4159	VALUE   VALUE   470   470   470   470   471 k   470   471 k	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	5 Nielsen/V PMRTV0 57. 41.4471 57. 41.4471 57. 41.4473 57. 41.4473 57. 41.4473 57. 41.4921 57. 41.4923 57. 41.4923 57. 41.4923 57. 41.4923 57. 41.4933 57. 41.4473	VALUE   470   470   470   470   470   471   472   472   473   474   475   47	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF
D D D D D D D D D D D D D D D D D D D	5 Nielsen/ 77. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4471 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4473 57. 41. 4159	VALUE   VALUE   470   470   470   470   471 k   470   471 k	5,5W 5,5W 33W 12w 5,5W	DR CSCH	MF

ND	PGS NO	PART NO	VALUE	SPECIFIC	ATIONS/EQUIVALENT	MFR
	R 70	58.01.3252	2.5 k	10% .5W	PCSCH	
	R 71	58.01.3103	10 k			
	R 72	58.01.3252	2.5 k			
	R 73	58.01.3252	2.5 k			
	R 74	58.01.3103	10 k			
-	R 75	58.01.3252	2.5 k			
~~~						
+						
-	-					-
_						
ND	DATE	NAME	1			
3						
3)						
2						
0			1			
ਗ	9.7.76	Nielsen/gv	1			



CAPSTAN SERVO 1.080.371 SLAVE GR 20 EL 6 / MASTER GR 20 EL 12



CAPSTAN SERVO 1.080.371 SLAVE GR 20 EL 6 / MASTER GR 20 EL 12

#### TACHO SCHMITT DISCRIMINATOR CARRIER FILTER DC AMP. MASTER SL AVE PREAMP. TRIGGER + 20.0 R33 10k BC178-B 8,57 TP2 ₹ R7 **₹ 150**k ₹8.2k R32 182 k R29 132k 9 ٧ Q1 Q2 40 V C16 R30 BC178B R46 C18+C19 €5k lin. BC109C 72,2n/2,2n 91 1,5 7 0...207 0...19 V 470p ₹83 .| BC109 C 11 431 \$100k (9 C10 \_ | 12 n | 15,8 n ≹R38 470 ₹R25 4,7k 0...7 Y R36 270 R36 22k ₹ R8 ₹ 120k ₹R1 ₹15k R4 3.3k ₹ 12.2µ ₹R39 ₹R40 R26 5,6k 1.8k ₹R44 47k 1114448 +0.0+0,0 C 23 ₹R41 10 NOT USED UNIT : 1.080.371 BOARD: I.080.376-12 NOT USED 0...5 V QPWR3 180...5 V QPWR 3 = RCA 411S 20.500.304.65 QPWR 3 -2 0PWR 3-3 YAC -MS -+0,0 +0,0 ŝ SLAVE Ė 0'0+ ᄔ MASTER QPWR 0-3 T-MM-1 YAC - MM -+ 0.0 + 0,0 + 24,0 15.0 0'0+ + 5/8 SLAVE GR 20 EL 6 MASTER GR 20 EL 12

#### CAPSTAN SERVO 1.080.371 SLAVE GR 20 EL 6 MASTER GR 20 EL 12


C 01 99.05.2681 68 n	MFF
C 03 59.32.1471 170 p	
C 08 59.05.2693 689 n 100V MPC  C 08 59.05.1225 1.2 μ 63V  C 08 59.05.2154 150 n 100V MPC  C 09 59.12.7123 12 n 11% 43V PS  C 10 59.99.007 1.8 n 10% 10W MPETF  C 11 59.11.6473 47 n 10% 10W MPETF  C 12 59.11.6473 47 n 20% 20% 20% 20% 20% 20% 20% 20% 20% 20%	
C 08 59.05.1225   2.2 µ	
C 06 59.05.3155 150 n 100V MPC 100 99.01.27132 12 n 156 3V PS 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.05 10.0	
C 0 9 99.12.7123 12 n 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
C 0 9 99.12.7123 12 n 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
C 09 59.12.7.123 12 n 1 1% 63V PS 1 1	
C 10 59.99.007 11.8 n 1 10% 100V MPETP C 11 19.91.1473 47 n 10% 100V MPETP C 11 19.91.1473 47 n 10% 100V MPETP C 11 19.91.1473 47 n 10% 100V T 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
C 11 59.31.6473 47 n 10% 10% NPETP C 12 59.11.6473 47 n 2 420% 20% TA 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
C 12 59.11.6473 47 n	
C 14 99.10.5150 15 W 10.5150 15	
C 14 99.10.5150	
C 16 9.05.4222 22 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	
C 17 95.12.7222 1.2 n 13.6 43V PS   C 18 59.12.7222 1.2 n 13.6 43V PS   C 18 59.12.7222 1.2 n 1	
C 16 9 99.12.7222 2.2 n	
C 19 59.12.7222 2.2 n	
C 20	
C 21 99.10.4151 50 p	
C 22	
C 29 99.99.0450	
C 24 99.25.5220 22 µ 5906 400 EL C 25 95.11.6471 470 p 4.5% 400 EC C 26 99.12.71222 n 4.1% 63V F3 Literito D 10 10 10 10 10 10 10 10 10 10 10 10 10	
C 25 59.11.6471 270 p * 5% 4600 PC C 26 59.12.7122 .2.n * 1% 630 PS Lötseite  D 01 50.04.0122 IN 4001  D 04 50.04.0102 IN 4148 D 5 50.04.0102 IN 448 D 5 5 5.04 Z 5 5 5.04 Z 5 5 5.04 Z 5 5 5.04 Z 5 5 5 5.04 Z 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	
C 26	
D 01 \$0.04.0122	
D	
D 05	
D 05	-
D 05	-
D 06	-
D 07 90.04,1107 3,3 V 5% 48W Z  D 08 50.04,1107 3,3 V  D 09 70.01.0223 W 159,400 61  [ 01 1.080.378.00 Diskriminatorspule  MRC = met. polycarbonets MPETTO Net. polycater 0 0	+
D 08 50.04.1107 3.3 V 159/400 S1	1
D 09 70.01.0223 W 159/400 SI  L 01 1.080.378.00 Diskriminatorspule  MRC = mat. polycarbonate METTP= mat. polycater   0   0	-
MFC = met_polycarbonate MFETP= met.polycater 6 0 0	
MFC = met_polycarbonate MFETP= met.polycater 6 0 0	
KER = ceramic Z = zener (0)	
KER s ceramic Z = zener (3)	-
KER s ceramic Z = zener (3)	-
	t/gv

POS NO	PART NO	VALUE	SPECIFICATI	ONS	EQUIVAI	ENT	MFR
0 01	50.03.0306 50.03.0306	BC 178 B BC 178 B					
0 03	50.03.0306	BC 1/8 B					
0 04	50.03.0407	BC 109 C					
9.04	30.03.0401	20.203					
Q 07	50.03.0407	BC 109 C					
Q 08	50.03.0306	BC 178 B					
Q 09	50.03.0409	BC 108 B					
R Ol	57.41.4153	15 k	± 5% .25W	CSC	CH		
R 02	57.41.4563	56 k					
R 03	57.41.4682	6,8 k					
R 04	57.41.4332 57.41.4822	3,3 k 8,2 k					
R 05	57.41.4682	6,8 k					
R 06	57.41.4154	150 k					
R 08	57.41.4124	120 k					
R_09_	57.41.4102	l_k					
R 10	57.41.4479	4,7			_ i		
R 11	57.41.4102	1 k					
R 12	57.41.4682 57.41.4104	6,8 k					
R 14	31.41.4104	AUU K					
R 15							
R 16							
R 17							
R 18							
R 19 R 20							
R 21	57.41.4182	1,8 k	± 5%25v	CSC	717		
R 22	57.02.4224	220 k	.5W	Ch			
R 23	57.02.4224	220 k					
R 24	57.41.4103	_10 k		CSC	CH		
R 25	57.41.4472 57.41.4562	4,7 k				-	-
R 27	57.41.4182	1,8 k					
R 28	57,41,4182	68 k				-	
R 29	57.39.1823	182 k	1%	ME	P		
R 30	57.39.1823	182 k					
R 31	57.39.1823	182 k					
R 32	57.39.1823 57.41.4103	182 k	+ 5%	CSC	·u		
	solid carbon	10 A			T .		
MF =	metal film			ě			
CSCH=	carbon film			OOB88	2 /2 20	.ac* *	
					2.2.77 AS		
				IND	DATE	NA	ME


POS NO	PART NO	VALUE	SPECIFICATIONS	EQUIVALENT	MFR
R 34 R 35 R 36 R 37 R 38 R 39 R 40 R 41 R 42 R 43 R 43 R 45 R 46	57. 41. 4103 57. 41. 4561 57. 41. 4223 57. 41. 4271 57. 41. 4471 57. 41. 4102 57. 41. 4100 57. 56. 4100 57. 41. 4103 57. 41. 4473 57. 41. 4473	10 k 560 22 k 270 470 1 k 100 10 k 47 k 47 k 5 k	4.5% .25W CSCH 		
TP O1	54.01.0010 54.01.0019		Euchse, 2mm, SW Buchse, 2mm, WS		
CSCH =	carbon film		0 0		

SECTION 8/30

#### DUAL-CAPSTAN DIRECTION BOARD 1.080.369 GR 20 EL 7




### DUAL CAPSTAN DIRECTION BOARD 1.080.369 GR 20 EL 7



1 JUMPER INSERTED = BIDIRECTIONAL OPERATION
JUMPER OUT = ORDINARY PLAY DIRECTION ONLY

2 JUMPER INSERTED = RECORD OPERATION POSSIBLE JUMPER OUT = NO RECORD MODE




### DUAL CAPSTAN DIRECTION BOARD 1.080.369 GR 20 EL 7

POST	NO PART	NO	VALUE	SF	ECIFICAT	IONS	EQUIV	ALENT	MER
C 0			100 µF	16 V	-10+10	0% EL			
C 0			100 µF						i
C 0			100 µF 10 µF		20+ 5	0% TA			
100			10 µF						
C 0	6 59.22.	4101	100 µF		-10+10		1.		
1) ( )			10 µF 4700 pF	25 V 63 V	1%	PS	1		
100			10 uF	16 V	-20+ 5t		-		
C 10			10 µF	10 4	-101 3	UM IN			
) (1	1 59.25.	4100	10 µP	25 V		EL			
< 1			0,068µF	_					
C 1			4700 pF 10 uF	63 V	1% -20+ 5	PS			
C 1			22 uF	40 V	-10+ 5				
D O	1 50.04.		1 N 4448	50V,	100mA	.,	N 103		
D O			1 N 4448						
D O			1 N 4448						
D O			1 N 4448						
E O			1 N 4448						
D O			1 N 4448	i					
I O			1 N 4448 1 N 4448						
I D			1 N 4448	1					
E 1	1 50.04.	0125	1 N 4448						
E 1			1 N 4448						
E 1:			1 N 4448						
r 1			1 N 4448						
E 1			_1 N 4448						
E 1			1 N 4448						
E 1			1 N 4448						
D E 20	50.04.	0954	AAZ 18						
E 2			AAZ 18						
E 2			AAZ 18 AAZ 18						
I 2			12 V		596				
D I 2			1 N 4001	50 V,	1 A				
EL I			LED LED	RED, RED,					
IC .			RC 455B		OP AMP				
IC			RC 4558	DOAL	OF MMP				
IC (	50.05.	0158	NE 555	TIMER					
TA	= Tantal = Ceramic					00	15.9.82 3.1.80	74	/vg
FS	= Polystyr	01				(2)	5.12.78	m	
EL	= Electrol	ytic				8	20.4.77	Schn	./qv
						IND	DATE	NA	
1	UDER		apstan Direc				080,369		PAGE


PCS NO	PART NO	VALUE	SPECIFICATI	ONS	EQUIVALENT	MFR
IC 04 IC 05 IC 06	50.05.0158 50.06.0002 50.05.0203	NE 555 SN74LS02 SN75463	TIMER 4 NOR DUAL OR DRIV	BR .		
E 01 E 02 E 03	56.04.0144 56.04.0144 56.04.0144	NF4-24V NF4-24V NF4-24V	RELAIS 24V,	4xti		MA
0 01 0 02	50.03.0408 50.03.0408	BC 107 B BC 107 B			BC 237 B BC 237 B	
E 01 E 02 E 03	58.01.7502 58.01.7502 57.41.4392	5 K 5 K 3,9 K	LIN, 10% .	5W		
R 04 R 05 R 06	57.41.4101 57.39.2001 57.39.2001	100 Ω 2 K 2 K	1 % .25W	MF		
8 07 8 08 8 09 8 10 8 11	58.01.7203 58.01.7203 57.41.4392 57.41.4103 57.41.4103	20 K 20 K 3,9 K 10 K	LIN. 10% .	5W		
R 12 R 13	57.41.4221 57.39.2323	220 Ω 232 K	1 % .25W	MF		
R 14 R 15 R 16	57.41.4103 57.39.2001 57.39.2001	10 K 2 K 2 K	5 % .25W 1 % .25W	MF		
R 17 R 18 R 19 R 20 R 21 R 22	57.41.4101 57.39.2323 57.41.4332 57.41.4472 57.41.4332 57.41.4472	100 Ω 232 K 3,3 K 4,7 K 3,3 K 4,7 K	5 % .25W 1 % .25W 5 % .25W	MF		
R 23 R 24 R 25 R 26 R 27	57.41.4472 57.41.4332 57.41.4332 57.41.4472 57.41.4223	4,7 K 3,3 K 3,3 K 4,7 K 22 K				
E 28 E 29 E 30 E 31 E 32	57.41.4103 57.41.4221 57.41.4223 57.41.4472 57.41.4472 57.41.4472	10 K 220 Ω 22 K 4,7 K 4,7 K				
	57.41.4472 talfilm		tsushita		.9.82 84	/vg
				0 5. 0 //2 0 20		./gv/
STL	JDER c	apstan Direct	ion	1.080		PAGE 2 of 3

	POS NO	PART NO	VALUE	SPECIFICATI	ONS	EQUIVALEN	T MFR
8	R 34 R 35 R 36 R 37 R 38 R 39 R 40 R 41	57.41.4472 57.41.4152 57.41.4152 57.41.4152 57.41.4102 57.41.4473 57.41.4102 57.41.4181 57.41.4331	4.7 K 1.5 K 1.5 K 1 K 47 K 1 K 180 Ω 330 Ω	5 % .25W			
	XIC XIC	53,03,0166 53,03,0167 50,03,9921	DIL	IC_Socket 8 IC_Socket 14 Transistor_So			
)	C 16 C 17	59.99.0205 59.99.0205	0,068μF 0,068μF	50V	CER		
					(a) 3. (b) 5. (c) 20.		
	STU	DER Caps	tan Directio	on.			PAGE 3 of 3


## DIRECTION SWITCH 1.080.259 GR17 EL2




## IC DECODER AND DRIVER/BLOCK DIAGRAM 1.080.391 GR 20 EL 8



# IC DECODER AND DRIVER 1.080.391 GR 20 EL 8



#### IC DECODER AND DRIVER 1.080.391 GR 20 EL 8




#### IC DECODER AND DRIVER 1.080.391 GR 20 EL 8

© C         1         Sy.25,53,20         22 m.         +50 M.         40 Vm.         Et.         1           © C         2         30,95,2104         10 m.         10 M.         10 V.         MPC         1           © C         3         57,99,0197         100 m.         10 M.         10 V.         MER         1           © C         5         59,25,5200         10 m.         10 M.         40 Vm.         EL.         1           © C         5         59,25,5200         10 m.         10 M.         40 Vm.         EL.         1           E         6         59,05,2104         100 m.         10 M.         10 M.         MPC         1           B         1         50,04,0102         1 M.         914         1         1         1           B         3         50,04,0102         1 M.         914         1         1         1           B         4         50,04,0102         1 M.         914         1         1         1           B         3         50,04,0102         1 M.         914         1         1         1         1           B         3         50,04,0102         1 M.		Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerkung
© c 3   59,99,0197   100 n, 480 %, 25 V, EER   1    © c 6   59,05,2104   100 n, 10 %, 40 V*, EL   1    B 1   50,04,0102   1 N 914   1    B 2   50,04,0102   1 N 914   1    B 3   50,04,0102   1 N 914   1    E 4   50,04,0102   1 N 914   1    E 5   50,04,0102   1 N 914   1    E 6   50,04,0102   1 N 914   1    E 7   50,04,1107   3,9 V, 5 %, 44 W, 2   1    E 7   50,04,0102   1 N 9001   1 N 914   1    E 7   50,04,1107   3,9 V, 5 %, 44 W, 2   1    E 8   50,04,0102   1 N 4001   1    E 9   7   50,04,1107   3,9 V, 5 %, 44 W, 2   1    E 7   50,04,0122   1 N 4001   1    E 7   50,04,0122   1 N 4001   1    E 7   50,04,0122   1 N 4001   1    E 8   50,01,0499   10 108 b, 1   1    G 1   50,01,0499   10 108 b, 1   1    G 2   50,01,0499   10 108 b, 1   1    G 3   50,01,0499   10 108 b, 1   1    G 3   50,01,0499   10 108 b, 1   1    G 4   50,03,0116   1 K 140 / 16   1    G 6   50,03,0116   1 K 140 / 16   1    G 7   50,03,0116   1 K 140 / 16   1    G 8   50,03,0116   1 K 140 / 16   1    G 9   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   50,03,0116   1 K 140 / 16   1    G 1   7   7   7   7   7   7   7   7   7		c 1	59.25.5220	22 μ, +50 %, 40 V=, EL	1	
© 1 59,23,520 22 µ, 450 %, 40 №, BL 1				100 n, 10 %, 100 V, MPC	-	
© C 6	0	C 3	59.99.0197	100 n, +80 %, 25 V, KER	1	
© C 6					+	
E 1 50.04.0102 1 N 914 1 1						
E 2   S0.04.0102   1 N 914	0	c 6	59.05.2104	100 n. 10 %, 100 V, MPC	-	
E 2   S0.04.0102   1 N 914					+	
E 2   S0.04.0102   1 N 914						
E 2   S0.04.0102   1 N 914						
B         3         50,04,6102         1 N 924         1           B         4         50,04,6107         3.3 V, 5 %, 4 W, Z         1           B         5         50,04,1107         3.3 V, 5 %, 4 W, Z         1           B         5         50,04,0122         1 N 4001         1           B         7         50,04,0122         1 N 4001         1           C         1         50,04,0122         1 N 4001         1           C         2         50,03,0409         10 108 b,         1           C         3         50,03,0409         10 108 b,         1           C         3         50,03,0409         10 108 b,         1           C         4         50,03,016 E 104 b,         1         1           C         4         50,03,016 E 104 b,         1         1           C         5         50,03,016 E 104 b,         1         1           C         6         50,03,016 E 104 b,         1         1           C         6         50,03,016 E 104 b,         1         1           C         6         50,03,016 E 104 b,         1         1           C         7         50,03,		E 1	50.04.0102	1 N 914	1	
December		E 2	50.04.0102	1 N 914	1	
E 5						
E 6		Name and Address of the Owner, where the Owner, which is			_	
© 1 50.03.0409				3.3 V, 5 %, .4 W, Z		
0 1 50.01.0409 Rc 108 b. 1 0 2 50.01.0409 Rc 108 b. 1 0 3 50.01.0409 Rc 108 b. 1 0 4 50.01.0409 Rc 108 b. 1 0 4 50.01.0409 Rc 108 b. 1 0 5 50.01.0409 Rc 108 b. 1 0 6 50.01.0409 Rc 108 b. 1 0 6 50.01.0409 Rc 108 b. 1 0 7 7 50.01.016 Rc 140 / 16 1 0 7 7 50.01.016 Rc 140 / 16 1 0 7 7 50.01.016 Rc 140 / 16 1 0 7 7 50.01.016 Rc 140 / 16 1 0 7 9 50.01.016 Rc 140 / 16 1 0 1 0 50.01.016 Rc 140 / 16 1 0 1 0 50.01.016 Rc 140 / 16 1 0 1 0 50.01.016 Rc 140 / 16 1 0 1 0 50.01.016 Rc 140 / 16 1 0 1 0 50.01.016 Rc 140 / 16 1 0 1 1 50.01.016 Rc 140 / 16 1 0 1 2 50.01.016 Rc 140 / 16 1 0 1 2 50.01.016 Rc 140 / 16 1 0 1 5 50.01.016 Rc 140 / 16 1 0 1 5 50.01.016 Rc 140 / 16 1 0 1 5 50.01.016 Rc 140 / 16 1 0 1 5 50.01.016 Rc 140 / 16 1 0 1 5 50.01.016 Rc 140 / 16 1 Rc 1 57.31.3151 Bc / Rc 140 / 16 1 R 1 57.31.3151 Bc / Rc 140 / 16 1 R 5 8 7 7 57.31.3151 Bc / Rc 140 / 16 1 R 6 57.02.5182 Rc 140 / Rc 14						
0 2 50.03.0409 № 100 B; 1 0 4 50.01.0116 № 140 / 16 1 0 5 50.01.0116 № 140 / 16 1 0 6 50.01.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 9 30.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 12 50.03.0116 № 140 / 16 1 0 13 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 14		L /	30.04.0122	1 14 4001	++	
0 2 50.03.0409 № 100 B; 1 0 4 50.01.0116 № 140 / 16 1 0 5 50.01.0116 № 140 / 16 1 0 6 50.01.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 9 30.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 12 50.03.0116 № 140 / 16 1 0 13 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 14					_	
0 2 50.03.0409 № 100 B; 1 0 4 50.01.0116 № 140 / 16 1 0 5 50.01.0116 № 140 / 16 1 0 6 50.01.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 7 50.03.0116 № 140 / 16 1 0 9 30.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 10 50.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 11 30.03.0116 № 140 / 16 1 0 12 50.03.0116 № 140 / 16 1 0 13 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 140 / 16 1 1 0 15 50.03.0116 № 14						
Q         3         50.03.0400         № 100 № 1.         1           Q         4         50.03.01616         № 140 / 16         1           Q         5         50.03.0116         № 140 / 16         1           Q         5         50.03.0116         № 140 / 16         1           Q         7         50.03.0116         № 140 / 16         1           Q         8         50.03.0116         № 140 / 16         1           Q         9         50.03.0116         № 140 / 16         1           Q         1         0.1         3         50.03.016         № 140 / 16         1           Q         1         0.1         3         50.03.016         № 140 / 16         1           Q         1         0.1         0.1         0.1         0.1         0.1           Q         1         0.0         0.0         0.0         0.1 <td></td> <td>Q 1</td> <td>50.03.0409</td> <td>BC 108 b,</td> <td>1</td> <td></td>		Q 1	50.03.0409	BC 108 b,	1	
0 4 50.01.0116 NC 140 / 16 1 1 1 0 6 50.01.0116 NC 140 / 16 1 1 1 0 6 50.01.0116 NC 140 / 16 1 1 1 0 6 50.01.0116 NC 140 / 16 1 1 1 0 0 7 50.03.0116 NC 140 / 16 1 1 0 0 9 50.03.0116 NC 140 / 16 1 1 0 0 9 50.03.0116 NC 140 / 16 1 1 0 1 1 0 1 1 1 1 1 1 1 1 1 1 1 1						
0         5         50.03.0316         BC 140 / 16         1           0         6         50.03.016         BC 140 / 16         1           0         7         50.03.016         BC 140 / 16         1           0         8         50.03.016         BC 140 / 16         1           0         9         50.03.016         BC 140 / 16         1           0         10         50.03.016         BC 140 / 16         1           0         11         50.03.016         BC 140 / 16         1           0         12         50.03.016         BC 140 / 16         1           0         13         50.03.016         BC 140 / 16         1           0         14         50.03.016         BC 140 / 16         1           0         14         50.03.016         BC 140 / 16         1           0         15         50.03.016         BC 140 / 16         1           0         15         50.03.016         BC 140 / 16         1           1         1         10         1         1           0         15         50.03.016         BC 140 / 16         1           1         1         1					-	
0 6 S0.03.0116 No.140 / 16 1 1 1 0 0 1 1 0 0 1 0 0 0 0 0 0 0 0						
0 7         50.03.0316         Bc 140 / 16         1           0 8         50.01.0316         Bc 140 / 16         1           0 9         50.03.0316         Bc 140 / 16         1           0 10         50.03.0316         Bc 140 / 16         1           0 11         50.03.0316         Bc 140 / 16         1           0 12         50.03.0316         Bc 140 / 16         1           0 13         50.03.0316         Bc 140 / 16         1           0 14         50.03.0316         Bc 140 / 16         1           0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15         50.03.0316         Bc 140 / 16         1           1 0 15					-	
0						
0         9         50.03.0316         BC 140 / 16         1           0         10         50.01.0316         BC 140 / 16         1           0         11         50.03.0316         BC 140 / 16         1           0         12         50.03.0316         BC 140 / 16         1           0         13         50.03.0316         BC 140 / 16         1           0         14         50.03.0316         BC 140 / 16         1           0         15         50.03.0316         BC 140 / 16         1           8         1         57.31.3451         150 ,         25 M,         MP         1           8         3         57.31.3451         150 ,         2         7         2 M,         25 M,         MP         1           8         4         57.02.5231         330 ,         10 %,         .25 W,         CSA         1         AB           9         6         6         70.02.5221         230 ,         1         AB           8         7         57.02.5262         22 ,         10 %,         .25 W,         CSA         1         AB           9         3         57.02.52621         12 ,         M					_	
Description						
0 11					1	
0 12					1	
O 14					1	
0 15         50.01.0316         № 140 / 16         1           8 1         87.31.3470         47 , 2 %, 25 %, MP         1           8 2         87.31.3151         150 ,            8 4         87.02.5313         330 , 10 %, 25 %, 25 %, 24 %         1           8 5         87.02.5313         330 , 10 %, 25 %, 25 %, 25 %         1           8 6         87.02.5318         1.8 %,         1           8 7         57.31.3151         130 , 2 %, 25 %, 25 %, MP         1           8 8         5 87.02.5182         1.8 %,         1           8 9         57.02.5262         22 , 10 %, 25 %, 25 %, MP         1           8 9         57.02.5262         82 , 10 %, 25 %, 25 %, MP         1           8 10         57.02.5151         1.0 %, 25 %, 25 %, MP         1           8 11         37.02.5162         1.2 %, 1.2 %, 1.3 %         1           8 12         37.02.5151         1.0 %, 25 %, 25 %, MP         1           8 13         37.02.5162         1.0 %, 25 %, 25 %, MP         1           8 14         37.02.5271         20 , 1         1         A8           8 12         37.02.5232         2.2 %, 1         1         A8           8 14				BC 140 / 16	1	
B         1         57,31,3470         47         2         %         25         MF         1           B         2         37,21,3151         150					-	
F 2   57,11,3151   150						
B   3   57,31,3151   150     1   AB   B   5   57,02,5212   220,   1   AB   B   5   57,02,5221   220,   1   AB   B   6   57,02,5121   130   2   W, .25   W, .MP   1     1   AB   B   6   57,31,3151   150   2   W, .25   W, .MP   1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1     1       1       1       1         1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             .					1	
B         4         87,02,5931         390         10 %, 25 W,         CMA         1         AB           B         6         57,02,5921         220           1         AB           B         6         57,02,5182         1.8 B,          1         AB           B         6         57,02,5182         1.0 S,         2 %,          2 M,          1         AB           B         9         57,02,5182         1.0 S,          25 W,         CMA         1         AB         B         B         9 67,02,5182         1.0 S,          25 W,         CMA         1         AB         B         B         1.0 S,          25 W,         CMA         1         AB         B         B         1.0 S,          1         AB         B         B         B         1.0 S,          1         AB         B         B         B         AB         AB         B         B         B         AB         B         B         AB         B         B         AB         B         B         B         AB         B         B         B					-	-
B   5   57,02,5221   220,   1   AB   B   6   57,02,5182   180   1   1   AB   AB					1	AB
B 6    37,02,5192   1.8 k,   1						
B B					1	
B 9   \$7.02.5920   82   10 %   .25 W   CMA   1   AB   B 10   \$7.02.5191   10   8   X   1   AB   B 11   37.02.5192   1.8 W   1   AB   1   AB   B 12   37.02.5192   1.9 W   1   AB   1   AB   B 12   37.02.5271   270   . 1   AB   AB   AB   AB   AB   AB   AB			57.31.3151	150 , 2 %, .25 W, MF	1	
B 10         57,02,5151         150         .         AB           B 11         57,02,5182         1.8 k         .         1         AB           B 12         57,02,5271         270         .         1         AB           B 13         57,02,5222         2.2 k         .         1         AB           R 14         57,02,5181         180         .         1         AB           R 15         57,02,5181         180         .         1         AB           R 16         57,02,5193         3,3 k         1         AB           R 17         57,02,5193         3,3 k         1         AB           R 19         37,02,5191         3,3 k         1         AB           R 20         37,02,5191         100         1         AB           R 20         37,02,5191         100         1         AB           R 21         37,02,5191         100         1         AB           R 22         37,02,5191         100         1         AB           R 23         37,02,5191         100         1         AB           R 24         37,02,5191         100         1         AB						
B 11   \$7.02.5182   1.8 k,   1   AB   B 12   \$7.02.5182   2.2 k,   1   AB   B 13   \$7.02.5222   2.2 k,   1   AB   B 13   \$7.02.5222   2.2 k,   1   AB   B 14   \$7.02.5181   180 ,   1   AB   B 15   \$7.02.5181   180 ,   1   AB   B 15   \$7.02.5182   3.3 k,   1   AB   B 16   \$7.02.5192   3.3 k,   1   AB   B 17   \$7.02.5192   3.3 k,   1   AB   B 17   \$7.02.5192   3.3 k,   1   AB   B 19   \$7.02.5192   3.3 k,   1   AB   B 19   \$7.02.5192   3.3 k,   1   AB   B 20   \$7.02.5193   3.3 k,   1   AB   B 21   \$7.02.5193   3.3 k,   1   AB   B 21   \$7.02.5193   3.3 k,   1   AB   B 21   \$7.02.5193   3.3 k,   1   AB   B 22   \$7.02.5193   3.3 k,   1   AB   B 23   \$7.02.5193   3.3 k,   1   AB   B 24   \$7.02.5192   100 ,   1   AB   B 25   \$7.02.5101   100 ,   1   AB   B 26   \$7.02.5102   100 k,   1   AB   B 26   \$7.02.5101   100 ,   1   AB   B 26   \$7.02.5101   100 ,   1   AB   B 26   \$7.02.5101   100 ,   1   AB   B 29   \$7.02.5103   3.3 k,   1   AB   B 29   \$7.02.5103   3.3 k,   1   AB   B 28   \$7.02.5103   3.3 k,   1   AB   B 28   \$7.02.5103   3.3 k,   1   AB   B 39   \$7.02.5103   3.3 k,   1   AB   B 30   \$7.02.5103   3.3 k,   1   AB   B 31   \$7.02.5102   3.3 k,   1   AB   B 31   \$7.02.5103   3.3 k,   1   AB   B 31   \$7.02.5103   3.3 k,   1   AB   B 33   \$7.02.5103   3.3 k,   1   AB   B 34   \$7.02.5103   3.3 k,   1   AB   B 34   \$7.02.5103   3.3 k,   1   AB   B 35   \$7.02.5103   3.3 k,   1   AB						
1						
B 13   \$7,02,5222   2,2 k,   1   Ab     B 14   \$7,02,5232   3,3 k,   1   AB     B 15   \$7,02,5332   3,3 k,   1   AB     B 16   \$7,02,5332   3,3 k,   1   AB     B 17   \$7,02,5332   3,3 k,   1   AB     B 19   \$7,02,5323   3,3 k,   1   AB     B 19   \$7,02,5323   3,3 k,   1   AB     B 20   \$7,02,5323   3,3 k,   1   AB     B 20   \$7,02,5323   3,3 k,   1   AB     B 21   \$7,02,5332   3,3 k,   1   AB     B 22   \$7,02,5332   3,3 k,   1   AB     B 22   \$7,02,5332   3,3 k,   1   AB     B 23   \$7,02,5332   3,3 k,   1   AB     B 24   \$7,02,5332   3,3 k,   1   AB     B 25   \$7,02,5332   3,3 k,   1   AB     B 26   \$7,02,5332   3,3 k,   1   AB     B 27   \$7,02,5332   3,3 k,   1   AB     B 28   \$7,02,5332   3,3 k,   1   AB     B 29   \$7,02,5332   3,3 k,   1   AB     B 29   \$7,02,5332   3,3 k,   1   AB     B 20   \$7,02,5332   3,3 k,   1   AB     R 28   \$7,02,5332   3,3 k,   1   AB     R 29   \$7,02,5332   3,3 k,   1   AB     R 30   \$7,02,5332   3,3 k,   1   AB     R 31   \$7,02,5332   3,3 k,   1   AB     R 33   \$7,02,5332   3,3 k,   1   AB     R 34   \$7,02,5332   3,3 k,   1   AB     R 35   \$7,02,5332   3,3 k,   1   AB     R 36   \$7,02,5332   3,3 k,   1   AB     R 37   \$7,02,5332   3,3 k,   1   AB     R 38   \$7,02,5332   3,3 k,   1   AB     R 39   \$7,02,5332   3,3 k,   1   AB     R 30   \$7,02,5332   3,3 k,   1   AB     R 30						
R 14						
R 15						
R 16						
R 18		R 16	57.02.5100		1	AB
R 19						
R 20         57.02.5332         3.3 k.         1         AB           R 21         57.02.5332         3.3 k.         1         AB           R 22         57.02.5332         3.3 k.         1         AB           R 23         57.02.5102         1.00 c.         1         AB           R 24         57.02.5101         1.00 k.         1         AB           R 25         57.02.5101         100 .         1         AB           R 26         57.02.5101         100 .         1         AB           R 27         57.02.5332         3.3 k.         1         AB           R 28         57.02.5332         3.3 k.         1         AB           R 30         57.02.5332         3.3 k.         1         AB           R 31         57.02.5332         3.3 K.         1         AB           R 33         57.02.5332         3.3 K.         1         AB           R 34         57.02.5332	ı					
R 21         57.02.5332         3.3 k.         1         AB           B 22         67.02.5332         3.3 k.         1         AB           B 23         67.02.5101         100         1         AB           R 24         67.02.5102         1.00 k.         1         AB           R 25         57.02.5101         100 .         1         AB           R 26         57.02.5101         100 .         1         AB           R 27         57.02.5132         3.3 k.         1         AB           R 28         57.02.5132         3.3 k.         1         AB           R 29         57.02.5132         3.3 k.         1         AB           R 30         57.02.5132         3.3 k.         1         AB           R 30         57.02.5132         3.3 k.         1         AB           R 31         37.02.5132         3.3 K.         1         AB           R 32         37.02.5132         3.3 K.         1         AB           R 34         57.02.5132         3.3 K.         1         AB						
B 22         57.02.5332         3.3 k,         1         AB           B 23         67.02.5101         10 o ,         1         AB           B 24         57.02.5102         1.0 k,         1         AB           B 25         57.02.5101         100 ,         1         AB           B 26         57.02.5101         100 ,         1         AB           B 27         57.02.5312         3.3 k,         1         AB           B 29         57.02.5312         3.3 k,         1         AB           B 30         57.02.5312         3.3 k,         1         AB           B 31         57.02.5332         3.3 k,         1         AB           B 32         57.02.5332         3.3 k,         1         AB           B 33         57.02.5332         3.3 k,         1         AB           B 34         57.02.5332         3.3 k,         1         AB           B 34         57.02.5332         3.3 k,         1         AB           B 34         57.02.5332         3.3 k,         1         AB						
B 23         57.02.5101         100         1         AB           B 24         57.02.5102         1.0 o k         1         AB           B 25         57.02.5101         100         1         AB           R 26         57.02.5312         1.0 o         1         AB           R 27         57.02.5312         3.3 k         1         AB           R 28         57.02.5312         3.3 k         1         AB           R 29         57.02.5312         3.3 k         1         AB           R 30         57.02.5312         3.3 k         1         AB           R 31         57.02.5312         3.3 K         1         AB           R 32         57.02.5312         3.3 K         1         AB           R 33         47.02.5312         3.3 K         1         AB           R 34         47.02.5312         3.3 K         1         AB           R 35         57.02.5312         3.3 K         1         AB					-	
R 24         57.02.5102         l.o k,         1         AB           R 25         57.02.5101         100 ,         1         AB           R 26         57.02.5101         100 ,         1         AB           R 27         57.02.5101         100 ,         1         AB           R 27         57.02.51312         3.3 k,         1         AB           R 28         57.02.5132         3.3 k,         1         AB           R 30         57.02.5132         3.3 k,         1         AB           R 31         57.02.5132         3.3 K,         1         AB           R 32         57.02.5332         3.3 K,         1         AB           R 34         57.02.5332         3.3 K,         1         AB           R 34         57.02.5332         3.3 K,         1         AB           R 35         57.02.5332         3.3 K,         1         AB           R 36         57.02.5332         3.3 K,         1         AB						
R 26         57.02.510.1         100         .         1         AB           R 27         57.02.5332         3.3 k,         1         AB           R 28         57.02.5312         3.3 k,         1         AB           R 29         57.02.5312         3.3 k,         1         AB           R 30         57.02.5312         3.3 k,         1         AB           R 31         57.02.5312         3.3 K,         1         AB           R 32         57.02.5312         3.3 K,         1         AB           R 33         57.02.5332         3.3 K,         1         AB           R 34         57.02.5332         3.3 K,         1         AB           R 35         57.02.5332         3.3 K,         1         AB						
R 26         57.02.5101         100         1         AB           R 27         57.02.5312         3.3 k,         1         AB           R 28         57.02.5312         3.3 k,         1         AB           R 29         57.02.5312         3.3 k,         1         AB           R 30         57.02.5312         3.3 k,         1         AB           R 31         57.02.5312         3.3 K,         1         AB           R 32         57.02.5332         3.3 K,         1         AB           R 33         57.02.5332         3.3 K,         1         AB           R 34         57.02.5332         3.3 K,         1         AB           R 35         57.02.5332         3.3 K,         1         AB		R 25	57.02.5101	100 ,	1	AB
B         8         57.02.5332         3.3 k,         1         AB           R         29         57.02.5332         3.3 k,         1         AB           R         30         57.02.5332         3.3 k,         1         AB           R         31         57.02.5332         3.3 K,         1         AB           R         32         57.02.5332         3.3 K,         1         AB           R         33         57.02.5332         3.3 K,         1         AB           R         34         57.02.5332         3.3 K,         1         AB           R         35         57.02.5332         3.3 K,         1         AB			57.02.5101	100 ,	1	AB
R 29         57.02.5312         3.3 k.         1         AB           B 30         57.02.5312         3.3 k.         1         AB           B 31         57.02.5332         3.3 K.         1         AB           R 32         57.02.5332         3.3 K.         1         AB           R 33         57.02.5332         3.3 K.         1         AB           R 34         57.02.5332         3.3 K.         1         AB           R 35         57.02.5332         3.3 K.         1         AB					_	
R 30						
R 31						
R 32 57.02.5332 3.3 K, 1 AB R 33 57.02.5332 3.3 K, 1 AB R 34 57.02.5332 3.3 K, 1 AB R 35 57.02.5332 3.3 K, 1 AB						
R 33 57.02.5332 3.3 K, 1 AB R 34 57.02.5332 3.3 K, 1 AB R 35 57.02.5332 3.3 K, 1 AB						
R 34 57.02.5332 3.3 K, 1 AB R 35 57.02.5332 3.3 K, 1 AB						
		R 34			1	
Aenderungen (1) (2) (3) (4) (5)					1	
		Aenderung	jen 🛈	0 0		(5)


Pos.	Bautei No.	Bezeichnung	Stk.	Bemerkung
R 36	57.02.5332	3.3 k, 10 %, .25 W, CMA	1	AB
R 37				
R 38	57.02.5103	10 k,	1	
R 39	57.02.5222	2.2 k,	1	
TP 1	54.01.0010	Buchse, 2 nm, sw	1	
TP 2	54.01.0019	nr8	1	
TP 3	54.01.0014	gb	1	
TP 4	54.01.0012	rt	1	
TP 5	54.01.0019	ws	1	
TP 6	54.01.0014	gb	1	
TP 7	54.01.0019	ws	1	
TP 8	54.01.0016	bl	1	
TP 9	54.01.0019	ws	1	
TP 10	54.01.0019	ws	1	
TP 11	54.01.0014	gb	1	
TP 12	54.01.0019	ws	1	
TP 13	54.01.0019	ws	1	
TP 14	54.01.0019	ws	1	
TP 15	54.01.0012	rt	1	
	-	-	_	
	<u> </u>			
IC 1	50.05.0109	SN 7404 N	1	1
IC 2	50.05.0108	SN 7400 N	1	
IC 3	50.05.0110	SN 7410 N	1	
IC 4	50.05.0108	SN 7400 N	1	
IC 5	50.05.0109	SN 7404 N	1	
IC 6	50.05.0108	SN 7400 N	1	
IC 7	50.05.0108	SN 7400 N	1	
IC 8	50.05.0109	SN 7404 N	1	
IC 9	50.05.0108	SN 7400 N	1	
Aenderu	ngen (1)	(2) (3) (4)	1)	(5)

SECTION 8/40


## IC MEMORY AND COUNTER/BLOCK DIAGRAM 1.080.393 GR 20 EL 9












## IC MEMORY AND COUNTER 1.080.393 GR 20 EL 9

Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerlung
(4) C 01	59.25.522	12 µ, +50 %, 40 V=, EL	1	
)3 c 02	59.99.019	100 n, +80 %, KER	1	
OC 03	59.99.019	100 n,	1	
)(3) C 04	59.99.019	100 n.	1	
C 05	59.99.018	10 n. +80 %, 50 V.	1	
C 06	59.99.018	10 n.	1	
⑤ c 07	59.05.210		1	
)3 c 08	59.99.019	100 n, +80 %, 25 Wm, KER	1	
3 c 09	59.05.210	100 n, 10 %, 100 V , MPC	1	
(5) C 10	59.05.210		1.	
(5) c 11	59.05.210	100 n,	1	
(3) C 12	59.05.210	100 n,	1	
(3) C 12	59.05.210	100 n.	1	
⑤ c 14	59.05.210		1	
(I) C 15	59.05.210	100 n.	1	
(5) c 16	59.05.210	100 n.	1	
C 17	59.10.410		1	
C 18	59.05.410		1	
C 19	59.05.410		1	
C 20	59.05.410		1	
⑤ c 21	59.05.210	100 n, 100 v	1	
C 32	59.05.410		1	
(6 C 23	59.32.310		1	
-	-		-	
D 01	50.04.012	1 N 4001,	1	
D 02	50.04.110	3.3 V, 5 %, .4 W, Z	1	
D 03	50.04.110	3.3 V,	1	
D 04	50.04.110	3.3 V,	1	
D 05	50.04.110	3.3 V.	1	
D 06	50.04.110	3.3 V,	1	(7) 22.12.82
D 07	50.04.110		1	@ 22.9.75 I
Aender	ingen 1 1.9	71 @16.11.72 ③ 13.7.73 <i>年</i> (4) 2	7.2.74	F1(3) 10.7.74 F2
STU	DER   Posit	onsliste Erste		.8.71 Bz
REGEN: ZOF		ry-Print bestückt Bloff	itt: Fr	É Blätter 3
Kopie f		satz für: setzt durch:	1.	080.393.00


	Pos.	Destall No.	Taurit		
	Pos.	Bauteil No.	Bezeichnung	_ S	tk. Bemerlung
	D 08	50.04.1107	3.3 V, 5 %, .4 W.	Z 1	
	D 09	50.04.1107	3.3 V, 5 %, .4 W.	2 1	
2	IC Ol	50.05.0200	SN 7404 N,	1	
	IC 02	50.05.0112		1	
	IC 03	50.05.0112		1	
	IC 04	50.05.0108	SN 7400 N.	1	
(7)	IC 05	50.06.0051	SN 74LS51 N,	1	
2	IC 06	50.05.0200		1	
(7)	IC 07	50.06.0074		1	
	IC 08	50.05.0123	SN 7413 N,	1	
	IC 09	50.05.0110		1	
	IC 10	50.05.0108		1	
	IC 11	50.05.0110		1	
	IC 12	50.05.0110		1	
	IC 13	50.05.0111	SN 7420 N,	1	
0	IC 14	50.05.0200		1	
	IC 15	50.05.0108	SN 7400 N,	1	
	Q 01	50.03.0316	BC 140 / 16,	1	
	0 02	50.03.0316	BC 140 / 16,	1	
	0 03	50.03.0316	BC 140 / 16,	1	
	Q 04	50.03.0316	BC 140 / 16,	1	
	Q 05	50.03.0316	B2 140 / 16,	1	
					(7)22.12.82.孤
			10		(6) 22.9.75
	Aencerung	U 1.7.7		427.2.7	
	STUDE	:R   Positi	onsliste	Erstellt: 2	
	REGENSOC		ry-Print bestückt	Geprüft:	AV.
	ZURICH			Blott:	2 Blätter 3
	Kopie für:		satz für: setzt durch	-	1.080.393.00
		E	serzi durchi		

Pos.	Bauteil No.	Bezeichnung	Stk	Bemerkung
R 01	57.02.5332	3.3 k, 10 %, .25 W, C	MA 1	
R 02	57.02.5391	390, 10 %, .25 W, C	MA 1	
R 03	57.02.5391	390, 10 %, .25 W, C	MA 1	
R 04	57.02.5332	3.3 k, 10 %, .25 W, C	CMA 1	
R 05	57.02.5681	680. 10 %, .25 W, C	CMA 1	
R 06	57.02.5470	47, 10 %, .25 W, C	MA 1	
R 07	57.02.5332	3.3 k, 10 %, .25 W, C	MA 1	
R 08	57.02.5101	100, 10 %, .25 W, C	2MA 1	
R 09	57.02.5221	220, lo %, .25 W, o	2MA 1	
R 10	57.02.5332	3.3 k, 10 %, .25 W, C	CMA 1	
R 11	57.02.5332	3.3 k, 10 %, .25 w, c	CMA 1	
R 12	57.02.5101	100, 10 %, .25 W, C	CMA 1	
R 13	57.02.5101	100, 10 %, .25 W, C	CMA 1	
R 14	57.02.5332	3.3 k, 10 %, .25 W, C	:MA 1.	
R 15	57.02.5332	3.3 k, 10 %, .25 W, 0	:MA 1	
R 16	57.02.5332	3.3 k, 10 %, .25 W, 0	2MA 1.	
R 17	57.02.5332	3.3 k, 10 %, .25 W, C	MA 1	
R 18	57.02.5332	3.3 k, 10 %, .25 W, 0	MA 1	
R 19	57.02.5332	3.3 k, 10 %, .25 W, 0	MA 1	
TP Ol	54.01.0010	Buchse, 2 mm, sw.	1.	
TP 02	54.01.0012	Buchse, 2 mm, rt,	1	
TP 03	54.01.0019	Buchae 2 mm, wa.	1	
TP 04	54.01.0014	Buchse, 2 mm, gb,	1	
TP 05	54.01.0014	Buchse, 2 mm, gb,	1	
TP 06	54.01.0014	Buchse, 2 mm, gb.	1.	
TP 07	54.01.0016	Buchse, 2 mm, bl.	1	
TP 08	54.01.0014	Buchse, 2 mm, gb,	1	
TP 09	54.01.0019	Buchse, 2 mm, ws,	1	
TP 10	54.01.0019	Buchse, 2 mm, ws,	1	
TP 11	54.01.0019	Buchse, 2 mm, ws,	1	
TP 12	54.01.0019	Buchse, 2 mm, ws,	1.	(7)22.12.82 辰
				(6)22.9.75
Aenderun	gen ① 1.9.71	@15.16.71 Try 3 13.7.73	(4) 27.2.74	\$10.7.74
STUDE	R Position	nsliste	Erstellt: 23.	
REGENSO	ORF TO Mercon	y-Print bestückt	Geprüft:	N.
ZURICE		yerane mercacke	Blott: 3	Blötter: 3
Kopie für		ıtz für:	1.0	80.393.00
	Erse	etzt durch:	1	


# ATTENUATOR AND PREAMPLIFIER/BLOCK DIAGRAM 1.080.396 GR 20 EL 10



# ATTENUATOR AND PREAMPLIFIER 1.080.396 GR 20 EL 10



#### ATTENUATOR AND PREAMPLIFIER 1.080.396 GR 20 EL 10





## ATTENUATOR AND PREAMPLIFIER 1.080.396 GR 20 EL 10

	Pes.	Bauteil No.	Bezeichnung	Stk.	Bemerkung
②	c 1	59.25.5220	22 μ, +50 %, 40 V=, EL	1	
Ŭ	C 2	59.10.7689	6.8 µ, 20 %, 35 V=, TA	1	
- 1	· C 3	59.10.7689	6.8 µ, 20 %, 35 V=, TA	1	
- 1	c 4	59.10.7689	6.8 μ, 20 %, 35 V=, TA	1	
	C 5	59,10.7689	6.8 μ, 20 %, 35 V=, TA	1	
- 1	c 6	59.10.7689	6.8 μ. 20 %, 35 V=, TA	1	
	C 7	59.10.7689	6.8 μ, 20 %, 35 V=, TA	1	
ļ	c 8	59.10.7689	6.8 μ, 20 %, 35 V=, TA	1	
- 1	C 9	59.10.7689	6.8 µ, 20 %, 35 V=, TA	1	
		ļ		-	
	C 11	59.10.5339	3.3 µ, 20 %, 20 V=, TA	1	
	C 12	59.05.1685	6.8 μ, 10 %, 63 V, MPC	1	
	C 13	59.05.1225	2.2 µ, 10 %, 63 V, MPC	1	
- 1	C 14	59.10.5689	6.8 μ, 20 %, 20 V=, TA	1	
- 1				_	
				_	
①	D 1	70.01.0222	B 35 C 800, SI	1	
9					
- 1	D 3	50.04.0122	1 N 4001,	1	
	D 4	50.04.0122	1 N 4001,	1	
	D 5	50.04.0102	1 N 914	1	
	D 8	50.04.0102	1 N 914,	1	
(3)	D 9	50.04.0102	1 N 914,	1	sicht gesickt
	D 10	50.04.0102	1 N 914,	1	
	D 11	50.04.0102	1 N 914,	1	
(3)	D 12	50.04.0102	1 N 914,	1	nicht gesickt
3	D 13	50.04.0102	1 m 914,	1	nicht gesicht
	D 14	50.04.0102	1 N 914.	1	
- 1	D 15	50.04.1122	18 V, 5 %, .4 W, Z	1	
- 1	D 16	50.04.1107	3.3 V, 5 %, 4 W, Z	1	
				-	
3	3 1	56.02.1001	24 V=, 1 A, 1 U,	1	
3	Қ 2	56.02.1001	24 V=, 1 A 1 U,	1	
- 1				-	
- 1	0 1	50.03.0408	BC 107 B	1	
	0 2	50.03.0316	BC 140 / 16	1	
	Q'3	50.03.0409	BC 108 b.	1	
- 1	0 4	50.03.0409	BC 108 b. BC 108 b.	1	
	Q 6	50.03.0316	BC 140 / 16,	1	
	0 7	50.03.0316	BC 140 / 16,	1	
	0 8	50.03.0316	BC 140 / 16,	1	
3	0 9	50.03.0316	BC 140 / 16,	1	
	R 1	57.56.4471	470, 5 %, 5.5 W, DR	1	
	R 2	57.02.5471	470, 10 %, .25 W, CMA	1	
	R 3	57.56.4471	470, 5 %, 5.5 W, DR	1	
	R 4	57.56.4471	470, 5 %, 5.5 W, DR	1	
	R 5	57.56.4471	470, 5 %, 5.5 W, DR	1	
	k 6	57.56.4471	470, 5 %, 5.5 W, DR	1	
	x 7	57.56.4471	470, 5 %, 5.5 W, DR	1	
	1 8	57.56.4471	470, 5 %, 5.5 W; DR	1	-
	3 9	57.02.5471	470, 10 %, .25 W, CMA	1	
	R 10	57.02.5153 57.02.5680	15 10 %, .25 W, CMA 68, 10 %, .25 W, CMA	1	
2	R 11	57.56.4100	10, 10%, .25 W, CMA	1	
(ك	R 13	57.56.4100	2.2 k, 10 %, .25 W, CMA	1	
3	E 14	57.02.5103	10 k. 10 %, .25 W CMA	1	
w	R 15	57.02.5151	150, 10 %, .25 W, CMA	1	
	E 16	57.02.5332	3.3 k, 10 %, .25 W, CMA	1	
	E 17	57.02.5682	6.8 k, 10 %, .25 W, CMA	1	
	E 18	57.02.5220	22, 10 %, .25 W, CMA	1	
	E 19	57.02.5681	680, 10 %, .25 W, CMA	1	
	E 20	57.02.5681	680, 10 %, .25 W, CMA	1	
	Aenderun	gen ① 5.5.713	FM @ 14.3.72FM 3 31 3.73 & @		(5)
		-			

Pos.	Bautel No.	Bezeichnung	Stk.	Bemerkung
R 21	57.02.5681	680, 10 %, .25 W, CMA	1	
R 22	57.02.5681	680, 10 %, .25 W, CMA	1	
R 23	57.02.5681	680, 10 %, .25 W, CMA	1.	
R 24	57.02.5681	680, 10 %, .25 W, CMA	1	
R 25	57.02.5681	680, 10 %, .25 W, CMA	1.	
R 26	57.02.5681	680, 10 %, .25 W, CMA	1	
R 27	57.02.5222	2.2 k, 10 %, .25 W, CMA	1.	
R · 28	57.02.5823	82 k, 10 %, .25 W, CMA	1	
R 29	57.02.5332	3.3 k, 10 %, .25 W, CMA	1.	
R 30	57.02.5471	470, 10 %, .25 W, CMA	1	
R 31	57.02.5471	470, 10 %, .25 W, CMA	1	
R 32	57.02.5471	470, 10 %, .25 W, CMA	1	
R 33	57.02.5471	470, 10 %, .25 W, CMA	1	
R 34	57.02.5471	470, 10 %, .25 W, CMA	1	
R 35	57.02.5471	470, 10 %, .25 W, CMA	1	
R 36	57.02.5471	470, 10 %, .25 W, CMA	1	
			_	
R 37	57.02.5471	470, 10 %, .25 W, CMA	1	
R 38	57.02.5333	33 k, 10 %, .25 W, CNA	1	
R 39	57.02.5122	1.2 k, 10 %, .25 W, CMA	1	
R 40	57.02.5122	1,2 k, 10 %, .25 W, CMA	1	
R 41	57.02.5122	1.2 k, 10 %, .25 W, CMA	1	-
R 42	57.02.5122	1,2 k, 10 %, ,25 W, CMA	1	-
R 43	57.02.5122	1.2 k, 10 %, .25 W, CMA	1	
R 44	57.02.5122	1.2 k, 10 %, .25 W, CMA	1	
R 45	57.02.5122	1.2 k, 10 %, .25 W, CMA	1.	
R 46	57.02.5122	1.2 k, 10 %, .25 W, CMA	1	
R 47	58. Ol. 5203	20 k, 20 % lin	1	<b>② ③</b>
R 48	57.02.5333	33 k, 10 %, .25 W, CMA	1	nicht gesickt
R 49	57.02.5102	1 k, 10 %, .25 W, CMA	1	
R 50	57.02.5220	22, 10 %, .25 W, CMA	1	
R 51	57.02.5681	680, 10 %, .25 W, CMA	1	
R 52	57.02.5681	680, 10 %, .25 W, CMA	1	
R 53	57.02.5331	330, 10 %, .25 W, CMA	1	
R 54	57.02.5121	120, 1ć %, .25 W, CMA	1	
R 55	57.02.5221	220, 10 %, .25 W, CMA	1	
R 56	57.02.5333	33 k, 10 %, .25W, CMA	1	
K 36	37.02.3333	33 K, 10 M, 123H, 3H	1	
			1	
TP 1	54.01.0010	Buchse, 2 mm, sw,	1	
TP 2	54.01.0014	Buchse, 2 mm, gb,	1	
TP 3	54.01.0014	Buchse, 2 mm, gb,	1	
TP 4	54.01.0019	Buchse, 2 mm, ws,	1	
	34.01.0013	ndensey a may	+-	
<b>-</b>			1	
l			<b>†</b>	
-			1	
			1	-
<b>-</b>			1	<u> </u>
			+-	
			-	
			-	-
			-	
			-	
			-	
			-	
			_	
			-	
			T	
			1	
			t -	

## COMMAND SWITCH BOARD 1.080.275 GR17 EL1







## COMMAND SWITCH BOARD 1.080.275 GR17 EL1


Pes.	Bauteil No.	Bezeichnung		Stk.	Bernerkung
в 1	51.02.0145	24 V, .04 A,	т 5.5	1	
В 2	51.02.0145	24 V, .04 A,	т 5.5	1	
в 3	51.02.0145	24 V, .04 A,	т 5.5	1	
в 4	51.02.0145	24 V, .04 A,	T 5.5	1	
в 5	51.02.0145	24 V, .04 A,	т 5.5	1	
в 6	51.02 0145	24 V, .04 A,	T 5.5	1	
D 1	50.04.0102	1 N 914		1	
D 2	50.04.0102	1 N 914		1	
D 3	50.04.0102	1 N 914		1	
D 4	50.04.0102	1 N 914		1.	
D 5	50.04.0102	1 N 914		1	
D 6	50.04.0102	1 N 914		1	
					L
Aenderu	ingen (1)	(2) (3)	(4)		(5)

#### REMOTE MODE CONTROL




# TAPE TIME COUNTER UNIT/BLOCK DIAGRAM 1.228.810 GR18






# BASIS BOARD/COUNTER 1.228.812




#### BASIS BOARD/COUNTER 1.228.812



STUDER A80 QC SECTION 8/58

## BASIS BOARD/COUNTER 1.228.812


-	Pes.	Bauteil No.	Bezeichnung	\$1k.	Bemerkung
-	Ċ 1	59,25,3470	C 47 U _10% 16 V TA	1	
(2)	C 2	59.25.1471	C. 470 U -10% 6 V EL	1	
"1	D 1	50.04.1118	D 6,2V 5% .4W Z	1	
ı	D 2	50.04.1118	D 0,24 5,0 1,111	1	
-	D ?3	50.04.1114	D lov	1	
1	D 4	50.04.0109	D N 103	1	
١	D 5	50.04.0109	D B 200	1	
- 1	D 6	50.04.0109	D	1	
1	D 7	50.04.0109	D	1	
1	D 8	50.04.0109	D	1	
21	D 9	50.04.0122	D 1 N 4001	-1	
~1	-	30.04.0122	D 1 N 1001		
-	J 1	54.01.0228	J Buchsenleiste 5-Pol.	1	
- 1	J 2	54.01.0228	J 5_Pol.	1	
- 1	J 3	54.01.0218	J 7-Pol.	1	
- 1	J 4	54.01.0289	J 8-Pol.	1	
	R 1	57.41.4392	R 3,9K 5% .25W CSCH	1	
-	R 2	57.41.4472	R 4,7K	1	
	R 3	57.41.4472	R 4,7K	1	
	R 4	57.41.4392	R 3,9K	1	
	R 5	57.41.4472	R 4,7K	1	
- 1	R 6	57.41.4472	R 4,7K	1	
	R 7	57.41.4392	R 3,9K	1	
	R 8	57.41.4472	R 4,7K	1	
	R 9	57.41.4472	R 4,7K	1	
-	R 10	57.41.4681	R 680	1	
-	R 11	57.41.4392	R 3,9K	1	
١	R 12	57.41.4392	R 3,9K	1	
-	R 13	57.41.4472	R 4,7K	1	
١	R 14	57.41.4472	R 4,7K	1	
э	R 15	57.13.4271	R 270 5% .5 W	1	
)	R 16	57.11.4399	R 3,9 5% .25W CSCH	1	
-			5/2100705M3 (4)		(5)




# COUNTER DECODER 1.228.811

POS. + NEG.
COUNTING DIRECTION
ONLY POS.

TAPE SPEED 15/30 ips 7,5/15 ips




## COUNTER DECODER 1.228.811



#### COUNTER DECODER 1.228.811


	Pos.	Box	iteil No		Bere	ichnu	ng					Stk.	Bemerku	ing
	C 01	59	32.4	152	С	1.5	N,			50V	KER	1		
L	C 02	59	32.4	152	С	1.5	N,					1		
	C 03	59	36.2	150	С	15	U,	20%		10V	TA	1		
L	C 04	55	32.4	152	С	1.5	N,			50V	KER	1		
1	C 05	59	32.4	152	С	1.5	N.					1	-	
t	E 01	50	0.04.0	125	D	1 N	444	18			sı	1		
	E 02	50	0.04.1	118	D	6.2	V	5	%	. 4W	z	1.		
	E 03	50	0.04.0	L25	D	1 N	444	8			SI	1		
1	IC 1	50	0.05.0	136	I.C	SN	740	1				1	-	
Г	IC 2	50	0.06.0	026	IC	SN	74	LS 2	6			1		
	IC 3	50	0.06.0	000	IC	SN	74	LS O	0			1		
	IC 4	50	0.06.0	004	EC	SN	74	LS 0	4			1		
	IC 5	50	0.06.0	000	IC	SN	74	LS O	0			1		
L	IC 6	50	0.06.0	000	IC	SN	74	LS O	0			1		
-	IC 7	50	0.05.0	228	IC	SN	751	07 A				1		
ot	Q 01	50	0.03.0	436	Q	BC	237	В				1		
ŀ	R 01	57	.11.4	102	R	1	к.	28	_	.25W.	MF	1		
υE	R 02	57	.11.4	102	R	1	к,					1		
٥L	R 03	57	.11.4	102	R	1	к,					1		
oL.	R 04	57	-11.4	471	R	470						1		
oL.	R 05	57	.11.4	471	R	470	_					1		
0	R 06	57	.11.4	562	R	5.6	Κ,					1		
0	R 07	57	-11.4	103	R	10	к,					1		
0	R 08	57	.11.4	822	R	8.2	к,					1		
1	R 09	57	11.4	562	R	5.6	к,					1	-	
İ							_		_			7		
1		-			-			-					-	-
-		-		-	-	-						1		
ŀ		$\vdash$			-	-			_			-		
ľ	Aenderuni	gen	123.	5.76	14 (2)	14.	7.8	1 <b>857</b> 3			4		(3)	
Γ	STUDE	ER	Pos	ition	slist	е							.10.75	
١	REGENSO( ZORICE		zähl:	er-De	code	r P	rint	A 80	0		Geprüt Blatt		8, 76 Blötter	Idem 1
ı	Kopie für			Ersot	z für:									
- 1				Erset	zt dur	ch:					7 1.	228.	811	




COUNTER 1.228.813


**DISPLAY 1.228.814** 

DISPLAY 1.224.814-00



COUNTER 1.228.813-00





STUDER

## COUNTER 1.228.813

#### DISPLAY 1.228.814

Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerking
C 01	59.32.3472	C 4.7 N, +100% 40V KER	1	
C 02	59.32.2681	C 680 P, ± 10%	1	
C 03	59.25.4100	C 10 U, +100% 25V TA	1	
D 01	50.04.0954	D AAZ 18 GE	1	
D 02	50.04.0954	D AAZ 18	1	
D 03 D 04	50.04.0954	D AAZ 18 D AAZ 18	1	
D 05	50.04.0954	D AAZ 18	1	
D 06	50.04.0954	D AAZ 18	1	
D 07	50.04.0109	D 1 N 4448 SI	1	
D 08	50.04.0954	D AAZ 18 GE	1	
IC 1	50.05.0229	IC CA 3081 (RCA)	1	
IC 2	50.99.0121	IC MK 50396 (Mostek)	1	
1	E 4 03 0000	7 Probablishes 6 2-1	1	
J 01	54.01.0238	J Buchsenleiste 6-201.	1	
J 02	54.01.0263	J Buchsenleiste 7-701. J Buchsenleiste 11-701.	1	
J 03	54.01.0308	J Buchsenielace 11:701.	-	
0 01	50.03.0409	O BC 108 B	1	
0 02	50.03.0340	0 2 N 440l	1	
0 03	50.03.0340	Q 2 N 4401	1	
Q 04	50.03.0340	Q 2 N 4401	1	
Q 05	50.03.0340	Q 2 N 4401	1	
0 06	50.03.0340	0 2 N 440L	1	
			_	
R Ol	57.02.5820	R 82 , 10% .25W CMA	1	
R 02	57.02.5820	R 82	1	
R 03	57.02.5820	R 82	1	
R 04	57.02.5820	R 82 ,		
R 05	57.02.5820	R 82 ,	1	
R 07	57.02.5820	R 82 ,	1	
	977324			
R 08	57.02.5222	R 2.2 K, 10% .25W CMA	1	
R 09	57.02.5222	R 2.2 K,	1	
R 10	57.02.5222	R 2.2 K,	1	
R 11	57.02.5222	R 2.2 K,	1	
R 12	57.02.5222	R 2.2 K,	1	
R 13	57.02.5682	R 6.8 K,	1	
R 14	57.02.5472	R 4.7 K,	1	
R 15	57.02.5472	R 4.7 K,	1	
R 16 R 17	57.02.5392 57.02.5392	R 3.9 K,	1	
R 18	57.02.5392	R 3.9 K,	1	
R 19	57.02.5392	R- 3.9 K,	1	
R 20	57.02.5392	R 3.9 K,	1	
R 21	57.02.5392	R 3.9 K,	1	
R 22	57.02.5392	R 3.9 K,	1	
			-	
XIC	53.03.0168	XIC DIL 16-Pol.	1	
XIC	53.03.0172	XIC 40-Pol.	1	
		W. O. W. D. W. L	6	
X O	50.03.9921	X O TS-Unterlage	-	
	-		-	
	-		-	
	gen ① 23.6.7	(2) (3) (4)		(5)


Pos.	Bauteil No.	Bezeichnung				Stk.	Bemerkung
							,
L 1	73.01.0120	7 - Segmes	nt Displ	av		1	
L 2	73.01.0120			-		1	
ъ з	73.01.0120					1	
L 4	73.01.0120					1	
ь 5	73.01.0120					1	
R 1	57.02.5680	R 68	10%	.25W	CMA	1	
R 2	57.02.5680					1	
X IC	53.03.0167	DIL - 14	Pol.			5	
						_	
						_	
						_	
						-	
						-	
						-	
						-	
						-	
						-	
		-				-	
						-	
						-	
			100		100		
Aenderur	igen (1)	2	3		(4)		(5)

# CONTENTS


Description	Schema Nr.	Section/Pag
GENERAL		7
STUDER ELECTRONIC CARDS		7/3
PRESENTATION OF GROUPS		7/5
POWER SUPPLY UNIT	1,080,322	7/6
- RECTIFIER PC	1,080,335 GR2 EL5	7/0
- POWER CONNECTOR PC	1.080.373 GR20 EL1	
TAPE TRANSPORT CONTROL	1,000.373 GH20 EE1	8
TAPE TRANSPORT CONTROL/BLOCK DIAGRAM		
	1 000 070 01 CB20 FL2	8/3
STABILIZER/TAPE TRANSPORT	1.080.370—81 GR20 EL2	8/5
PRESSURE ROLLER ASSEMBLY	1.080.122 GR15 EL1	8/9
TAPE TENSION CONTROL ASSEMBLIES	1.080.142/1.080.146 GR11/12	8/11
CUTTER CONTROL ASSEMBLY	1.080.311 GR19 EL1	8/13
TAPE MOVE AND DIRECTION SENSOR UNIT	1,080,179 GR14	8/15
CONTACTOR	1.080.381 GR20 EL4	8/19
SPOOLING MOTOR CONTROL	1.080.387 GR20 EL5	8/23
CAPSTAN MOTOR CONTROL DIAGRAM		8/27
CAPSTAN SERVO	1.080.371 GR20 EL6 (SLAVE) EL12 (MASTER)	8/28
DUAL CAPSTAN DIRECTION BOARD	1.080.369 GR20 EL7	8/31
DIRECTION SWITCH	1,080.259 GR17 EL2	8/35
IC DECODER AND DRIVER	1.080.391 GR20 EL8	8/37
IC MEMORY AND COUNTER	1.080.393 GR20 EL9	8/41
ATTENUATOR AND PREAMPLIFIER	1.080.396 GR20 EL10	8/45
COMMAND SWITCH BOARD	1.080.275 GR17 EL1	8/49
REMOTE MODE CONTROL		8/51
TAPE TIME COUNTER UNIT	1,228,810 GR18	8/53
BASIS BOARD/COUNTER	1,228.812	8/55
COUNTER DECODER	1,228.811	8/59
COUNTER	1.228.813	8/63
DISPLAY	1.228.814	8/63
AUDIO		9
AUDIO BLOCKDIAGRAM 2CH RECORD/REPRODUCE VERS	SION	9/3
AUDIO BLOCKDIAGRAM 2+2CH REPRODUCE VERSION		9/5
BASIS BOARD UNIT/AUDIO A80 QC	1.081.951	9/7
REPRODUCE PREAMPLIFIER/2CH (ONLY A80 QC MKI)	1.020.683	9/9
REPRODUCE PREAMPLIFIER/2+2CH (ONLY A80 QC MKI)	1,020.684	9/13
STABILIZER/AUDIO	1.080.988	9/17
REPRODUCE AMPLIFIER	1.081.952-81	9/19
REPRODUCE EQUALISATION (ONLY A80 QC MKI)	1.081.953/963	9/21
RECORD AMPLIFIER	1.081.960-00/-81	9/23
RECORD EQUALISATION (ONLY A80 QC MKI)	1.081.958/962	9/25
OSCILLATOR	1.080.984	9/27
EQUALISATION CONVERTER BOARD	1.080.979-81	9/31
CONNECTION PANEL/2CH REP/RECORD VERSION	1.080.973/989/997	9/35
CONNECTION PANEL/2+2CH REP. VERSION	1.080.959 (WITH MUTE CIRCUIT)	9/39

# CONTENTS


Description	Schema Nr.	Section/Page
ANNEX		
MODIFIED AND ADDITIONAL CIRCUITS FOR A80 QC M	KII:	
REPRODUCE PREAMPLIFIER 2CH	1.020.708–00	9/43
REPRODUCE PREAMPLIFIER 2+2CH	1.020.709-00	9/45
REPRODUCE EQUALISATION IEC I/II-IV	1.081.965-00	9/47
RECORD EQUALISATION IEC I/II—IV	1.081.964-00	9/48
OPTION FOR A80 QC VU :		
BASIS BOARD / AUDIO A80 QC VU	1.081.950-00	9/49
WIRE HARNESS BACK PANEL / VU+MONITOR PANEL	10.023.170.03	9/50
MONITOR PANEL A80 QC	1.081.900—81	9/51
- MONITOR AMPLIFIER	1.081.908-00	
VU-METER BOARD A80 QC	1.167.750-00	9/53
WIRE HARNESS VU/MONITOR PANEL	10.023.170.01	9/54





# AUDIO BLOCK DIAGRAM 2+2-CH REPR. VERSION

















POS NO	PART NO	VALUE	SP	ECIFICATI	ONS		EQUIVAL	ENT	MFR
61	59. 82. 8103	10 nF	80%	401	K	r.P			
6 2	69.32.3103	10 nF	80%	40 V	20	æ			
c 2	59. 34. 4271	270 pF	5%	N 752	26	P			
66	59. 30. 1221	220 UF	20%	31	,	4			
C 5	69.30. 1221	220 HF	20%	38	7	4			
66	59. 34. 4271	290 pF	5%	N750	Ke				
67	59.32. 3103	10 HF	80%	dov	to	FR			
C8	59.30.7100	IONE	20%	25V		4			
69	59. 30. 7100	10 HF	20%	25Y		74			
610	59.30.7100	10 p.F	20%	25V		4			
C11	59. 34. 2470	47 pF	5%	N 150	L.	E.P.			
C 12	59.34, 2470	47 pF	5%	N 150		EP.			
C 13	59.30.7100	10 45	20%	25V		4			
014-15	59.08.7/0/	loopF	2,5%	63V		90			
21	50.04.0122	1 N 4001				_			
						-		-	
91	50.03.0496	8 C 560 C	l				·		P. S. /
22	50. 02.0496	86 560 C						_	P.S.
03	50. 03. 0442	SPF 523		-					H
04	60. 03. 0442	SPF 323							М
	l	l							
						-			
	57. 41. 4182		5%	.254					
23	E7. 41. 4182	1.84	5%	.254					-
26	57. 41.4101	100	5%	.254					
86	57.41.4101	100	5%	.254					-
27	57. 41. 4471	470	5%	-2511					-
28	27. 41. 4103	10 k	5%	.254	-	-		-	
29	57. 41. 4403	106	5%	,254					
P 10	57. 41. 4471	470	6%	.254	mit o de la castina	-		_	
P 11	57. 41. 4154	150 E	5%	,254		_			
2 12	57. 41. 4154	1504	6%	.254					
2 13	E7. 41. 4182	1.84	63	.254					
211	27. 41. 4182	1,84	5%	.254					
215	57. 41. 4473	172	5%	.25H					
216	27. 31. 4373	175	6%	.25H					
H = H0	OPOL 4				0		<u>'</u>		
P = DH					(0)	Ę			
5 = 516	AENI				800	13	9 1990	and,	ger
-					-ŏ-	2	JUNI 1977	seed.	1990
					IND		DATE	n.a	ME








REPRODU	RODUCE PREAMPLIFIER 2+2 CH 1.020.684—00								
POS NO	PART NO	VALUE	SPECIFICATIONS	EQUIVALENT MFR					
61	59.30.7100	.10 µF	20% ZEV TA						
< 2 < 3	59.32.3103 59.30.7100 59.32.3103	10 HF 10 HF	20% 40V KER 20% 25V TA						
6.5	59.32.3103 59.34.4271	270 pF	5% N750 KER	e					
C 6	59. 30. 1221	220 UF	20%						
68	59. 34.4271	270 pF 270 pF 220 pF 220 pF	5% N 750 KER 5% N 750 KER	e					
C10	59.80.1221 59.30.1221	220 p.F.	20% IV TA						
C 12	69.34.4271 69.32.3103	270 pF							
. (3 . (4 . (5 . (6 . (7 . (2) . (10) . (10)	59. 80. /227 59. 34. /277 59. 34. /277 59. 30. /227 59. 30. /227 59. 32. 3103 59. 32. 3103 59. 32. 3103 59. 32. 3103 59. 30. 7100 59. 30. 7100 59. 30. 7100 59. 30. 7100 59. 31. 327 59. 3	270 pF 10 nF 47 pF 47 pF 10 nF 10 nF 10 nF	\$6% 40V EE\$ 5% M/50 K65 5% M/50 K65 20% 25V 74	e e					
C 16	59.30.7100	10,45	20% 25V TA 20% 25V TA						
619	59.30.7100	10 p.F	20% 25V TA 20% 25V TA						
C 20	59.34, 2470	10 pF 17 pF 47 pF 47 pF 10 uf 10 pF	5% N'50 KER	,					
C22	59. 34. 2470 59. 30. 7100	10,45	5%, N 100 KEE 20% 25V TA						
D 824-2	29. 58. 7/0/		2,5% 63V PP						
0.1	50.04.0122	1 N 4001							
2 4	50. 03. 0496	8c 560 C		P.S.H					
@ a 1 @ a 2 @ a 8	50.03.0496	8c 860 C 8c 860 C		P, S, M					
05	50, 05, 0,442	SPF 328		H H					
97	50. 03. 0496 50. 03. 0496 50. 03. 0496 50. 03. 0496 50. 03. 0442 50. 01. 0442 50. 01. 0442	80 560 C SPF 328 SPF 323 SPF 323 SPF 323		P.S.M D.S.M P.S.M P.S.M H H					
	30, 01,0002	477.000							
0 21	57. 41. 4471	470	5% .254						
1 1									
0 06	57. 41. 4471	470	5% .25W						
2 6 27 28	57. 41. 4112	470 1,84 1.84	5% .25W C% .25W						
P + P	NOTOROLA WILLIPS IEMENS		9	9. 12. 81 Enchance					
			-8-	9.12.81 Encloper 17.3.798+ 117 2.388 1977 Encloper DATE NAME					
ST	UDER 2			PAGE					
	1.0000	T	<del></del>						
POS N		VALUE	SPECIFICATIONS	EQUIVALENT MFR					
R 9 R 40 R 41 R 42	5%, 41, 4182 57, 41, 4182 57, 41, 4182	1.84	5% .25W 5% .25W 5% .20V						
2 12	2 57.41.4182	1,84 1,84 100	5% .25H 5% .2CH 5% .2CH 5% .25H						
R 11 R 11	57. 41. 4101 57. 41. 4101 57. 41. 4101	100	5% .25W C% .ZCW						
2 16	57.41.4101	100 470	5% ,25W 5% ,25W						
2 16 2 17 2 18 2 19	57. 41. 4101 57. 41. 4471 57. 41. 4103 57. 41. 4103	10k 10k	5% . 25W 5% , 25W						
R 20 R 21	67.41.4103	10k 10k	5% .254 5% .254						
R 22	57.41.4471	470 450k	5% .25W						
1 7 2 4	57.41.4154	1504	5% ,25%						
R 25 R 26 R 27 R 21	\$7.41.4154 £7.41.4154 £7.41.4154 £7.41.4152 £7.41.4182	150k 150k 1,8k	Ch. 25W Ch. 25W Ch. 25W						
276		1,8k							
R 30 2 71 2 32	57. 41. 4473 57. 41. 4473 57. 41. 4473	1,84 474 474 474	C's. 25W S'4. 25W S'4. 25W S'4. 25W						
2.32	57,41,4473	474	5%, .250						
	-								
	-	-							
		-							
	-								
	-								
		1	1	1					
			000	9.12.81 Budger 15.9.1880 2. JUN 1817 Buckegner					
			8						
ST	UDER Report		1102- 404 1-1	PAGE 2 of 2					
	Repro	ance- mean	ipupier, 464 14.05	v. + ra   - 012	J				

STUDER A80 QC SECTION 9/17

#### STABILIZER (AUDIO) 1.080.988 -00




## STABILIZER (AUDIO) 1.080.988-00

Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerkung		
C 01	59.31.4104	C 0.1 U, 20%, 160 V, MPETP	1			
C 02	59.25.4222	C 2.2 M, 50%, 25 V, BL	1			
C 03	59.32.0561	C 560 P, 20%, 500 V, KER	1			
C 04	59.30.4100	C 10 U, 50%, 16 V, TA	1			
C 05	59.27.4470	C 47 U, 50%, 35 V, EL	1			
C 06	59.31.4104	C 0.1 U, 20%, 160 V, MPETP	1			
C 07	59.25.4222	C 2.2 M, 50%, 25 V, EL	1			
C 08	59.32.0561	C 560 P, 20%, 500 V, KER	1			
C 09	59.30.4100	C 10 U, 50%, 16 V, TA	1			
C 10	59,27,4470	C 47 U, 50%, 35 V, EL	1			
D 01	70.01.0222	D B 35 C 800, SI	1			
D 02	70.01.0222	D B 35 C 800, SI	1			
F 01	51.01.0116	F 800 M, 5 x 20, T	1			
F 02	51.01.0116	F 800 M, 5 x 20, T	1			
IC Ol	50.05.0119	IC VA 723, TO 100, LIN	1			
IC 02	50.05.0119	IC VA 723, TO 100, LIN	1			
0 01 50,03,047		Q BD 142-5L, NPN	1			
Q 02	50.03.0475	Q BD 142-5L, NPN	1			
R 01	57.41.4102	R 1.0 K, 5%, .12 W, CSCH	1			
R O2	57.41.4222 gen (1) 19.3.7	R 2.2 K, 5%, .12 W, CSCH	1	(5)		
		7.5				
REGENSON ZORICH	ORF Stabiliz	islisie	prüff: 24, £. 72			
Kopie für:		itz für:				
mobile ini.		tz1 durch:	1.4	00.888.08		


1	Pos.	Baut	eil No	1.	Be	zeich	nun	9				-		Stk.	Berr	erku	ng
d	R 03	57	56.5	109	R	1.0	,	_	10%,		41		DR:	1			
ı	R 04		41.4		R	2,2			5%,				CSCH	1	T		
t	R 05		19.0		R	1.0			20%,				PCSCH	1			
I	R 06		41.4		R	3.3			5%,				CSCH	1			
Ì	R 07		41.4		R	1.0	K		5%,				CSCH	1			
Ì	R 08	57.	41.4	222	R	2.2	K.		5%,		12 7	ι, .	CSCH	1			
ĺ	R 09	57.	56.5	109	R	1.0			10%,		1 1	ι, :	DR	1			
	R 10	57.	41.4	222	R	2.2	K.		5%,		2 9		CSCH	1			
	R 11	58.	19.0	102	R	1.0	K.		20%,		15 9	ι,	PCSCH	1			
	R 12	57.	41.4	332	R	3.3	K,		5%,		L2 V	1,	сесн	1			
ĺ																	
l															<u> </u>		
I																	
l																	
l						.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					-						
											-						
E															_		
ļ					_			nnen									
					_												
					_							-	-				
					-												-
ļ					_					********							
Į				-	_								ant terminate				
١															_		-
I					<u> </u>												
I					_					-							
I					-						-						
Į					-										-		
-					-												
	-	_			-				_								
	-	_			-												
	Aendarun	Aendarungen (1)19.3.73			4	2) 2	11	02 /	(a				(4)		(3)		
					73 ② 2.11.83 ( ③ ionsliste					Erstell	. 16	.8.7	,	Bz			
	STUDI		-			re							Georaf			-	23.
	REGENSO	Stab	ilize	izer						Blatt:	21	£. 72	tter:	2			
1	Kopie für:			Ersot	Ersatz für:						5.511		080.9				
			rsetzt durch														


## REPRODUCE AMPLIFIER 1.081.952-81



STUDER A80 QC SECTION 9/20

## REPRODUCE AMPLIFIER 1.081.952-81






INC.	PCS.NO.	PART NO.	VALUE	SPECIFICATIONS / EQUIVALENT	MANUF.
	01	50.04.0125	1 N 4448		
	K * * * * * 1	56.02.1001		National RSD 24 V	
	P1	54.01.0220	9 cont.	AMP Nr. 163.740-7	
	R1	57.11.4103	10 kChm	5%	
	R 2	57.11.4682	6.8 kOhn	5%	
				12	

ORIG 83/02/23

S T U C E R 83/02/23 GAE REPRO. EQUAL. OC. IEC 1981 1.081.963.00 PAGE 1




## REPRODUCE AMPLIFIER 1.081.952-81


POSNO	PART NO	VALUE		SPI	ECIFICATI	ONS	EQUIVA	LENT	MF
C 1			-				-		<u> </u>
C 2	59.32.1471	470 p F	-1	80%	25 V	KER	-		-
63	59.30, 4100	1047		50%	160		-		-
64	59.80.1101	100 pt		50%	24	74			-
C 5	59.30.1101	100 47		50%	- 24	7A PS	-		-
6	59.08.7223	22 HF	-	1%	63V	13	-		-
C 7	59.50.4100	10 µ F		20%	160	74		-	
69	59.30.4100	1005		50%	124	ra	_		
		1							
car	58.12.7/23	12 nF		5%	62V	PS			
0.26	59.12.72+2	2 nF		1%	63V	P5			
6 H	59.08.7223	22 nF		2,5%	63 V	PP			
0 150	59.12.7/23	/2 nF		1%	63 V.	PS			_
C 156	53.12.7202	2 nF		1%	63V	PS			-
C 18	59.80. 1470	47µF	_	50%	31	734	-		-
69	59.30, 4100	10,45	-	50%	160	73	-	et et en	
6 19	59.27. 4470	17,45	-	0%	20	- EL			-
C +9	59. 30. 1470	67,15	-	50%	34	72			-
620	59.04.7422	47 45	-	5%	634	2			-
C 21	59.04.7482	6.205	-	5%	630	7.			-
C 22	59. 02. 0684	620115	-	5%	524	HPS			
C 24	59. 04. 7 122	1.205	_	5%	62V	2.	r l		
c 25	39. 04. 7472	4.745		5%	674	Ρ.	5		
c 26	59. 04. 7682	6.8nF		5%	680	7.	s l		
C 27	52.02.0684	68011=		5%	659	112			
C 22	59.31. 910d	1000-	_	1%	160 V	HP.			_
C 27	59.32.0101	100 11	_	20%	5007	C.F			-
C 30	59. 27. 4470	17,4F	_	50%	350	E			_
C 34	57.50.1101	100,05		50%	30	- 74			-
C 32	59. 32. 0220	22 pf		20%	5000	66 R			-
C 34	59. 25. 4102	1000 115		50% 50%	121	£6			-
c 35	59. 85. 410 2	1000 112		60%	171	EL			-
6 86	12. 12. 0221	220 p F		20%	5000	561			
6 27	59. 32. 0221	720 p. E		20 %	500 V	45			
c is	64. 24. 1150	15 p.E		6%	NPO	26.			
			_						
L.									
0 2	50. 04. 0125	1 N 3212	-			SI SI			$\vdash$
	50.00.0120	1,000.07				- 31			
		-	-				-		-
					-	0	19.7.79	201	-
			-	+		(2)	4.4.78	201	2
-				-		8	_L_SIM_1977_	2144	1119
1				9.12.	NITE	IND	4. HRZ. 1977	Seet	AME
		CONTRACTOR AND ADDRESS OF THE PARTY OF THE P	unp	Print	AIIIC.	IND	DATE	- N	
	JDER 2.								PAC


POS NO	PART NO	VALUE	SPECI	FICATION	SNC	EQUIVALENT	MFR
461	1.010.101.50	A 101				<u> </u>	ST
						-	1
21	1.022.128	9 111 11				-	ST
4.2	1.022.122	9 44 14					ST
501	50.03.0496	2c 560 C	PNP				P, CM
5) 0 2	50.01.0442	SPF 123 303078	DUP				P.S. 11
06						-	-
206	50.03.0515	Bc 707 B	Ryp				P, S, M
5) 06 5) 07 6 0 0 5) 00	50.03.0436	BC 237 E BC 307 B	NPN PNP			ļ	P, S, M
5 80	50. 05. 0426	80 237 8	1194				3,5,7
	50.05.0515	20 1078	NPN				ES, Ar
012	50.03.0345	20 160-16	PAP				4
		-	-				-
2 /	57.41.4473	47 6	2% 32 2% 25			<b></b>	
2.2	57.41.41.22	1604		511			
01	57.41.4153	154		54			
0 25	57.11.4621	680	5% .2	2511			
2.6	57. 41. 4928	826		Cw			
27	57. 41. 4394	350 i		164			
21	57. 59. 1601	1,50	1%	ecw			
20	C7. 41. 44.22	624	5%				-
2.2	57. 31. 453/	4530		25W	HE		-
24	57. 12. 6679	4.7		24	ME		
215	57.39. 1001	1k		25W 25W	79.7		-
8 %	27.41. 6573	47		TV.			
D 20	57. 41. 4121	8.2 k		7514			
219	57. 02. 0252	101	1in. 109	2011	· W		48
	57.4/.4/03	330		254			-
D 2 20	57.31.8870	560		ZCH	ME	1	
2) 7 22	57. 41. 4473	47k		754			
P . PHI	HENE AB=AL	UDER LE BRADLEY			8 1	1.7.79 2.78 (1) 4.18 (1)	igh
S = 51E					8 1	4.78	pin !
S = 11E	DATE:						
S = 11E- H = H07			2.12.81	Gá	8 1	HBZ 1977 2000	222
S = 1/6 H = H07		G IN	2.12.81 DATE /	Gå WME		HBZ 1977 . Store	AME PAGE

POS NO	PART NO	VALUE	SPE	CIFICATION	SNC		EQUIVA	LENT	MFR
225	5% H. 1107	104	5%	. Z.S. W		1			
224	57. 11. 2105	14	5%	.254		-			
7.25	17.4:4470	47	5%	-154					
2 26	57. 61. 6670	47	1%	254					-
P 27	57. 44. 4332	5.24	C%	150					
2 28	57. 41. 4152	1.24	5%	.25W					
229	E7. dr. 3121	100	5%	.24					
2 20	58. 25.2502	CA		0% Ty	· W				48
251	12. 61. 4224	120	2%	.25H					
8 22	57. 41. 1562	564	.05	.254					
253	57.41.4472	4.74	2%	-25%					
214	58.02.0252	2,5 k		1/2 Typ	·W				13
0 65	67. 41. 4581	330	- 23	1254					
212	57. 41. 6334	730	_ 0%	.500					
837	27. 21. 2101	100	5%	.25%					
232	51.03.7502	-58	-107.	10% 50	a W	-			43
239	C7. 61. 423 4	320	- 13	-254					
240	C7. 21. 15.62	5.64	- C.	-262					
	57. 41. 4177	4.74	.03	-254					
262	58.03.6252	Z. C4		1/2 Tyl	2 64	-			13
243	C7. A1. A324	230	5%	-264	-				
245	EV. 25.2503 EV. 41. 423 -	3.00		24. 14	9 14				18
246	Cr. 03. 250 1			0% Tur					40
217	57, 11. 1121	100	C%	.254	- 14				AB
545	27,07.2.2.			12.77		-			
255									
250	£2. 31. 1152	150		.254					
201	17 11 4170	47	25	1011					
2.58	57.45.4163	1501	70			-			
8 57	22 21 4104	1201	- 3	151					
250	57. 41. 4471	470	100	-204				-	
225	27. 41. 3172	4.75	.73	100					
200	57.11.2191	170	3%	.254					
257	67.21. 4222	2.24	173	-254					
251	57. 61. 2822	1.22	5	2511					
P 59	57. 44. 2108	- 4	33	.200					
260	17. 41. 41.70	47	200	-250					
261	51. 11. 12.11	270	-25	1274					
962	27. 21. 4192	16	1.00	250					
P62	57. 12. 1679	4.7	2%	124					
261	57. 12. 4477	4.7	- 6	2011		_			
265	17. 12. 6079	4.7	1.	-64					
266	57. 12. 44 79	1.7	J. C.	.224		-			
267	67. 11. 2102	- 16	7%	-254		_			
K 2/	[7. 22. 4474	470	2.8	.254		- 40	7.70	100	
	10-14	NBRADLEY			0	13	7.79	Gak	3/4
				1	3	9.4.		00/11	110
			(3) 2.12.71		8		JJM_1977	Buch	erry
			NO DATE		IND		PSZ, 1927	Berry	
	-		WWILE.	VIVIIC.	IND		ATE		ME
CTI	DER -			- 1					PAGE of 3



# RECORD AMPLIFIER 1.081.960-00/960-81






MANUF.	SPECIFICATIONS / EQUIVALENT	ALUE	·	PART NU.	POS.NO.	IND.
	PC	nF nF	6 + 8	59.11.3682 59.11.6102	C 2	
	AMP Nr. 163.740-7	cont.	9	54.01.0220	P * * * * 1	
	5% 5% 5% 5%	kOhm kOhm kOhm kOhm	33 100	57.11.4392 57.11.4333 57.11.4104 57.11.4103	R * * * * * 1 R * * * * * 2 R * * * * * 3 R * * * * * 4	


ORIG 83/02/23 S T U C E R 83/02/23 GAE REC. EQUAL. QC. TEC 1981 1.081.962.00 PAGE 1

### RECORD AMPLIFIER 1.081.960-00/-81

RECORD EQUALISATION 1.081.958/962

VERSION 1.081.960-00: C8 = 4,7n






RECORD EQUALISATION IEC I/II—IV 1.081.964 SEE ANNEX A80 QC MK II, SECTION 9/48

AC-voltmeter, min. 100 kΩ

DC-voltmeter, min. 40 k $\Omega/V$ 



Input 1500 mV, 1 kHz Position "FAST"


TEST POINTS 10 12 13 14 15 16 17 1500 225 430 340 mV ~ 270 820 -0.5 -12 -0.7 +11.6 -11.6 +11.2 -12 +12

★ IN CASE OF MONO RECORDING HEAD 1.317.110 AND THE TAPE TYPE IEC IV, C34 IS NOT EQUIPED.


## RECORD AMPLFIEIR 1.081.960-00/-81

A80 QC


INDI POS NO	MO I	PART NO	1 MALUE :	SPECIFICATIONS/EQUIVALENT 8						
C O1		59.04.7222	2,2 nF	SPECIFICATIONS/EQUIVALENT 9		POS NO	PART NO	VALUE		MFR
C 02		9.11.6331	330 pF				50.03.0306	BC178B		-
C 03		59.27.4470	47 µF	16V			50.03.0409	BC108B	NPN Board 1.080.974 PNP	+
C 04		59.30.4100	10 µF	16V			50.03.0428		Board 1.080.974 PNP Board 1.080.974 NPN	
C 05		9.27.4470	47 µF	16V		Q 10	50.03.0428	BCIO/A	Board 1.080.974 NPN	_
		9.30.4100	10 µF		$\dashv$			-		+
		9.30.1470	47 µF			D 01	57 43 4353	15.3	507 2544	
		59.11.3103		Con pate 1			57.41.4153	15 k	5% ,25W	+
		9.12.2223	22 nF	See note 1			57.41.4223	22 k		+
		9.31.6683	68 nF				57.41.4223	22 k		+
		59.31.9104	100 nF				57.41.4222	2,2 k		
0.12	3 50	59.12.2223					57.41.4101	100		-
		59.12.2223	22 nF			R 06		-		-
C 13						R 07				
C 14							57.41.4473	47 k		
C 15	.5 59	59.12.2223	22 nF				57.41.4332	3,3 k		-
		9.12.2223	22 nF	5%		R 10	57.41.4470	47		
C 17	.7 59	9.34.0479	4,7 pF				57.41.4470	47		
C 18	.8 59	59.30.6339	3,3 µF				58.03.1502	5 k	10% 1og.	
C 19	.9						58.03.1502	5 k	log.	
C 20	10						57.41.4103	10 k		
C 21		9,12,7682	6,8 nF			R 15	57.41.4153	15 k		
C 22		9.30.6339	3,3 µF			R 16	57.41.4103	10 k		_
C 23		9.04.7222	2,2 nF							-
		9.30.1470	47 µF				57.41.4472	4,7 k	10%	+
C 25		9.27.4470	47 µF	16V			58.03.0502	5 k		+
C 26			47 μF 10 μF	16V			57.41.4333		5% .25W	-
C 27		9.30.4100 9.30.6339	3,3 µF	35V Board 1.080.974			58.03.0502		10% lin.	+
C 28		9.30.6339	3,3 μF 47 μF	35V Board 1.080.974			57.41.4333		5% ,25W	+
				160			57.41.4472	4,7 k		_
C 29		9.04.8152	1,5 nF				57.41.4472	4.7 k		_
		9.04.7122 NAME	1,2 nF			R 24	57.41.4101	100	1	
(4)			W-1 - 4		- IND	DATE	NAME			
<u>a</u>		-	note 1: Ne	w standard for equalization IEC II aque) 1981: 10nF		-		-		
8					. 1	1		4		
0 00 0			***	lue for equalization 70µs CrO;:4,7n 59.11.447		-		4		
		GH (- (81)	1		.     0	22.2.83	Gä (81)	니		
O 23.10.	10.78	R. 6 Mi /g	v			23.10.78	R.G M. /c	rv		
STUD	JDER	Record A	mplifier Q	1.081.960.81 PAGE 1 OF	4 9	STUDER	Record A	Amplifier (	C 1.081.960.81 PAGE	3 OF 4
IND POS NO	NO I	PART NO	VALUE	SPECIFICATIONS/EQUIVALENT N	FR I INC	DI POS NO I	PART NO	VALUE	I SPECIFICATIONS/EQUIVALENT	
C 31				SPECIFICATIONS/EQUIVALENT N	FR INC					MFR
		9.04.8151	150 pF		_		57.41.4101	100	5% .25W	
C 32		9.04.8122	1,2 nF				57.41.4105	1 M		-
C 33		9.04.8122	1,2 nF				57.41.4470	47		
C 34		9.04.7471	470 pF			R 28				
C 35	5 59	59.32.1152	1,5 nF			R 29	57.41.4102	1 k		
C 36	6 59	9.30.1470	47 μF			R 30	57.41.4821	820		
C 37		9.32.3103	10 nF				57.41.4822	8,2 k		
C 38		9.32.3103	10 nF	Board 1.080.974			57.41.4333	33 k		
C 39		9.11.6182	1,8 nF			R 33	57.41.4103	10 k		
C 40						R 34	57.41.4102	1 k		
C 41	1 59	9.12.7103	10 nF				57.41.4102	1 k		
							57.41.4152	1,5 k		+
							57.41.4104			+
D 01	3 50	0.04.0125	1N4448	D . 11 200 001				100 k		-
				Board 1.080.974			57.41.4683	68 k		-
D 02	2 30.	0.04.1119	ZF 15	Board 1.080.974			57.41.4151	150		-
						R 40	57.41.4151	150		-
HC OT	0. 1.0	.010.101.50	A 101		$\dashv$ $\vdash$	R 41	57.41.4339	3,3		-
H							57.41.4222	2,2 k		-
K 01	1 56.	6.02.1002	Reed	24V Board 1.080.974			57.41.4470	47		-
H. H			-		$\dashv$ $\vdash$	R 44		-		
		.022,128.00			_  L	R 45	57.41.4102	1 k		
L 02		2.01.0114			_   _	R 46	58.03.2503	50 k		
		2.01.0114					58.03.2503	50 k		1
							57.41.4101	100	5% .25W	1
Q 01	1 50	0.03.0306	BC178B	PMP	7	R 49	57.41.4153	15 k		_
Q 02		0.03.0306	BC178B	PNP	$\dashv$ $\vdash$	R 50	57 41 4540	5,6 k		+
Q 03		0.03.0306	BC178B BC178B			B 51	57.41.4562			+
			BC178B BC108B	PNP			57.41.4153	15 k		-
				NP N	- H	D 52	57.41.4102	1 k		+
0.05	6 50.	0.03.0306	BC178B	PNP	+	K 53	57.41.4101	100		+-
L 10 06	o   50.	0.03.0306	BC178B	PNP			1.022.302.00		p = 1 : 1	
IND DAT	DATE	NAME			IND	DATE	NAME			
(4)					0					
(3)					0					
2					0			7		
① 22.2 8	2.83	Gä (81)			0	22.2.83	Gä (81)	J		
		R.G /1. /9	l,				R.G Mi /g	J		
	10.78		P			143.10.78	R.G ///- / q	М		
O 23.10.				3 -01 11						
			mplifier QC	1.081.960.81 AGE 2 OF	4 5		Record A		C 1.081.960.81 PAGE	4 OF 4



# OSCILLATOR 1.080.984








## OSCILLATOR 1.080.984


	Pos	Bauteil No.	Bezeichnung	Stk.	Bemerkung
(4)	C 01	59,26.2100	C 10 U, 20 %, 16y, ELSAI		(5)
	C 02	59.26.0470	c 47 U, 20 % 6,3v, ELSAI		(5)
(4)	C 03	59,26,2100	C 10 U, 20 %, 16V, ELSAI	1	(5)
(4)	C 04	59,22.8100	C 10 U, 20 %, 63V, EL	1	(5)
	C 05	59.25.5221	C 220 U, 100%, 35 V, EL	1	
	C 06	59.31.4104	C O.1 U, 20%, 160 V, MPETE	1	
	C 07	59.32.3103	C 10 N, 80%, 40 V, KER	1	3
2	C 08	59.04.9821	C 820 P, 5%, 630 V, PS	1	
@	C 09	59.04.9821	C 820 P, 5%, 630 V, PS	1	
2	C 10	59.04.9822	C 8.2 N, 5%, 630 V, PS	1	
	C 11	59.32.3103	C 10 N, 80%, 40 V, KER	1	3
				-	
	D Ol	50.04.0125	D 1N 4448. SI	1	
	D 02	50.04.0125	D 1N 4448. SI	1	
	D 03	50.04.0125	D 1N 4448. SI	1	
	D 04	50.04.0125	D 1N 4448. SI	1	
	D 05	50.04.0125	D 1N 4448, SI	1	
	1 01	54.02.0106	Jack-Socket R 32408	1	
	K 01 K 02	56.04.0120 56.04.0120	K 24V=, .03 A, 4U, AU/AG K 24V=, .03 A, 4U, AU/AG	1	
1	L 01	62.02.2122	HF-Drossel	1	
	L 02	1.022.130.00	Oszillatorspule	1	
	Aerderun	-			
	STUDE	Position:			.8.72 Bz
	REGENSON ZURICI		r Mono/Stereo Gepri	A 7.	. f. 72 22. Blütter: 2
	Kopia für	Ersot Erset	z für : zt durch:	1.0	080.984.00

		T		
Pos.	Bauteil No.	Bazeichnung	Stk.	Bemerkung
0 01	50.03.0409	Q BC 108 B, NPN	1	
Q 02	50.03.0306	Q BC 178 B, PNP	1	
0 03	50.03.0306	Q BC 178 B, PNP	1	
0 04	50.03.0434	Q ATES 0434. NPN	1	
Q 05	50.03.0434	Q ATES 0434, NPN	1	
Q 06	50.03.0434	Q ATES 0434, NPN	1	
R 01	57.41.4102	R 1.0 K, 5%, .12 W, CSCH	1	
R 02	57.41.4473	R 47 K,	1	
R 03	57.41.4470	R 47 ,	1	
R 04	57.41.4182	R 1.8 K,	1	
R 05	57.41.4222	R 2.2 K,	1	
R 06	57.41.4222	R 2.2 K,	1	
R 07	57,41,4472	R 4.7 K,	1	
R 08	57.41.4102	R 1.0 K,	1	
R 09	57.41.4339	R 3.3 ,	1	
R 10	57.41.4332	R 3.3 K,	1	
R 11	57.41.4153	R 15 K,	1	
R 12	57.41.4100	R 10 ,	1	
R 13	57.41.4102	R 1.0 K,	1	
R 14	57.41.4102	R 1.0 K,	1	
R 15	57.41.4102	R 1.0 K,	1	
R 16	57.41.4102	R 1.0 K,	1	
D R 17	57.02.5153	R 15 K, 10%, .25 W, CM	1	
T R 18	57.02.5153	R 15 K, 10%, .25 W, CM	1	
			1	
Aenderung	gen 10.5.73	2 17.3.75 322.9.75 4 12	.12 7	B 30.11.8 AFA
STUDE	B Position	sliste Erstell	1: 18	.8.72 Bz
REGENSO		mono/Stereo Geprüf	1: 21.	s. 72 28.
ZURICH		Mono/Stereo Blatt	2	Blätte: 2
Kopie für:	Ersat	z für:		080,984,00
	Erset	zi curch:	1.0	360.964.00


## **EQUALIZATION CONVERTER BOARD 1.080.979-81**



## EQUALISATION CONVERTER BOARD 1.080.979-81




# EQUALISATION CONVERTER BOARD 1.080.979-81




# EQUALISATION CONVERTER BOARD 1.080.979-81

Pos.	Bauteil No.	Bezeichnung	Stk.	Bemerkung
D 01	50.04.0109	D 1N 4448, SI	1	
D 02	50.04.0122	D 1N 4001, SI	1	
Q 01	50.03.0306	Q BC 178 B, PNP	1	
Q 02		Q BC 108 B, NPN	1	
Q 03		Q BC 108 B, NPN	1	
R 01	57.41.4472	R 4.7 K, 5%, .12 W, CSCH	1	
R 02	57.41.4103	R 10 K,	1	
R 03		R 10 K,	1	
R 04	-	R 2.2 K,	1	
R 05	57.41.4222	R 2.2 K,	1	
R 06	57.41.4680	R 68 ,	1	
R 07	57.41.4680	- 40	1	
R 07	37.41.4680	R 68 ,	1	
			<del> </del>	
			+	
			<del> </del>	
			+	
			<del> </del>	
			+	
	-			-
			₩	
	4		<u> </u>	
		<u> </u>		
Aenderu	ngen 🕧	② ③ ④		(5)


## CONNECTION PANEL 2-CH REC./REPR. VERSION 1.080.973/989/997




## CONNECTION PANEL 2-CH REC./REPR. VERSION 1.080.973/989/997











## CONNECTION PANEL WITH MUTE CIRCUIT 2+2-CH REPR. VERSION 1.081.959-00





STUDER A80 QC SECTION 9/42


### CONNECTION PANEL WITH MUTE CIRCUIT 2+2-CH REPR. VERSION 1.081.959-00

POS NO	PART NO	VALUE	SPECIFICATI	ONS	EQUIVAL	ENT MFF
C 1 C 2 C 3 C 4 C 5 C 6 C 7 C 8 C 9 C 10 C 11 C 12 C 13	59.32.3103 59.31.6224 59.31.6224 59.36.4109 59.36.4150 59.30.4100 59.30.4100 59.30.4100 59.30.421 59.32.0221 59.32.0221	0,01 uF 0,01 uF 0,02 uF 1 uF 15 uF 10 uF 10 uF 10 uF 220 pF 220 pF 220 pF 220 pF	KER KER MPETP 100 V TA TA TA TA TA KER KER KER	10 %		
D 1 D 2 D 3 D 4 D 5	50.04.0109 50.04.0109 50.04.0109 50.04.0109 50.04.0109	1N4448 1N4448 1N4448 1N4448 1N4448				
IC 1 K 1 K 2	50.99.0126 56.04.0130 56.04.0130	4N28	Optko 24 V 5 A 24 V 5 A	2A+2R 2A+2R		
L 1 L 2 L 3 L 4	62.01.0115 62.01.0115 62.01.0115 62.01.0115					
Q 1 Q 2 Q 3 Q 4 Q 5 Q 6 Q 7	50.03.0409 50.03.0409 50.03.0324 50.03.0350 50.03.0409 50.03.0350 50.03.0409	BC 108 B BC 108 B BC 177 B N-FET BC 108 B N-FET BC 108 B	J 112 J 112			
R 1 R 2 R 3 R 4 R 5 R 6 R 7 R 8	57.41.4334 57.41.4223 57.41.4105 57.41.4473 57.41.4683 57.41.423 57.41.4224	330 kohms 22 kohms 1 Mohms 47 kohms 68 kohms 22 kohms 33 kohms 220 kohms	CSCH	5 %		
	01112017007	The Rolling		0 0 0 0 0 2 2	.4.78	eibel/a


				ND See	21.4.78 DATE	Weibel/al
POS NO	PART NO	VALUE	SPECIFICATI	ONS	EQUIVA	LENT MFR
R 9 R 10 R 11	57.41.4683 57.41.4104 57.41.4103	68 kohms 100 kohms 10 kohms	CSCH	5 %		
R 12 R 13	57.41.4103 57.41.4272	10 kohms 2,7 kohms				

103140	17411110	· ALUE	UI COITTON	10110	EGOLVAL	
9 9 101 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	57.41.4683 57.41.4104 57.41.4104 57.41.4103 57.41.4272 57.41.4273 57.41.4473 57.41.4473 57.41.4403 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103 57.41.4103	68 Kohuns 100 Kohuns 110 Kohuns 110 Kohuns 127, Kohuns 110 Kohuns 127, Kohuns 110 Kohuns 128, Kohuns 128, Kohuns 128, Kohuns 130 Kohuns 140 Kohuns 140 Kohuns 150 Kohuns 160 Kohuns 170 Koh	CSCII	5 8		
				60 00 00 00 00 2	1.4.78 W	eibel/al NAME

## REPRODUCE PREAMPLIFIER 2 CH 1.020.708-00




## REPRODUCE PREAMPLIFIER 2 CH 1.020.708-00




C 0 C 2 C 0 C 0 C 0 C 0	002 003 004 005	59+12+3103 59+32+3103 59+34+4271 59+30+1221	10 nF 10 nF	90% 40V C+								
C0. Cn. Cn.	017 008 009 010	59.30.1221 59.34.4271 59.32.3103 59.30.7100 59.30.7100 59.30.7100 59.34.2470 59.34.2477	270 pF 220 uF 220 uF 220 pF 10 nF 10 uF 10 uF 10 uF 47 pF 57 pF	9018			R0014 R0015 R0016	97-11-91d2 97-11-4473 97-11-4473	1.8 kOhm 47 kOhm 47 kOhm			
C + • 01		59.30.7100	10 uF	20% - 25V + T +								
0 91	001	50.94.0122	14 4001									
L0		62.02.1101	0+1 mH									
Ln	002	62.02.1101	0.1 mH									
001 001 001	500	50.03.0496 50.03.0496 50.03.0442 50.03.0442	BC560C BC560C SPF 323 SPF 323		Ph.Sie.Mot Ph.Sie.Mot Mot Mot							
R - 00 R - 00 R - 00 R - 00 R - 00 R - 00 R - 00	002 003 004 005 006	57-11-4474 57-11-4474 57-11-4182 57-11-4182 57-11-3201 57-11-3201 57-11-4471 57-11-4403	470 kOhe 470 kOhe 1-8 kOhe 1-8 kOhe 200 Ohe 200 Ohe 470 Ohe 10 kOhe									
R * * DI	009	57.11.4103	10 kOhm			Cartor	unic. Tail	an talun				
R 01		57.11.4471	470 Ohn 150 kOhn			MATERIA A P	********	t=Matorplu, Ph:	Martine . Co.	Scamor		
R = = 00	012	57-11-4154	150 kOhn					C010101111 -11-		- 11 - 10 - 114		
R * * 01	013	57.11.4157	1.6 kOhm			0816-54	706/19					
STUDES	(00)	94/06/19 GAS	REPRODUCI	E PREAMPLIFIER 2 CH 1+020	.706.00 PAGE 1	5.1 0.7	) : P (0	1) 89/96/14 63:	R4 BACCO	C PREAMPLIFIER / CH	1.020.708.00	PAGE 2






## REPRODUCE PREAMPLIFIER 2CH 1.020.708-81




I ND •	POS-NO-	PART NO+	VALUE	SPECIFICATIONS / EQUIVALENT	MANUF.	:N0+	POS.NO.	PART NO.	VALUE	SPECIFICATIONS / EUU	IVAL ENT	MANU	F.
	C 0001	59-32-3103	10 nF	80%, 40V, Ce			R 0014	57-11-4182	1.8 kOhm				
	C = +0002	59.32.3103	10 nF	801, 40V, Ce			R0015	57-11-4473	47 kOhm				
	C0003	59.34.4271	270 pF	5%, N750, Ce			R0016	57-11-4473	47 kOhm				
	C++0004	59+30+1221	220 uF	20%. 3V. Ta									
	C++0005	59+30+1221	220 uF	20%, JV, Ta									
	C++0006	59+34+4271	270 pF	5%, N750, Ce									
	C0007	59.32.3103	10 nF	80%, 40V, Ce									
	C++0008	59.30.7100 59.30.7100	10 UF	20% 25V Ta 20% 25V Ta									
	C000V	59.30.7100	10 uF 10 uF	20%, 25V, 1a 20%, 25V, Ta									
	C0010	59.30.7100	47 pF	51, N150, Ce									
	C++0011			5%+ N150+ Ce									
	C++0012	59.34.2470	47 pF 10 uF	20%, 25V, Ta									
	C ** 001 3	59+30+7100	TO OF	2041 2791 18									
	00001	50.04.0122	IN 4001										
	L0001	62.02.1101	0.1 mH										
	L 0002	62.02.1101	0.1 mH										
	40001	50.03.0496	8C560C		Ph+Sie+Mot								
	S0000**D	50+03+0496	865600		PhySie-Mot								
	4++0003	50+03+0442	ZN 5458	selected ID = 2.5 mA a UG 0.5	-1-5 V Mot								
	W-+0004	50.03.0442	2N 5458	selected ID = 2.5 mA a UG 0.5	-1 -5 V Mot								
	R++0001	57-11-9979	470 k0hm										
	K = +0002	57-11-4474	470 kOhe										
	K 0003	57.11.4182	1.8 kOhm										
	K 0004	57-11-4182	1.8 kOhm										
	R = +0005	>7-11-3201	2 00 Ohm										
	R - +0006	57+11+3201	200 Ohm										
	R = = 0007	57-11-4471	470 Ohm										
	R0006	57-11-4472	4.7 kOhm										
	R 0009	57-11-4472	4.7 kOhm			Le=Cer	anic. Ta=T	antalus					
	R - +0010	57-11-4471	470 Ohm										
	H0011	57-11-4154	150 kOhm			BANUE	CTURER: Mo	t=Motorola, Ph=1	Philips. Sie	-Siemens			
	R.=0012	57-11-4154	150 kOhm										
	R + +0013	57-11-4162	1.8 kOhm			ORIG 6	6/11/20						
STU	0 E R (00	0) 86/11/20 GAE	REPRUDUC	E PREAMPLIFIER 2 CH 1+020+708+	B1 PAGE 1.	STU	DER (C	00) 86/11/20 GAE	REPRODUC	E PREAMPLIFIER 2 CH	1.020.708.81	PAGE	2


## REPRODUCE PREAMPLIFIER 2+2 CH 1.020.709-00



STUDER A80 QC MKII SECTION 9/46


### REPRODUCE PREAMPLIFIER 2+2 CH 1.020.709-00







	POS.NO.	PART NU.	VALUE	SPECIFICATIONS / LQUIVA	LENT MANUF.	IN).	POS-NO-	PART NO.	VALUE	SPECIFICATIONS / EQU		MANUF.
	C0001	59.30.7100	;0 uF	20%+ 25V+ Ta			R++0003	57-11-4474	470 kOhm			
	C - + 0002	59.32.3103	10 nF	50% 40V Ce			R++0004	57-11-4474	470 kOhm			
	C-+0003	59.30.7100	,0 uF	20% 25V Ta			R = = 0005	57-11-4474	470 kOhn			
	C++0004	59.32.3103	10 nF	90%, 40V, Ce			R = = 0006	57-11-4471	470 Ohm			
	C++0001	59.34.4271	210 pF	5%, N750, Le			R = = 0007	57-11-4182	1.8 kOhm			
	C++0004	59+30+1221	220 uF	20%, 3V, Ta			R0008	57.11.4182	1 = 8 kOhm			
	C 0007	59.30.1221	220 uF	20% 3V Fa			R0009	57-11-4182	1.8 kOhm			
	5000e+2	59.34.4271	210 pF	5%, N750, Co			R++0010	57-11-4182	1 = 8 kOhm			
	C++0009	59.34.4271	270 pF	5%, N750, Le			R++0011	57.11.4182	1 - 8 kOhm			
	C0010	59.30.1221	220 uF	20%, 3V, Ta			R++0012	57.11.4182	1.8 kOhm			
	C0011	59.30.1221	220 uF	20%, 3V, Ta			R**0013	57+11+3201	200 Ohn			
	C0012	59.34.4271	270 pF	5%, N750, Le			R 0014	57-11-3201	200 Ohn			
	C-+001!	59.32.3103	10 nF	80% 40V Le			R0015	57-11-3201	200 Ohn			
	C++0014	59.34.2470	47 pF	5%, N150, Le			R0016	57-11-3201	200 Ohm			
	C++0015	59.34.2470	47 pF	5%, N150, Le			R + + 0017	57-11-4471	470 Ohn			
	C0016	59.30.7100	LO uF	20%, 25V, Fa			R++0018	57+11+5103	10 kOhm			
	C0017	59.30.7100	LO UF	20%, 25V, Ta			R0019	57-11-4103	10 kOhm			
	C0018	59.30.7100	10 uF	20% 25V Fa			R 0020	57.11.4103	10 kOhm			
	C0019	59.30.7100	:0 uF	20%+ 25V+ Fa			K0021	57.11.4103	10 kOhm			
	C++0020	59.30.7100	LO uF	20%, 25V, Fa			R0022	57.11.4471	470 Ohm			
		59.34.2470	47 pF	5%+ N150+ Ce			R0023	57.11.4154	150 kOhm			
	C0022 C0023	59+34+2470	47 pF	5%, N150, le			R 0024	57.11.4154	150 kOhm			
	C0023	59+30+7100	10 UF	20% - 25V - Fa			R0025	57.11.4154	150 kOhm			
	00001	50+04+0122	IN 4001		Mot		R * * 0026	57-11-4154	150 kOhm			
	00001	2010440155	TM 4001		701		R 0027	57.11.4182	1.8 kOhm			
	Q0001	50-03-0496	8C560C		Ph.Sie.Not		R 0028	57-11-4182	1.8 kOhm			
	9++0002	50.03.0496	BC160C		Ph+Sie+Hot		R0029	57-11-4473	47 k0hm			
	00003	50+03+0496	BC560C		Ph+Sie+Mot		R0030	57.11.4473	47 kOhm 47 kOhm			
	9++0004	50.03.0496	8C560C		Ph+Sie+Mot		H = = 00 32	57.11.4473	47 kDhm			
	9++0005	50.03.0442	SPF323		Mot		H 17U 32	37.11.4413	47 KURIM			
	90006	50.03.0442	SPF323		Mot							
	90007	50.03.0442	SPF323		Hot	£ ( a.	ranic. Tarl	and alone				
	Q0008	50+03+0442	SPF323		Hot	00.00	SHILL 18-11	ant arou				
						MAYUFA	ACTURER: "o	t=4otoral₁, Ph=	Philips: Sic	=5 remens		
	R0001 R0002	57-11-4471 57-11-4474	470 Ohm 470 kOhm									
	K++0002	57-11-4474	470 kOhn			ORIG	34/06/19					
TU	D E R (00	1 84/06/19 GAE	REPRODUC	E PREAMPLIFIER 2+2 CH 1	+020+709+00 PAGE 1	0.0	0 5 8 101	01 d4/06/19 GAS	ALC BRITATION	E PREAMPLIFIER 2+2 CH	1.020.709.00	PAGE à






## REPRODUCE PREAMPLIFIER 2+2 CH 1.020.709-81






P05-N0-	PART NO.	VALUE	SPECIFICATIONS / EQUIVALENT	HANUF.	100.	POS-NO-	PART NO.	VALUE	SPECIFICATIONS / EUUI	VALENT	HANUF.
C0001	59-30-7100	10 uf	20%. 25V. Ta			R++0003	57+11-4474	470 k0hm			
C++0002	59-32-3103	10 nF	80% 40M- Ce			R++0004	57-11-4474	470 k0hm			
C-+0003	59+30+7100	10 UF	20% 25Ve To			80005	57-11-4474	470 k0hn			
C0004	>9+32+3103	10 nF	80%, 40%, Le			K 0006	57-11-4471	470 Ohn			
C-+0005	59+34+4271	210 pF	5% N750+ Le			H 0007	57-11-4182	1-8 kOhm			
C++0006	59-30-1221	220 UF	20% - 3V - Ta			R = = 0005	57-11-4182	1.8 kOhm			
C++0007	59.30.1221	220 uF	20%, 3V, Ta			R * * 0009	>7.11.4182	1-s kOhn			
C++0008	59-34-4271	210 pF	5%, N750, Ce			R++0010	>7-11-4182	1-8 kOhn			
C 0009	59-34-4271	210 pF	5%, N750, (e			R - + 0011	57-11-5182	1+8 k0hm			
C0010	>9.30.1221	220 uF	20%, 3V, Td			K * * 0012	o7.11.4182	1+8 k0hm			
C0011	59-30-1221	220 uF	20%, 3V, Ta			R 0013	57+11+3201	200 Ohm			
C0012	59-34-4271	210 pF	5%, N750, Ce			R0014	57-11-3201	200 Ohm			
C0013	59+32+3103	10 nF	80%, 40%, Ce			R 0015	57.11.3201	200 Ohn			
C0014	59+34+2470	47 pF	5%, N150, (e			R GULo	57-11-3201	200 Ohn			
C++0015	59-34-2470	47 pF	5%, N150, (e			ROC17	57-11-4471	470 Ohn			
C++001s	59.30.7100	10 uF	20%, 25V, Ta			R001s	57.11.4472	4.7 kOhn			
C++0017	59.30.7100	10 uF	20%, 25V, Ta			R0019	57-11-4472	4.7 kOhm			
C0018	59.30.7100	10 uF	20%, 25V, Ta			R++002U	57-11-4472	4.7 k0hm			
C 0019	59.30.7100	10 uF	20%, 25V, To			R + + 0021	57.11.4472	4.7 k0hm			
00020	>9.30.7100	10 uF	20% 25V to			R++0022	>7+11+4471	470 Ohn			
1500 3	59+34+2470	47 pF	5%, N150, Le			R++0023	57-11-4154	- 150 kOhm			
C 0022	59+34+2470	47 pF	5%, N150, Ce			R * * 0024	57 - 11 - 4154	150 k0hm			
C 0023	59+30+7100	10 uF	20%, 25V, Ta			R 0025	57.11.4154	150 k0hm			
						R0026	57-11-4154	150 kOhm			
1000++0	50.04.0122	19 4001		Mot		R 0027	57.11.4182	1.8 kOhm			
						R0928	57-11-4182	1.8 kOhm			
10009	50.03.0496	BC560C		Ph.Sie.Mot		R0029	57-11-4473	47 kOhm			
00005	50.03.0496	BC560C		Ph.Sie.Mot		P0030	57-11-4473	47 kOhm			
00003	50.03.0496	BC560C		Ph.Sie.Mot		80031	57-11-4473	47 kOhm 47 kOhm			
0++0004	50.03.0496	BC:6UC		2h+Sie+Mot		R0032	57-11-4473	47 kUhm			
4++0005	50+03+0442	2N 5458	selected ID = 2.5 mA a UG 0.5								
40606	50.03.0442	2N 5458	selected ID = 2.5 mA a UG 0.5		4						
00001	>0.03.0442	2N 5458	selected ID = 2.5 mA D UG 0.5.		cercer	amic+ Ta=I	antaium				
60008	>0-03-0442	2N 5458	selected ID = 2.5 mA a UG 0.5.	.1.5 V Mot	MANUFA	CTURER: Mo	t=Motorgla+ Phi	Philips, Sie	-Sienens		
R + + 0001	57-11-4471	476 Ohn									
R++0002	57.11.4474	476 kOhn			ORIG 8	6/11/20					
	) 66/11/20 GAE		PREAMPLIFIER 2+2 CH 1+020+709	81 PAGE 1			0) 86/11/20 GAE	REPRODUC	E PREAMPLIFIER 2+2 CH	1.020.709.81	PAI

## REPRODUCE EQUALISATION IEC I/II-IV 1.081.965-00







D1 50.04.0125 1 N 44443  K1 56.02.1041 *** *******************************	100.	POS-NO-	PART NU.	VALUE	SPECIFICATIONS / FUUIVALENT	MANUE.
P1 54-01-0220 9 cont. AMP Nr. 163-740-7  R1 57-11-4103 10 kNhm 52  R2 57-11-4562 5-6 kNhm 54		D 1	50.04.0125	1 % 4443		
R1 57.11.4103 10 kNhm 5% R2 57.11.4562 5.6 kNhm 54,		K1	56-02-1001		hational 855-24-V	
R****2 97-11-4562 5+6 kOhm 54 ,		P • • • • 1	54.01.0220	9 cont.	AMP Nr. 163.740-7	
		R 1	57.11.4103	10 k∩hm	5.4	
R3 57.11.4224 220 kOhm 5%		R * * * * 2	57.11.4562	5.6 kOhm	5.4 ,	
		R 3	57 - 11 - 4224	220 kOhm	5%	

ORIG 84/05/15

S T U D E R (00) 84/05/15 GAP REPRO. Fu. 1EC 1/11-1V 1.081.965.00 PAGE 1

## RECORD EQUALISATION IEC I/II-IV 1.081.964-00







• CNI	POS.NO.	PART NO.	VALUE	SPECIFICATIONS / EQUIVALENT	MANUF.
	C 1	59.11.4472	4+7 nF		
	C • • • • 2	59 • 11 • 6102	1 nF		
	P • • • • 1	54.01.0223	9 cont.	AMP Nr. 163.740-7	
	R 1	57.11.4392	3.9 kOhm	54	
	R * * * * 2	57.11.4183	16 k0hm	5 %	
	R 3	57-11-4223	22 kOhm	5%	
	R 4	57.11.4104	100 kOhm	5%	
	R * * * * 5	57.11.3512	5+1 kOhm	5.6	

DRIG 84/05/15


S T U D S R (00) 84/05/15 SA\* ReC. Fig. 160 1/11-1V

1.081.964.00 PAGE 1






# MONITOR PANEL A80 QC 1.081.900-81 MONITOR AMPLIFIER 1.081.908-00



STUDER A80 QC/VU SECTION 9/52

#### MONITOR PANEL A80 QC 1.081.900-81 MONITOR AMPLIFIER 1.081.908-00




IND	POS NO		PART NO	VALUE	SP	ECIFICATION	ONS/EQUIVALENT	MER
	61	59	3.30.6478	0,47,45	160		74	
	C2	59	30.6478	0.6745	160		74	
	03	55	30.6478	0,47,45	160		Zir	
	04	51	1.30.6478	0,4745	160		7A	
	05	54	30.6109	fuF.	160		74	
	66	51	30,6109	1µF	16V		7.4	
	67	55	2.30.6109	1 <sub>U</sub> F	161		7.4	
	01	59	30.6109	1 <sub>U</sub> F	161		.54	
3	00	51	2.99.0205	62nF			KER	
C	C10	59	7.99.0264	68nF			KER	
	01	50	1.03.0409	EC 10 F B				
	02	50	.03.0409	80 1088				
	03	50	0.03.0409	30 1088				
	04	50	.03.0409	30 1088				
	21		7.11.4273	27 E S2	5%	025W		
	22	57	1.11.4273	27 ksz	54	0.25N		
	23	58	.01.8203	20 k sz	10%		tin.	
	24	.50	.01.8203	20ks2	10%	0.25.7	lia	
	25	5	7.11.4473	47 612	5%	0.25%		
	26	6	7.11.4473	47kn	5%	0.251/		
	₽7	51	7.11.4102	1112	5%	8.25W		
	21	57	7.11.4332	3,3 k (2	5%	0.25W		
	89	57	7.11.4102	1412	5%	0.254		
	210	6	7.11.4332	3,3612	5%	0.2511		
	211	- 63	7.11.0102	1612	54	0.2514		
	R12	51	7.11.4332	3,36.12	54	0.254		
IND	DAT		NAME					
(4)	7.60	93	0.5					
3	21.8.	80	Bucherger					
2	2.11.7	9	10					
1	13.9.	79	Buchegger	1				
O	18.2	77	Frey	1				

1.081.900 -21 PAGE 1 OF 2


STUDER Monitor - Panel - Board


ND POS NO	PART NO	VALUE	SPEC	CIFICATIONS/EQUIVALENT	I MER
R13	57.11.4102	1612	5%	0.25W	
214	57, 11.4332	33202	5%	0,25W	
215	57.39.4751	4750 sz	1%	a 25W	
RIG	57.39.4751	4750.22	7%	0,25W	
217	57.11.4473	47 k s2	5%	0,2514	
RIE	57.11.4473	47 ES	3%	0,250	
219	67.11.4473	47£sz	5%	0.25W	
2.20	E7.11.4173	47 652	5%	0.254	
221	57.56.5220	22.52	10%	41/	
P22	58.04.0108	10 6 12	68	0.254 tog	
		-			
21	54.01.0226	Zo contacts			AMP
72	54.01.0226	20 contacts			AME
2) 73	54.24.0102				P
21	54.01.0317	7 contacts			AMP
4 5 t ) 4 5 2 } 4 5 3 }	1.081.900-07				
24	55.01.0153				
DATE	NAME	1			
7.6.8		R = Rendor	Instrument	5 LTD	
3 21.8.	80 Benleger			-	
0 2.11.7		1			
0 13.9.		1			
18.2.		1			




POS NO	PART NO	VALUE	SPECIFICATIO	INS EQUIVALENT	MFR
0 1	59.12.2224	. 22,4	5% 634		
0 8	59.25.4/02	1000 μ	- 40% ZEV		
6 3	59.25.4102	122020	-10% 250		
6 4	59.30.3330	33,00	-20% 10V		
C 5	59. 52. 3104	1 /4	-20%, 600		
C 6	59.32.3104	.11	-20% 600		-
D /	50.04.0122	184001			
D 2	50.06.0122	11 4001			
23	50.04.0/22	111 4721			-
D /C /	50.05.0243	NE 5534			
Z /	57.41.4102	16	5% .Z5H		-
2 2	67. 41. 4223	224	E% .25W		
2 3	(7. 41. 4223	224	5% .254		
7 4	57. 41. 4105	111	5% .25W		
25	C7. 41. 4102	11.	C% -754		
8 6	57. 41. 4102	1k	C% .200 C% .204		-
2 8	57.03, 5329	2.2	10"5 . EW		
2 9	57.03.5229	2.2	10% . SH		-
210	57.44. 422/	222	£% .25W		_
211	57.56, 4220	2.2	10% 424		-
7.7:	52. 54. 4220	2.2	10%, 4,24		
01	50.03.0478	BD -135 - 10	UPU		-
02	50. 02. 0479	80 436 - 10	740		
					-
					-
					-
					-
-					-
				(b)	
-				0 10.1.10 Wr	
				0 18.1.80 Hr 0 18.2.77 Fre	hel
1100000000	V 400 000 000 000 000 000 000 000				AME
STL	DER Moni	for vers får		1.081.908	PAGE / of /

#### VU-METER BOARD A80 QC 1.167.750-00






IND	POS NO	PART NO	VALUE	1 8	SPECII	ICATIONS/EQUIVALENT	M
	C 01	59.31.6224	0.22u				
	C 02	59.25.4470	47u				
	C 03	59.34.4221	220p				
	C 04	59.32.3103	10n				
	C 05	59.32.3103	10n				
	C 06	59.36.0150	15u	-			
	1C 1	50.05.0243	NE5534	(TBA 10	34 }		
	J 01	54.01.0243	15 Pol	CIS-Soc	ket-	Strip	
	JS 1	54.01.0021		Jumper			
		54.01.0020		Jumper-	Pin		
_	MP 1	1.167.750-11		PCB			
	R 01	57.11.4392	3.9k				
	R 02	58.01.8103	10k 1in	Potenti	onet	er	
	R 03	57.11.4472	4.7k				
	R 04	57.11.4182	1.8k				
	R 05	57.11.4222	2.2k				
_	R 06	57.11.4104	100k				 
	R 07	57.11.4182	1.8k				
	R 08	57.11.4332	3.3k	-			 _
	XIC1	53.03.0166		IC-Sock	et		_
-							
IND	DAT	E NAME					
(4) (3)							
② ①							
$\stackrel{\vee}{\sim}$	15.05.	84 HO	-				



#### **HEAD SHIELD**




### Mounting accessories to POS 4

 - +	 -+	 	 -+-	 	 	 	 	-
•			•	w M3x14				
 - +	 	 	 - + -	 	 	 	 	2000
			•	washer				
 - +	 	 	 -+-	 	 	 	 	-


### **HEAD SHIELD**

INDEX! QTY	ARTICLE NU	JMBERI PA	RT NAME
------------	------------	-----------	---------

		1 1.080.245.00	Head shield, compl.
to		1	1
above	2	24.16.3023	Circlip
01	1	1 1.080.245.01	Head shield housing
	1	1 1.080.245.02	Guide bolt
02	1	1 1.080.246.00	Head shield
	1	1 1.080.315.06	Spring bolt
	1	1 1.080.315.07	Retaining bolt
	1	1 1.080.315.08	Guide bolt
03	1	1 1.080.315.09	l Knob
	1	1 1.080.315.10	Tension spring
İ	1	1 1.080.315.11	·
04	1	1 1.080.247.00	Mounting plate compl.
05	1 1	1 1.077.100.05	l Socket alug
to	, -		1
above	1	1 1.077.100.21	Clamping sleeve
3001	1 1		I Screw M3x6
1	î	•	I Lock washer
	·	+	† = = = = = = = = = = = = = = = = = = =



# HEAD BLOCK ASSEMBLY REC/REPRO



### **HEAD BLOCK ASSEMBLY**

1			
			Headblock assembly (REPRODUCE)
01 to			Head block cover
above	1	21.51.2472 21.51.2456	
02	1	1.020.709.00	Preamplifier Reproduce
03		1.020.680.05	Angle bracket
		1.020.680.04	•
to (	-	21.51.2354	   Screw
		1.020.680.03	
above	   4	1 21.51.2354	   Screw
06	•	1 1.020.682.05	
above	2	21.51.2355	
			Screen plate (top)
08 to	•	1.020.682.07	· ·
above	1	21.53.0355	Screw
		24.16.1030	
to above	1 1	   21.53.0461	   Screw
	1	24.16.1040	Lock washer
10 to	1	1 1.020.682.10	Spindle
		21.53.0456 24.16.1040	
	:	1.020.682.08	Spindle
to above	•	21.53.0456	1
	•	1 1.020.692.05	Cover plate
to above	2	21.51.8460	•
	1 1	24.16.2040	Fan disk +
13	3	1.010.020.27	Spacer sleeve
		1 1.020.680.26	Sleeve
15	1 1		Guide (Reproduce Version)
16	1	·	Spacer shim (Reproduce Version
17	1	1.020.891.00	Guide roller
	1	1 1.020.692.04	Guide 
above	•	41.99.0108	Sinter bearing
19	1	1.020.692.03	Spacer shim
20	2	21.53.0372	•
21	2	24.16.1030	


### **HEAD BLOCK ASSEMBLY**

INDEX	QTY (	ARTICLE NUMBER	PART NAME
22	1	1.020.692.01	Screen plate 0.15" (bottom)
23   to	1	1.020.680.15	Guide 0.15"
above	1	21.53.0456   24.16.1040	Screw Lock washer
24	2	1.020.680.22	Knob
		1.020.680.23	
	2	1.020.680.24	Pin
26 to	2	1.020.680.25	Guiding nut
above	2	25.06.5155	Pin
27 to	2	1.020.680.50	Adjusting plate
above		41.01.0130	Ball Adjusting screw
28		1.020.768.13	
to   above	l   2		Pressure spring
	28	37.01.0101     1.010.004.27	Plate spring   Spacer sleeve
	2	22.01.8030	Nut
29	1	1.020.691.00	Headblock assembly
		1 1.116.801.00	Reproduce head
31	2	1.216.001.01	Screen cover
32		1.216.001.03	
33		1.020.680.51	Screen cover
34	2	21.51.2472	
37	1		24 – Pin socket
38	1	1 21.53.2472	Screw M4x16
39	1	21.53.2456	
		1.020.698.00	Headblock assembly (REC/REPRO)
			as 1.020.699.00 however:
01	1	1.020.692.06	Headblock cover
02	1 1	1.020.708.00	Preamplifier Reproduce
12	1	1.020.697.05	
29	1	1.020.679.00	Head block assembly
35 to	2	1.116.712.01	Erase head
above		1.710.122.02	Spacer shim Lower part to Erase head
36	1	1.116.800.00	Record head

# HEAD BLOCK ASSEMBLY


	ARTICLE NUMBER	PART NAME
1	1.020.697.00	Headblock assembly fulltrack (REC/REPRO)
1	1	as 1.020.698.00 however
36   1	1.317.110.00	
	+	THE THE THE THE THE THE THE THE THE THE

# Accessory set for Philips ferrite heads




Û1	1 1	21.02.2278	Screw
92	1 1	23.99.0110	
		1.216.001.01	
04	1 1	1 1.216.001.03	
		23.01.2043	
06	1 1	•	Record head Reproduce head Record head (Fulltrack)
07	•	21.01.0278	
08	•	24.16.1025	Lock washer
09		1.020.680.52	
10		1.020.680.54	Screw spec。
	1 2	21.01.0277	
	1 1	1.020.680.51	Rottom screen
13	1 1	1 1.020.680.50	
		· · · · · · · · · · · · · · · · · · ·	

### COVER



### COVER


		ARTICLE NUMBER	PART NAME
01	1	1.081.613.00	Tape deck cover (front)
02	1	1.081.602.00	Tape deck cover (rear)
03	1	1.080.362.00	Lower cover (rear)
04	1	1.080.362.02	Lower cover (front)
,		·	



### **EDIT SLIDER**

INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.080.319.00	EDIT slider 0.25"
01   to	1	1.080.319.01	Tape lifter bolt 0.25"
above	1	24.16.1030   22.01.8030	Lock washer Nut
02   to	1	1.080.318.06	Knob
above	1		Lock washer Nut
03	1	1.080.318.01	Slider
04	2	1.020.820.03	Slider case
05	2	21.01.2357	Screw
06	2	1.080.319.02	Spring
07	2	1.010.029.23	Washer
08	2	23.01.2032	
09	2	22.01.8030	Nut

# TAPE END SWITCH




# Mounting accessories


1	1	1	21.53.0521   Screw M5×14
1	1	1	24.16.1050   Lock washer
		-+	

### TAPE END SWITCH

INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.080.313.00	Tape end switch
01	1	1.080.300.01	Base plate
02	1	1 1.080.300.03	Light projector
03	1	1.080.300.04	Light detector
04   to	1	1.080.313.01	Mount
above	2	21.01.0355   24.16.1030	Screw Lock washer
05	1	35.03.0109	Securing strap
06   to	1	54.02.0403	Molex connector
abovel	1 3	54.02.0411   54.02.0412	
07		21.53.0471	Fixing screw
08	1 2 2	1.080.300.02     21.01.0204     24.16.1020	Clamp Screw Lock washer
09	1	1 1.080.313.02	Bush
10	1	1 1.080.300.07	Mirror
11	1	1 1.080.303.04	Pressure spring




#### PINCH ROLLER ASSEMBLY



#### PINCH RÖLLER ASSEMBLY


INDEX		ARTICLE NUMBER	PART NAME
		1.080.122.00	Pinch roller assembly 0.15"
			Dashpot, compl.
02	1	21.53.0455	
03	13	24.16.1040	Lock washer
,	4	1.010.018.23	Washer
	4		Screw M4x10
	1	55.01.0124	Microswitch
07	1	1.080.120.10	Bracket
08		1 1.014.745.00 1	Pressure solenoid
09	2	1.014.743.00	Solenoid armature, compl.
10	2	25.06.8356	Cylindrical pin
11	1	1.080.123.00	Rod
12	2	24.16.3023	
13	1	1 1.080.124.01	Die cast chassis
14	1 1	1.030.120.14	
15	·	1.080.230.05	Tension spring
16	1	1.080.125.04	Tension spring
17	•   6	24.16.3080	Circlip
18	2	1.080.126.01	
19	•   6		Ball bearing
20	+ 1 6	37.02.0206	Spring washer K
	1 5	1 24.16.4220	Retaining ring D22
22	1	1.080.140.31	
23		1.080.139.01	Andruckarm 0∙15"
24	1		Eye screw, right - hand thread
25	2	1.080.135.03	Spindle
26	1	1.080.130.02	Eye screw, left - hand thread
27	1	22.01.8050	Nut M5
28		1.080.130.01	
29	1	1 1.080.135.02	Eye screw, right-hand thread
30	1	22.01.8040	
31		1.080.125.03	
32	4	1.080.124.02	Clamp

INDEX	QTY	ARTICLE NUMBER	PART NAME
33	8	21.53.0472	Screw
34 to	1	54.02.0403	Molex plug housing
above	1 4	54.02.0411   54.02.0412	
35	4	22.01.8030	Nut
36	8	24.16.1030	
37	4	21.53.0353	Screw
38	4	21.53.0372	
39	1	1.080.120.08	Bracket
40	1	55.01.0124	Microswitch
41	2	1.080.120.09	Switching bolt
42	1	1.080.120.06	Rod
43	1	1.080.247.00	Mounting plate
44	1	1.080.130.02	Eye Screw, left-hand thread
45	1	1.080.115.04	Collar
46	1	1.080.115.05	Hexagonal M12
47	1	1.010.056.37	Pressure spring
48	1	1.080.115.03	Clamping sleeve
49	1	1.080.115.31	Collar M5 left handed thread
50	1		Shank screw M5 handed thread




# PINCH ROLLER

INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.080.549.00	Pinch roller compl. 0.15"
01	1	1.080.530.05	Cover nut
02	1	1.080.549.01	Pinch roller polished, 015"
03	1	21.53.0456	Screw
04	1	23.01.3043	Washer
05	. 2	41.99.0103	Ball bearing
06	2	37.02.0206	Spring washer
07	1	24.16.4220	Circlip D22
08	1	1.080.530.03	Spacer shim
09	1	1.080.550.01	Bearing housing 0.25"
10	- age and one can can	1.080.530.06     /07     /08     /09     /10	Spacer shim (Factory adjusted)
11	1	1.080.530.02	Spindle 0.25"
12	1	24.16.1060	Lock washer
13	1	2,2.01.8060	Nut
14	1	23.01.2064	Washer



# **GUIDE ROLLER, LEFT**


INDEX	QTY	ARTICLE NUMBER	PART NAME
01	1	21.53.2456	Screw M4x10
02	1	1.080.105.04	Clamp
03	1	1.080.595.02	Guide roller left 0.15"
		1.080.196.00	Idler roller bearing compl.
04       		1.080.530.06	Spacer shim (Factory adjusted)
05	2	41.99.0111	Ball bearing
06	2	24.16.4220	Retaining ring, internal
07	1	1.080.205.00	Bearing housing, compl.
08	1	1.080.196.01	Snaft
09	3	21.53.0472	Screw M4x16
10	3	24.16.1040	Lock washer
11	2	37.02.0206	Spring washer
12	1	24.16.5100	Retaining ring external D10



# TAPE TENSION SENSOR, LEFT 1.080.142.00, RIGHT 1.080.146.00

INDEX	QTY [	ARTICLE NUMBER	PART NAME
		1.080.595.08	Engraved cover, left
02	1	1.080.595.07	Engraved cover, right
03	1	1.080.142.10	Countersunk screw, special
04	1	24.16.3032	
05 1	1 1	1.080.148.00	Lock wheel, with bolt
06	1	1.080.530.06	Spacer shim
07	1 1	1.080.153.00	Holding magnet, compl.
/19	. 2	24.16.3080	
00	. 1	1 1 080 142 07	Spindle
10	1 2	41.99.0111	
11	1 2	1 24.16.4220	Retaining ring, internal 022
12	1 1	1.080.150.00	Bearing housing, compl.
13	1 2	37.02.0206	l Sorino washer
14	. 1	1 1.080.310.08	Coupling fork
15	1 2	1 21-53-0355	I Screw
16	1 1	1 1.080.142.08	Coupling lever
17	1 1	1 25.06.8208	Cylindrical pin
18	1 1	1 58.99.0110	Potentiometer with nut
19	1 2	37.02.0105	Spring washer K
20	1 2	1 21.60.4455	Hexagonal - head screw
21	1 2	1 24 - 16 - 1040	Lock washer
		1 23.01.2043	Washer
23	1 1		Connector housing
to above	1	1 54.02.0412	   Molex femal +
	1 1	1 1.080.142.06	Angle bracket
25	1 1	1 1.080.142.11	Coupling washer
26	1 3	1 21.53.0354	_
27	1 3	1 24.16.1030	
28	1 3	21.53.0472	Screw M4x16
29	1 3	1 24.16.1040	
30	1 3	1 22.01.5040	
31	1 3	1 1.080.142.03	The state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the s
32	1 1	1 1.080.142.02	3locking disc
33	1 1		† Spring (pressure)
34	1 1	1 24.16.5160	Retaining ring
35	1 2		Spring washer
			·


# TAPE TENSION SENSOR ROLLERS



# TAPE TENSION SENSOR ROLLERS

INDEX	QTY	ARTICLE NUMBER	PART NAME
	! !	1.080.449.81	Tape tension sensor rollers 0.15
	1	1.080.454.00	Guide roller 0.15" compl. mounted
01	1	1.080.457.00	Guide roller with spindle
02	2	41.04.0102	Ball bearing
03	1	1.080.453.01	Bearing housing
04	2	24.16.4100	Retaining housing, internal
05	1 2	37.02.0201	Spring washer
06	!	1.080.453.03	Spacer shim
07	1	24.16.5030	Retaining ring, external
08	     	1.080.450.02     /03     /04     /05	Spacer shim (Factory adjusted)
	1	1.080.460.00	Roller compl• mounted
09	1	1.080.463.00	Roller with spindel
10	1	1.080.450.01	Roller support
11	3	24.16.1030	Lock washer
12	3	21.53.0354	Screw
		+	


### DASHPOT ASSEMBLY



# DASHPOT ASSEMBLY


INDEX	QTY	ARTICLE NUMBER	PART NAME
01	1 1		Mounting plate
	1		Spring assembly, compl.
03	1	24.16.3032	Circlip
03	1	1.080.170.10	Adjusting ring
04	2	21.53.0353	Screw
05	1	1.080.170.08	
06	1	1.080.169.01	Axle
07	1	1.080.170.06	Pressure spring
08	1		Pressure spring
09	1	•	Pressure spring
10	3	1.080.170.05	Guiding sleeve
11	1	1.080.170.01	Linkage
12		21.01.0354	Screw
13		24•16•1030	Lock washer
14	1	1.080.175.00	Searing
15	1	1.080.170.11	
15	1	1.080.170.02	Pivot pin
17	2	1.080.166.27	
18	4	24.16.3023	
19	1	1.080.158.00	Lever riveted
20	1	1.080.142.05	Rød
21	1	1.080.166.29	Clamping ring
22	2	1.080.166.28	Clamping part
23	1	1.080.166.26	Lever
24	1		Dashoot 0.15", compl.

# ADAPTOR



# ADAPTOR


INDEX	QTY	ARTICLE NUMBER	PART NAME
01	1	1.013.350.00	Adaptor compl.
02	1	89.01.0354	NAB Adaptor
03	1	1.013.331.00	NAB Adaptor with grip slave
04	1	1.013.326.00	Three - pronged adaptor
05	1	10.039.001.00	rubber ring
06	1	1.062.390.01	Guiding sleeve
07   to	1	1.013.326.06	Adaptor screw
	3	1.736.794.03	Spring
08	1	1.013.326.03	Bolt
09	1	1.013.325.00	Adaptor support
10	1	1.013.325.03	Rubber ring
11	1	37.02.0216	Spring washer



### BRAKES


INDEX	l QTY	ARTICLE NUMBER!	PART NAME
01	1	1.080.230.06	Tension spring
02	1 1	1 1-080-105-03 1	Protective hood
03		1.080.250.00	Brake drum, compl.
04	1	1.080.238.00	Brake band, compl.
*CON AGO: 4000 4000 4000		1.080.230.00	Brake chassis left, compl.
		1 1.080.240.00	Brake chassis right, compl.
05	1 1	1 1.080.230.05 1	Tension spring
06	5	24.16.3032	
07	1 1	1.080.230.01	
08	1 2	1 37.01.0102 1	Spring washer K
09	1 3	I 24.16.1040 I	
10	1 1	1 22.01.8040 1	
11	1 4	23.01.1043	
12	1 2	21.53.0454	Screw
13		25.16.2106	
14		1 1.080.230.02	
15		1 1.080.233.00	Brake chassis (left) Brake chassis (right)
16	1	1.080.105.21	
17	1	L 1.080.112.02 L	
18	1	1.080.236.00	
19	1		Solenoid armature, compl.
20	1	1.014.750.00	Solenoid
	1	54.02.0400 1	
	2	54.02.0411	Molex pin

#### SPOOLING MOTOR



# SPOOLING MOTOR


INDEX	1 QTY	ARTICLE NUMBER	PART NAME
	!	1.021.240.00	Spooling motor, compl.
01	1	1.021.240.06	Circlip surface polished
02	1	24.16.5100	Retaining ring D10, external
03	2	41.99.0103	Ball bearing
04	2	24.16.4220	Retaining ring D22, internal
05	1	1.021.242.00	Bearing flange with stator
06	1 4	37.02.0106	Spring washer
07	1 3	21.53.0456	Screw
08	3	24.16.1040	Lock washer
09	1 1	1.021.240.05	Rotor polished
10	1	1.021.241.00	Spooling motor spindle, compl.
	1 1	54.02.0402	Plug Molex
	1 3	54.02.0411	Molex pin
			~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~



### **CAPSTAN MOTOR**

INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.021.192.00	Capstan motor 0.15" (Master)
		1.021.193.00	Capstan motor 0.15" (Slave)
01	1	54.02.0421	Molex case
to above	! ! 	54.02.0412	Molex femal
02 to	1	1.021.140.05	Supporting sheet metal
above	1 1	21.53.0353   24.16.1030	Screw Lock washer
	1 	+	
03	2	1.021.186.01	Bracket
04	4	1.021.186.07	Spacer bolt
05	1	1 1.021.186.00	Scanner head 7.5/15 ips, (left)
06	1	1.021.188.00	Scanner head, (right)
07	4	21.01.0278	Screw
08	4	24.16.1025	Lock washer
09	4	1.228.211.02	Washer
10	1	1.021.183.01	Rotor compl. with flywheel
11	1	1.021.183.02	Rotor compl. with flywheel
12	1	1.021.160.10	Snaft lock
13	4	24.16.1040	Lock washer
14	4	21.53.0461	Screw


### COUNTER



# COUNTER


TNDEXI	OTV	LARTICLE	MIIMBED	DADT	NAME	
INDEVI	wii	IAKILLE	NUMBERI	PARI	NAME	

		t	TAKT HAILE
		1.228.810.00	5 - digit counter
01 to	1	1.228.220.00	Counter reset assembly
above	1	55.01.0124	Microswitch
	1	55.01.0126	Roll spring lever
	1	1.080.260.12	Pressure spring
	1	1 1.228.205.09	Counter reset button support
	l l	[ 1.010.104.27 ]	Threaded bolt
	2	24.16.1030	Lock washer
1	2	23.01.2032	Washer
02	1	1 1.228.813.00	Counter p.c. board
03	1	1.228.812.00	Basis board
04 to	1	1.228.314.00	Display board
abovel	4	   21•53•0356	Screw
30346	4	24.16.1030	Lock washer
,	4	1.010.015.27	Spacer bush
		<b>,</b>	
05	1	1 1.228.810.01	Display support
to	ļ	l	
abovel	2	21.53.0355	Screw
	2	24.16.1030	Lock washer
06	1	1.228.205.08	Supporting bracket
07	1	1.228.811.00	Counter decoder A 80
08 (	1	1.030.260.05	Counter reset button cover
apovel	1	1.080.260.20	Labeled zero button lower part
09	1	1.080.105.61	Threadedplate



# **PUSH BUTTON ASSEMBLY**


INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.080.260.00	Push button assembly
01	1	1.080.260.01	Push button support
02			Push button top part
03	2	1.080.260.14	Symbol "Forward - Rewind"
04	1	1.080.260.15	Symbol "Play"
05	1	1.080.260.18	Symbol "Edit"
06	1	1.080.260.16	Symbol "Record"
07	1	1.080.260.17	Symbol "Stop"
08	6	1.080.260.19	
09	6		Push button lower part
10	1	1.080.260.26	Timer cover
11	1	1.228.810.02	Anti - glare glass printed
12	2	22.16.2501	
13	6	1 1.080.260.09	Button holder
14	•   6	24.16.3019	
15	·   6	1 1.080.270.00	Contact holder
16	12	24.16.3032	Circlip
17	+   6	1 1.080.260.12	Pressure spring
	•	20.21.7355	
19	1 1	1 1.080.260.08	Bearing rail
			Threaded bolt
21	1 6	55.02.0101	Wiper holder
22	1 6	1.010.007.55	Wiper contact
23	6	51.02.0145	• "
24	1	1.080.275.00	Push button print, assembled
25	12	21.26.0355	Screw
26	12	24.16.1030	Lock washer
27	4	21.01.0201	Screw
28	4	1.228.211.02	Spec. washer
29	1 4	24.16.1020	Lock washer



# TAPE DIRECTION SWITCH

INDEX	QTY	ı	ARTICLE NUMBER!	PAF	RT NAME
			1.080.259.00	Tap	pe direction switch
01	2	- • !	21.53.0457	Sci	rew
02	2		22.01.8040	Nut	
03	4	-+ 	24.16.1040	Loc	k washer
04	2	-+ !	55.03.0130	Ill	uminated push button switch
to (	2	1	51.02.0145	Bul	b 24V, 0,04A
05	1		1.080.104.12	Bra	ocket
06	1		1.080.104.13	Hol	der
07	1		1.080.259.01	Kal	otte "Play forward"
08	1	1	1.080.259.02	Kal	otte "Play reverse"
09	2	1	21.53.0471	Sci	ew M4x14
10	2	1	24.16.1040	Loc	k washer
	1	1	54.02.0418	Mo	ex plug case
	6	-+	54.02.0411	Mo	ex pin


# **CUTTER CONTROL ASSEMBLY**



### **CUTTER CONTROL ASSEMBLY**

TNDEV	1 NTV	ARTICLE NUMBER	I DADT NAME
	+	+	Cutter control assembly
01	1		
02	1	1 1.080.311.01	Cam wheel
to above	   1   1	•	   Screw M3x8   Pressure spring
03 to	1	1.080.310.01	Bracket
above	_	1.077.450.04	Bush
04 to		55.01.0124	Microswitch
above	2		Screw M3x16 Lock washer Hexagonal nut
05	1	1.010.017.27	Spacer bush
06	2	1 1.010.025.27	Threaded stud
to above	2 2	21.53.0354     24.16.1030	Screw Lock washer
07	1	1.080.310.02	Bearing bracket
08	2	1.080.310.07	Threaded bolt
09 to	1	1.080.310.08	Driving fork
above		1.077.450.04   21.53.0355   23.01.1064	Screw
10	1	25.06.8208	Cylindrical pin
11 to		1.080.310.09	Coupling lever
above	_	21.53.0355	Screw
12 to		1.080.310.03   	Mounting bracket
above	2	21.53.0354   24.16.1030	
13	1	58.10.9002	Potentiom R 10
14   to	1	54.02.0403	Molex case
above	1 4	54.02.0411   54.02.0412	Molex femal
15	1	1.080.105.10	
16	1	21.59.5452	Set screw
17	2	21.53.0457	Screw M4x12
18	2	24.16.1040	Lock washer

# MAINS SWITCH



# MAINS SWITCH

INDEX	QTY	ARTICLE NUMBER	PART NAME
		1.080.284.00	Mains and tape speed switch
01	1	1.080.284.01	Base plate
02	1	1.080.280.01	Shaft
03	1	1.080.286.00	Mounting bow, compl.
04	1	1.080.283.01	Protection cover
to above	1	1 1.080.283.02   28.21.1440	Isulating plate Pipe rivet
05	2	1.077.440.04	Bush
06	4	24.16.3040	
07	1	1.077.450.00	Switching disk
08	2	55.01.0124	Microswitch
to above	2	1.077.440.08     21.01.0213     23.01.1022     24.99.0109     22.01.8020	Screw Washer Spring washer
09 to	1	54.02.0403	Molex case 5 pole
above	4	54.02.0411	Molex pin
10	2	21.59.5452	Set screw
11	1	1.080.105.10	
		+	